

**KARPAGAM ACADEMY OF HIGHER EDUCATION**

(Deemed to be University)

(Established Under Section 3 of UGC Act 1956)

Coimbatore – 641 021.

(For the candidates admitted from 2018 onwards)

**DEPARTMENT OF CHEMISTRY****SUBJECT NAME: POLYMER CHEMISTRY    SUBJECT CODE: 17CHP305A****SEMESTER: III****CLASS: II M. Sc CHEMISTRY****Scope**

Polymer chemistry frames much of our understanding of the natural world and continues to bring new technologies that are useful to every aspect of human life. Polymer chemistry is an exciting and challenging course, which helps us to understand the various aspects of compounds used in our day to day life. Polymer chemistry interfaces with a myriad of other disciplines and fields. It is fundamental to understand other areas of chemistry, biology and medicine. Due to highly prized nature of Polymer chemistry and its diverse topics, it lays the foundation for extremely productive and exciting career in variety of disciplines as pharmaceutical, agrochemical, mineralogy, molecular biology, biotechnology, nanotechnology, polymer technology, teaching research, scientific publication and so on. The importance of this subject would not diminish over time, so it will remain a promising career path. This course presents the basic principles of polymerization, coordination polymerization, determination of molecular weight of polymers, properties of polymers.

**Objectives**

1. To learn about the basic concepts of kinetics and mechanism of polymerization.
2. To learn about the coordination polymerization.
3. To understand the Molecular weight of the polymers and their properties.
4. To learn about the processing of polymers.

**Methodology**

Blackboard teaching, Powerpoint presentation and group discussion.

**UNIT – I**

**Polymer Basic Concepts:** Monomers, repeat units, degree of polymerization, linear, branched and network polymers. Condensation polymerization: Mechanism of stepwise polymerization. Kinetics and statistics of linear stepwise polymerization. Addition polymerization: Free radical, cationic and anionic polymerization. Polymerization conditions. Polymerization in homogeneous and heterogeneous systems.

**UNIT – II**

**Co-ordination Polymerization:** Kinetics, mono and bimetallic mechanism of co-ordination polymers. Zeigler Natta catalyst, co-polymerization: Block and graft co-polymers, kinetics of copolymerization. Types of co-polymerization. Reactivity ratio.

**UNIT-III**

**Molecular Weight and Properties:** Polydispersion – average molecular weight concept, number, weight and viscosity average molecular weights. Measurement of molecular weights. Viscosity, light scattering, osmotic and ultracentrifugation methods. Polymer structure and physical properties – crystalline melting point  $T_m$ . The glass transition temperature. Determination of  $T_g$ . Relationship between  $T_m$  and  $T_g$ .

**UNIT – IV**

**Polymer Processing:** Plastics, elastomers and fibres. Compounding, processing techniques: calendering, die casting, rotational casting, film casting, injection moulding, blow moulding extrusion, moulding, thermoforming, foaming, reinforcing and fibre spinning.

**UNIT – V**


**Properties of Commercial Polymers:** Polyethylene, polyvinyl chloride, polyamides, polyesters, phenolic resins, epoxy resins and silicone polymers. Functional polymers, fire retarding polymers and electrically conducting polymers. Biomedical polymers – contact lens, dental polymers, artificial heart, kidney, skin and blood cells.

**SUGGESTED READINGS:****Text Books:**

1. Billmeyer, F. W. (2003). *Text Book of Polymer Science* (III Edition). New York: John Wiley.
2. Gowariker, V. R., Viswanathan, N. V., & Sreedhar, J. (2015). *Polymer Science* (II Edition). New Delhi: New Age International Private Ltd.
3. Alcock, H. R., Lampe, F. W., & Mark, J. E. (2003). *Contemporary Polymer Chemistry* (III Edition). NJ: Prentice Hall. Englewood Cliffs.

**Reference Books:**

1. Flory, P. J. (1953). *Principles of Polymer Chemistry*. New York: Cornell University Press.
2. Odian, G. (2004). *Principles of Polymerization* (IV Edition). New York: John Wiley & Sons.

**KARPAGAM ACADEMY OF HIGHER EDUCATION**

(Deemed to be University)

(Established Under Section 3 of UGC Act 1956)

Coimbatore - 641 021.

(For the candidates admitted from 2017 onwards)

**DEPARTMENT OF CHEMISTRY****SUBJECT NAME: POLYMER CHEMISTRY****SUBJECT CODE: 17CHP305A****SEMESTER: III****CLASS: II M. Sc CHEMISTRY****LECTURE PLAN**UNIT-1

Polymer Basic Concepts

Total no. of hours: 10

S.NO	LECTURE DURATION	TOPICS TO BE COVERED	SUPPORT MATERIALS
1.	1	Monomers, repeat units, degree of polymerization	T1: 9-12;; T2: 4-5 ,239 T1: 96-98; T2: 139-141
2.	1	Linear, branched and network polymers	T1: 142-143; T2: 5-8, T1: 142-143
3.	1	Condensation polymerization: Mechanism of stepwise polymerization	T2: 25-26, 26-32
4.	1	Kinetics of linear step wise polymerization	T2: 33-35
5.	1	Statistics of linear step wise polymerization	T2: 35-38
6.	1	Addition polymerization: Free radical,	T1: 105,116-120; T2: 50-53, 85-88, 89-90
7.	1	Cationic and anionic polymerization	T1: 105,116-120; T2: 50-53, 85-88, 89-90
8.	1	Polymerization conditions	T2: 126
9.	1	Polymerization in homogenous and heterogeneous systems	T2: 127-133
10.	1	Discussion of important questions	

Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.**Reference book****R1:** M.S Bhatnagar, 2004, "A text book of polymers". I<sup>st</sup> Edition, S.Chand & Company.

UNIT-2

Co-ordination Polymerization

Total no. of hours: 10

S.NO	LECTURE DURATION	TOPIC TO BE COVERED	SUPPORT MATERIALS
1.	1	Co-ordination polymerization	T2: 91
2.	1	Kinetics of co-ordination polymerization	T2: 94-96
3.	1	Mono metallic mechanism of co-ordination polymers	T1: 47-52; T2: 92-93
4.	1	bimetallic mechanism of co-ordination polymers	T1: 47-52; T2: 92-93
5.	1	Ziegler Natta catalyst	T1: 46; T2: 91-94
6.	1	Co-polymerization: Block and graft co-polymers	T1: 120-122; T2: 142-144
7.	1	Kinetics of copolymerization	T1: 101,107-108
8.	1	Types of co-polymerization	T1: 103-106, T2: 182,206
9.	1	Reactivity ratio	T1: 106-107
10.	1	Discussion of important questions	

Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.

Reference book

R1: M.S Bhatnagar, 2004, "A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

UNIT -3

Molecular Weight and Properties

Total no. of hours: 10

S.NO	LECTURE DURATION	TOPIC TO BE COVERED	SUPPORT MATERIALS
1	1	Polydispersion- Average molecular weight concept, number	T1:86-88,
2	1	Weight and viscosity average molecular weights	T1: 89-92,
3	1	Measurements of molecular weights	T2: 208-213, 198
4	1	Viscosity, light scattering	T2: 208, T1: 404-408, T1: 413-419
5	1	Osmotic method	T2: 205-206, T1: 392-401
6	1	Ultracentrifugation methods	T2: 207, T1: 409-413
7	1	Polymer structure and physical properties- Crystalline melting point $T_m$	T1: 100-104; T2:331-336
8	1	The glass transition temperature $T_g$	T2: 337
9	1	Determination of $T_g$ , Relation between $T_m$ and $T_g$ .	T1: 423-426 T2: 337-340
10	1	Discussion of important questions	

Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York

Reference book

R1: M.S Bhatnagar, 2004, " A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

UNIT -4

Polymer Processing

Total no. of hours: 09

S.NO	LECTURE DURATION	TOPIC TO BE COVERED	SUPPORT MATERIALS
1	1	Plastics, elastomers and fibres.	T1: 14,221, 225, 429,229,449 T2: 351, 371,486,471-475
2	1	Compounding	T1: 450-451
3	1	Process techniques: Calendering,	T1: 452-453; T2:464-466
4	1	Die casting	T1: 453-454; T2:464-466
5	1	rotational casting, film casting	T1: 454-456; T2: 465-466
6	1	injection moulding, blow moulding, Extrusion moulding	T1: 457-462; T2: 458-461, 461-464
7	1	Thermoforming	T1: 462-464; T2: 467-469
8	1	Foaming	T1: 462-464; T2: 467-469
9	1	Reinforcing, Fiber spinning	T1: 465-469, T1: 470-474; T2: 491-496
10	1	Discussion of important questions	

Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986(2014 re-print). "Polymer Science", *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2008(Re-print). "Text Book of Polymer Science". III Edition, John Wiley, New York.

Reference book

R1: M.S Bhatnagar, 2004, "A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

UNIT -5

Properties of Commercial Polymers

Total no. of hours: 09

S.NO	LECTURE DURATION	TOPIC TO BE COVERED	SUPPORT MATERIALS
1	1	Polyethylene, Polyvinyl chloride	T1: 215-217, 236-238, 227-229
2	1	Polyamides	T1: 215-217, 236-238, 227-229
3	1	Polyesters and Silicon polymers	T1: 221-223, 255-256; T2: 442-445, 448-450
4	1	Phenolic resins, Epoxy resins	T1: 251-254; T2: 436-440, 445-446
5	1	Functional polymers, Fire retarding Polymers	W <sub>1</sub>
6	1	Electrically conducting polymers	W <sub>1</sub>
7	1	Bio-medical polymers- contact lens, dental polymers	W <sub>2</sub> , Journals
8	1	Artificial heart, kidney, skin and blood cells.	W <sub>2</sub> , W <sub>3</sub>
9	1	Recapitulation and discussion of Previous year question	

Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York

Reference book

R1: M.S Bhatnagar, 2004, "A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

Web Address:

W<sub>1</sub>: [https://en.wikipedia.org/wiki/Fire-safe\\_polymers](https://en.wikipedia.org/wiki/Fire-safe_polymers) or Functional or Electrically conducting polymers.

W<sub>2</sub>: <https://en.wikipedia.org/wiki/Artificial-heart> or <https://biomedicalpolymers/applications>.

W<sub>3</sub>: <https://en.wikipedia.org/wiki/Artificial-kidney>

Journals: Applications of polymers in the biomedical field, Current-Trends in Biomedical eng & biosensors, vol.4, issue.4 (2017), Ibrahim et al (mini review)

## UNIT-1


### SYLLABUS

Monomers, repeat units, degree of polymerization, Linear, branched and network Polymers. Condensation Polymerization: Mechanism of stepwise polymerization. Kinetics and statistics of linear stepwise polymerization. Addition polymerization: Free radical, cationic and anionic polymerization. Polymerization conditions. Polymerization in homogeneous and heterogeneous systems.

### Polymer Basic Concepts

#### INTRODUCTION

#### **Polymer**



Appearance of real linear polymer chains as recorded using an atomic force microscope on a surface, under liquid medium. Chain contour length for this polymer is ~204 nm; thickness is ~0.4 nm.

#### **IUPAC definition**

Substance composed of macromolecules. Applicable to substance macromolecular in nature like cross-linked systems that can be considered as one macromolecule.

A **polymer** (/ˈpɒlɪmər/; Greek *poly-*, "many" + *-mer*, "parts") is a large molecule, or macromolecule, composed of many repeated subunits. Because of their broad range of properties, both synthetic and natural polymers play essential and ubiquitous roles in everyday life. Polymers range from familiar synthetic plastics such as polystyrene to natural biopolymers such as DNA and proteins that are fundamental to biological structure and function. Polymers, both natural and synthetic, are created via polymerization of many small molecules, known as monomers. Their consequently large molecular mass relative to small



molecule compounds produces unique physical properties, including toughness, viscoelasticity, and a tendency to form glasses and semicrystalline structures rather than crystals.

The term "polymer" derives from the ancient Greek word *πολύς* (*polus*, meaning "many, much") and *μέρος* (*meros*, meaning "parts"), and refers to a molecule whose structure is composed of multiple repeating units, from which originates a characteristic of high relative molecular mass and attendant properties. The units composing polymers derive, actually or conceptually, from molecules of low relative molecular mass. The term was coined in 1833 by Jöns Jacob Berzelius, though with a definition distinct from the modern IUPAC definition. The modern concept of polymers as covalently bonded macromolecular structures was proposed in 1920 by Hermann Staudinger, who spent the next decade finding experimental evidence for this hypothesis.

Polymers are studied in the fields of biophysics and macromolecular science, and polymer science (which includes polymer chemistry and polymer physics). Historically, products arising from the linkage of repeating units by covalent chemical bonds have been the primary focus of polymer science; emerging important areas of the science now focus on non-covalent links. Polyisoprene of latex rubber is an example of a natural/biological polymer, and the polystyrene of styrofoam is an example of a synthetic polymer. In biological contexts, essentially all biological macromolecules—i.e., proteins (polyamides), nucleic acids (polynucleotides), and polysaccharides—are purely polymeric, or are composed in large part of polymeric components—e.g., isoprenylated/lipid-modified glycoproteins, where small lipidic molecules and oligosaccharide modifications occur on the polyamide backbone of the protein.

The simplest theoretical models for polymers are ideal chains.

### **Monomer**

A **monomer** (*/ˈmɒnəməɹ/* **MON-** -m r) (*mono-*, "one" + *-mer*, "part") is a molecule that, as a unit, binds chemically or supramolecularly to other molecules to form a supramolecularpolymer. Large numbers of monomer units combine to form polymers in a process called polymerization. It is a small molecule of an organic substance. A double bond exist between the individual molecule which is weak. Molecules of a small number of monomer units (up to a few dozen) are called oligomers. The term "monomeric protein" may also be used to describe one of the proteins making up a multiprotein complex.

### **Biopolymer groupings, and the types of monomers that create them:**

- For *lipids* (Diglycerides, triglycerides)\*, the monomers are **glycerol and fatty acids**.
- For *proteins* (Polypeptides), the monomers are **amino acids**.

### **Repeat unit**

A **repeat unit** or **repeating unit** is a part of a polymer whose repetition would produce the complete polymer chain (except for the end-groups) by linking the repeat units together successively along the chain, like the beads of a necklace.

A repeat unit is sometimes called a *mer* or *mer unit*. "Mer" originates from the Greek word "meros," which means part. The word polymer derives its meaning from this, which means "many mers." A repeat unit (or mer), is not to be confused with the term monomer, which refers to the small molecule from which a polymer is synthesized.

One of the simplest repeat units is that of the addition polymer polyvinyl chloride,  $-\text{[CH}_2\text{-CHCl]}_n-$ , whose repeat unit is  $-\text{[CH}_2\text{-CHCl]}-$ . In this case the repeat unit has the same atoms as the monomer vinyl chloride  $\text{CH}_2=\text{CHCl}$ . When the polymer is formed, the  $\text{C}=\text{C}$  double bond in the monomer is replaced by a  $\text{C}-\text{C}$  single bond in the polymer repeat unit, which links by two new bonds to adjoining repeat units.

In condensation polymers (see examples below), the repeat unit contains fewer atoms than the monomer or monomers from which it is formed.

The subscript "n" denotes the degree of polymerisation, that is, the number of units linked together. The molecular mass of the repeat unit,  $M_R$ , is simply the sum of the atomic masses of the atoms within the repeat unit. The molecular mass of the chain is just the product  $nM_R$ . Other than monodisperse polymers, there is normally a molar mass distribution caused by chains of different length.

In copolymers there are two or more types of repeat unit, which may be arranged in alternation, or at random, or in other more complex patterns.

### Degree of polymerization

The **degree of polymerization**, or **DP**, is the number of monomeric units in a macromolecule or polymer or oligomer molecule.

For a homopolymer, there is only one type of monomeric unit and the *number-average* degree of polymerization is given by  $\text{DP}_n = X_n = M_n / M_0$ , where  $M_n$  is the number-average molecular weight and  $M_0$  is the molecular weight of the monomer unit. For most industrial purposes, degrees of polymerization in the thousands or tens of thousands are desired. This number does not reflect the variation in molecule size of the polymer that typically occurs, it only represents the mean number of monomeric units.

Some authors, however, define DP as the number of repeat units, where for copolymers the repeat unit may not be identical to the monomeric unit. For example, in nylon-6,6, the repeat unit contains the two monomeric units  $-\text{NH}(\text{CH}_2)_6\text{NH}-$  and  $-\text{OC}(\text{CH}_2)_4\text{CO}-$ , so that a chain of 1000 monomeric units corresponds to 500 repeat units. The degree of polymerization or chain length is then 1000 by the first (IUPAC) definition, but 500 by the second.

### Classification of polymers:

**copolymer** - a polymer prepared from more than one monomer

**addition polymer** - a polymer that consists of a repeat unit equivalent to its monomer - generally vinyl polymers, e.g., polyethylene, or ring-opening polymers, e.g., poly(ethylene oxide)

**condensation polymer** - a polymer that differs from its monomer(s) by the elimination of a small molecule during polymerization (Carothers' original definition) e.g., polyamides and polyesters

the definition has been expanded to include any polymer that incorporates new functional group(s) in the chain that were not present in the monomers  
(to allow inclusion of polyurethanes)

### Descriptions of polymer structure:

**linear polymer** - a polymer consisting of a single continuous chain of repeat units

**branched polymer** - a polymer that includes side chains of repeat units connecting onto the main chain of repeat units (different from side chains already present in the monomers)

**crosslinked polymer** - a polymer that includes interconnections between chains, either formed during polymerization (by choice of monomer) or after polymerization (by adding a specific reagent)

**network polymer** - a crosslinked polymer that includes numerous interconnections between chains such that the entire sample is (or could be) a single molecule


### Condensation polymerization

The monomers that are involved in condensation polymerization are not the same as those in addition polymerization. The monomers for condensation polymerization have two main characteristics:

- ⇒ Instead of double bonds, these monomers have functional groups (like alcohol, amine, or carboxylic acid-groups).
- ⇒ Each monomer has at least two reactive sites, which usually means two functional groups.

#### The Amide Linkage:


When a carboxylic acid and an amine react, a water molecule is removed, and an amide molecule is formed.



Because of this amide formation, this bond is known as an *amide linkage*.

### The Ester Linkage:

When a carboxylic acid and an alcohol react, a water molecule is removed, and an ester molecule is formed.



Because of this ester formation, this bond is known as an *ester linkage*.


Monomers involved in condensation polymerization have functional groups. These functional groups combine to form amide and ester linkages. When this occurs, a water molecule is removed. Since water is removed, we call these reactions condensation reactions (water condenses out.). When a condensation reaction involves polymerization, we call it *condensation polymerization*.

### Examples: The Mechanism of Condensation Polymerization

That the monomers are joined by condensation polymerization have two functional groups. You also know (from Part 6) that a carboxylic acid and an amine can form an amide linkage, and a carboxylic acid and an alcohol can form an ester linkage. Since each monomer has two reactive sites, they can form long-chain polymers by making many amide or ester links. Let's look at two examples of common polymers made from the monomers we have studied.

#### Example 1:


A carboxylic acid monomer and an amine monomer can join in an amide linkage.




As before, a water molecule is removed, and an amide linkage is formed. Notice that an acid group remains on one end of the chain, which can react with another amine monomer. Similarly, an amine group remains on the other end of the chain, which can react with another acid monomer. Thus, monomers can continue to join by amide linkages to form a long chain. Because of the type of bond that links the monomers, this polymer is called a polyamide. The polymer made from these two six-carbon monomers is known as nylon-6,6. (Nylon products include hosiery, parachutes, and ropes.)

Example 2:



A carboxylic acid monomer and an alcohol monomer can join in an ester linkage.



A water molecule is removed as the ester linkage is formed. Notice the acid and the alcohol groups that are still available for bonding.



Because the monomers above are all joined by ester linkages, the polymer chain is a polyester. This one is called PET, which stands for poly(ethylene terephthalate). (PET is used to make soft-drink bottles, magnetic tape, and many other plastic products.)



### Stepwise polymerization

A number of different chemical reactions may be used to synthesize polymeric materials by step polymerization. These include esterification, amidation, the formation of urethanes, aromatic substitution, and others. Polymerization usually proceeds by the reactions between two different functional groups, for example, hydroxyl and carboxyl groups, or isocyanate and hydroxyl groups. All step polymerizations fall into two groups depending on the type of monomer(s) employed. The first involves two different bifunctional and/or polyfunctional monomers in which each monomer possesses only one type of functional group. (A polyfunctional monomer is a monomer with more than one functional group per molecule. A bifunctional monomer is one with two functional groups per molecule.) The second involves a single monomer containing both types of functional groups. The synthesis of polyamides



illustrates both groups of polymerization reactions. Thus polyamides can be obtained from the reaction of diamines with diacids.



or from the reaction of amino acids with themselves:




The two groups of reaction can be represented in a general manner by the equations




where A and B are the two different types of functional groups. The characteristics of these two polymerization reactions are very similar. The successful synthesis of high polymers (i.e., polymer of sufficiently high molecular weight to be useful from the practical viewpoint) using any step polymerization reaction generally is more difficult than the corresponding small molecule reaction, since high polymers can be achieved only at very high conversions (>98–99%). A conversion of 90%, which would be considered excellent for the synthesis of ethyl acetate or methyl benzamide, is a disaster for the synthesis of the corresponding polyester or polyamide. The need for very high conversions to synthesize high polymer places several stringent requirements on any reaction to be used for polymerization—a favorable equilibrium and the absence of cyclization and other side reactions. These stringent requirements are met by a relatively small fraction of the reactions familiar to and used by chemists to synthesize small molecules. An additional requirement for achieving high molecular weights is the need for the A and B functional groups to be present at very close to stoichiometric amounts.


### **Kinetics of Stepwise Polymerisation:**

Consider the polyesterification of a diacid and a diol to illustrate the general form of the kinetics of a typical step polymerization. Simple esterification is a well-known acidcatalyzed reaction and polyesterification follows the same course [Otton and Ratton, 1988; Vancso-Szmercsanyi and Makay-Bodi, 1969]. The reaction involves protonation of the carboxylic acid,



followed by reaction of the protonated specie with the alcohol to yield the ester





In the above equations and are used to indicate all acid or alcohol species in the reaction mixture (i.e., monomer, dimer, trimer, . . . , n-mer). Species I and II are shown in the form of their associated ion pairs since polymerization often takes place in organic media of low polarity. (A<sup>-</sup>) is the negative counter ion derived from the acid HA. Polyesterifications, like many other step polymerizations, are equilibrium reactions. However, from the practical viewpoint of obtaining high yields of high-molecular-weight product such polymerizations are run in a manner so as to continuously shift the equilibrium in the direction of the polymer. In the case of a polyesterification this is easily accomplished by removal of the water that is a by-product of the reaction species II (Eq. 3).

Under these conditions the kinetics of polymerization can be handled by considering the reactions in Eqs. 2 and 3 to be irreversible.

The rate of a step polymerization is conveniently expressed in terms of the concentrations of the reacting functional groups. Thus the polyesterification can be experimentally followed by titrating for the unreacted carboxyl groups with a base. The rate of polymerization R<sub>p</sub> can then be expressed as the rate of disappearance of carboxyl groups -d[COOH]/dt. For the usual polyesterification, the polymerization rate is synonymous with the rate of formation of species II; that is, k<sub>4</sub> is vanishingly small (since the reaction is run under conditions that drive Eqs. 2 and 3 to the right), and k<sub>1</sub>, k<sub>2</sub>, and k<sub>5</sub> are large compared to k<sub>3</sub>. An expression for the reaction rate can be obtained following the general procedures for handling a reaction scheme with the characteristics described [Moore and Pearson, 1981]. The rate of polymerization is given by

$$R = -d[\text{COOH}]/dt = k_3[\text{C}^+(\text{OH})_2][\text{OH}] \quad 4$$

Where [COOH], [OH], and [C<sup>+</sup>(OH)<sub>2</sub>] represent the concentrations of carboxyl, hydroxyl, and protonated carboxyl (I) groups, respectively. The concentration terms are in units of moles of the particular functional group per liter of solution. Equation 4 is inconvenient in that the concentration of protonated carboxylic groups is not easily determined experimentally. One can obtain a more convenient expression for R<sub>p</sub> by substituting for C<sup>+</sup>(OH)<sub>2</sub> from the equilibrium expression

$$K = k_1/k_2 = [\text{C}^+(\text{OH})_2] / [\text{COOH}][\text{HA}] \quad 5$$

for the protonation reaction (Eq. 1). Combination of Eqs. 4 and 5 yields

$$-d[\text{COOH}]/dt = k_3K[\text{COOH}][\text{OH}][\text{HA}] \quad 6$$

Two quite different kinetic situations arise from Eq. 6 depending on the identity of HA, that is, on whether a strong acid such as sulfuric acid or p-toluenesulfonic acid is added as an external catalyst.



## Self-Catalyzed Polymerization

In the absence of an externally added strong acid the diacid monomer acts as its own catalyst for the esterification reaction. For this case [HA] is replaced by [COOH] and Eq. 6 can be written in the usual form [Flory, 1953]

$$-d[\text{COOH}]/dt = k[\text{COOH}]^2 [\text{OH}] \quad 7$$

where K and k<sub>3</sub> have been combined into the experimentally determined rate constant k. Equation 2-18 shows the important characteristic of the self-catalyzed polymerization- the reaction is third-order overall with a second-order dependence on the carboxyl concentration. The second-order dependence on the carboxyl concentration is comprised of two first-order dependencies—one for the carboxyl as the reactant and one as the catalyst.

For most polymerizations the concentrations of the two functional groups are very nearly stoichiometric, and Eq. 7 can be written as

$$-d[\text{M}]/dt = k[\text{M}]^3 \quad 8a$$

Or

$$-d[\text{M}]/[\text{M}]^3 = kdt \quad 8b$$

where [M] is the concentration of hydroxyl groups or carboxyl groups.

Integration of Eq. 8b yields

$$2kt = 1/[\text{M}]^2 - 1/[\text{M}_0]^2 \quad 9$$

where [M<sub>0</sub>] is the initial (at t = 0) concentration of hydroxyl or carboxyl groups. It is convenient at this point to write Eq. 9 in terms of the extent or fraction of reaction p defined as the fraction of the hydroxyl or carboxyl functional groups that has reacted at time t. p is also referred to as the extent or fraction of conversion. (The value of p is calculated from a determination of the amount of unreacted carboxyl groups.) The concentration [M] at time t of either hydroxyl or carboxyl groups is then given by

$$[\text{M}] = [\text{M}_0] - [\text{M}_0]p = [\text{M}_0](1-p) \quad 10$$


Combination of Eqs. 9 and 10 yields

$$1/(1-p)^2 = 2[\text{M}_0]^2kt + 1 \quad 11$$

## Experimental Observations



Equation 11 indicates that a plot of  $1/(1-p)^2$  versus  $t$  should be linear. This behavior has been generally observed in polyesterifications. Figure 2-1 shows the results for the polymerization of diethylene glycol,  $(\text{HOCH}_2\text{CH}_2)_2\text{O}$ , and adipic acid [Flory, 1939; Solomon, 1967 and 1972]. The results are typical of the behavior observed for polyesterifications. Although various authors agree on the experimental data, there has been considerable disagreement on the interpretation of the results. At first glance the plot does not appear to exactly follow the relationship. The experimental points deviate from the third-order plot in the initial region below 80% conversion and in the later stages above 93% conversion. These deviations led various workers [Amass, 1979; Fradet and Marechal, 1982a,b; Solomon, 1967, 1972] to suggest alternate kinetic expressions based on either 1- or  $3/2$ -order dependencies of



the reaction rate on the carboxyl concentration, that is, 2- and  $2(1/2)$ -order dependencies according to

$$-d[\text{COOH}]/dt = k[\text{COOH}][\text{OH}] \quad 12a$$

And

$$-d[\text{COOH}]/dt = k[\text{COOH}]^{3/2}[\text{OH}] \quad 12b$$

However, a critical evaluation shows that both kinetic possibilities leave much to be desired. The experimental rate data fits Eq. 12a well only in the region between 50 and 86% conversion with an excessively poor fit above 86% conversion. On the other hand, a plot according to Eq. 12b fits reasonably well up to about 80% conversion but deviates badly above that point. Neither of the two alternate kinetic plots comes close to being as useful as the third-order plot in Fig. 2-1. The third-order plot fits the experimental data much better than does either of the others at the higher conversions. The fit of the data to the third-order plot is reasonably good over a much greater range of the higher conversion region. The region of high conversion is of prime importance, since, high-molecular-weight polymer is obtained only at high conversions. From the practical viewpoint, the low conversion region of the kinetic plot is of little significance.

## External Catalysis of Polymerization

The slow increase in molecular weight was mistakenly thought originally to be due to the low reactivity of functional groups attached to large molecules. It is, however, simply a consequence of the third-order kinetics of the direct polyesterification reaction. The realization of this kinetic situation led to the achievement of high-molecular-weight products in reasonable reaction times by employing small amounts of externally added strong acids (such as sulfuric acid or p-toluenesulfonic acid) as catalysts. Under these conditions, [HA] in Eq. 2-17 is the concentration of the catalyst. Since this remains constant throughout the course of the polymerization, Eq. 2-17 can be written as,

$$-d[M]/dt = K' [M]^2 \quad 13$$

where the various constant terms in Eq. 11 have been collected into the experimentally determinable rate constant  $K'$ . Equation 13 applies to reactions between stoichiometric concentrations of the diol and diacid. Integration of Eq. 13 yields

$$K' t = 1/[M] - 1/[M_0] \quad 14$$

Combining Eqs. 14 and 10 yields the dependence of the degree of polymerization on reaction time as

$$[M_0]k't = 1/(1 - p) - 1 \quad 15$$

Or


$$\bar{X}_n = 1 + [M_0]k't \quad 15b$$

Data for the polymerization of diethylene glycol with adipic acid catalyzed by p-toluene sulfonic acid are shown in Fig. 2-2. The plot follows Eq. 15 with the degree of polymerization increasing linearly with reaction time. The much greater rate of increase of  $\bar{X}_n$  with reaction time in the catalyzed polyesterification (Fig. 2-2) relative to the uncatalyzed reaction (Fig. 2-1) is a general and most significant phenomenon. The polyesterification becomes a much more economically feasible reaction when it is catalyzed by an external acid. The selfcatalyzed polymerization is not a useful reaction from the practical viewpoint of producing high polymers in reasonable reaction times.

Equations 2-27 and 2-33 and Fig. 2-2 describe the much greater difficulty of performing a successful polymerization compared to the analogous small-molecule reaction (such as the synthesis of ethyl acetate from acetic acid and ethanol).

Consider the case where one needs to produce a polymer with a degree of polymerization of 100, which is achieved only at 99% reaction. Running the polymerization to a lower conversion such as 98%, an excellent conversion for a small-molecule synthesis, results in no polymer of the desired molecular weight. Further, one must almost double the reaction time (from 450 min to 850 min in (Fig. 2-2) to achieve 99% reaction and the desired polymer molecular weight. For the small molecule reaction one would not expend that additional time to

achieve only an additional 1% conversion. For the polymerization one has no choice other than to go to 99% conversion. The nonlinearity in the initial region of Fig. 2-2 is, like that in Fig. 2-1, a characteristic of esterifications in general and not of the polymerization reaction. The general linearity of the plot in the higher conversion region is a strong confirmation of the concept of functional group reactivity independent of molecular size. Figure 2-2 shows that the polyesterification.



continues its second-order behavior at least up to a degree of polymerization of 90 corresponding to a molecular weight of 10,000. There is no change in the reactivities of the hydroxyl and carboxyl groups in spite of the large increase in molecular size (and the accompanying large viscosity increase of the medium). Similar results have been observed in many other polymerizations. Data on the degradation of polymers also show the same effect. Thus in the acid hydrolysis of cellulose there is no effect of molecular size on hydrolytic reactivity up to a degree of polymerization of 1500 (molecular weight 250,000) [Flory, 1953]. The concept of functional group reactivity independent of molecular size has been highly successful in allowing the kinetic analysis of a wide range of polymerizations and reactions of polymers. Its validity, however, may not always be quite rigorous at very low or very high conversions.

### Addition polymerization

**Polymers** are long chain giant organic molecules are assembled from many smaller molecules called **monomers**. **Polymers** consist of many repeating monomer units in long chains. A polymer is analogous to a necklace made from many small beads (monomers). Many monomers are alkenes or other molecules with double bonds which react by **addition** to their unsaturated double bonds.


The electrons in the double bond are used to bond two monomer molecules together. This is represented by the red arrows moving from one molecule to the space between two molecules where a new bond is to form. The formation of polyethylene from ethylene (ethene) may be illustrated in the graphic on the left as follows. In the complete polymer, all of the double bonds

have been turned into single bonds. No atoms have been lost and you can see that the monomers have just been joined in the process of addition. A simple representation is  $-\text{[A-A-A-A-A]}-$ . Polyethylene is used in plastic bags, bottles, toys, and electrical insulation.

- **LDPE - Low Density Polyethylene:** The first commercial polyethylene process used peroxide catalysts at a temperature of 500 C and 1000 atmospheres of pressure. This yields a transparent polymer with highly branched chains which do not pack together well and is low in density. LDPE makes a flexible plastic. Today most LDPE is used for blow-molding of films for packaging and trash bags and flexible snap-on lids. LDPE is recyclable plastic #4.
- **HDPE - High Density Polyethylene:** An alternate method is to use Ziegler-Natta aluminum titanium catalysts to make HDPE which has very little branching, allows the strands to pack closely, and thus is high density. It is three times stronger than LDPE and more opaque. About 45% of the HDPE is blow molded into milk and disposable consumer bottles. HDPE is also used for crinkly plastic bags to pack groceries at grocery stores. HDPE is recyclable plastic #2.

#### Examples

- **PVC (polyvinyl chloride),** which is found in plastic wrap, simulated leather, water pipes, and garden hoses, is formed from vinyl chloride ( $\text{H}_2\text{C}=\text{CHCl}$ ). The reaction is shown in the graphic on the left. Notice how every other carbon must have a chlorine attached.
- **Polypropylene:** The reaction to make polypropylene ( $\text{H}_2\text{C}=\text{CHCH}_3$ ) is illustrated in the middle reaction of the graphic. Notice that the polymer bonds are always through the carbons of the double bond. Carbon #3 already has saturated bonds and cannot participate in any new bonds. A methyl group is on every other carbon.
- **Polystyrene:** The reaction is the same for polystyrene where every other carbon has a benzene ring attached. Polystyrene (PS) is recyclable plastic #6. In the following illustrated example, many styrene monomers are polymerized into a long chain polystyrene molecule. The squiggly lines indicate that the polystyrene molecule extends further at both the left and right ends.



- Blowing fine gas bubbles into liquid polystyrene and letting it solidify produces *expanded polystyrene*, called *Styrofoam* by the Dow Chemical Company.
- **Polystyrene with DVB:** Cross-linking between polymer chains can be introduced into polystyrene by copolymerizing with ***p*-divinylbenzene (DVB)**. DVB has vinyl groups (-


CH=CH<sub>2</sub>) at each end of its molecule, each of which can be polymerized into a polymer chain like any other vinyl group on a styrene monomer.

Polymers from conjugated dienes usually give elastomer polymers having rubber-like properties.

<i>Addition homopolymers from conjugated dienes</i>			
Monomer	Polymer name	Trade name	Uses
H <sub>2</sub> C=CH-C(CH <sub>3</sub> )=CH <sub>2</sub>	polyisoprene	natural or some synthetic rubber	applications similar to natural rubber
H <sub>2</sub> C=CH-CH=CH <sub>2</sub>	polybutadiene	polybutadiene synthetic rubber	select synthetic rubber applications
H <sub>2</sub> C=CH-CCl=CH <sub>2</sub>	polychloroprene	Neoprene	chemically-resistant rubber

#### Ring opening polymerization

In this kind of polymerization, molecular rings are opened in the formation of a polymer. Here epsilon-caprolactam, a 6-carbon cyclic monomer, undergoes ring opening to form a Nylon 6 homopolymer, which is somewhat similar to but not the same as Nylon 6,6 alternating copolymer.



#### Cationic polymerization


**Cationic polymerization** is a type of chain growth polymerization in which a cationic initiator transfers charge to a monomer which then becomes reactive. This reactive monomer goes on to react similarly with other monomers to form a polymer. The types of monomers necessary for cationic polymerization are limited to olefins with electron-donating substituents and heterocycles. Similar to anionic polymerization reactions, cationic polymerization reactions are very sensitive to the type of solvent used. Specifically, the ability of a solvent to form free ions will dictate the reactivity of the propagating cationic chain. Cationic polymerization is used in the production of polyisobutylene (used in inner tubes) and poly(N-vinylcarbazole) (PVK).

#### Monomers


Monomer scope for cationic polymerization is limited to two main types: olefins and heterocyclic monomers. Cationic polymerization of both types of monomers occurs only if the overall reaction is thermally favorable. In the case of olefins, this is due to isomerization of the monomer double bond; for heterocycles, this is due to release of monomer ring strain and, in some cases, isomerization of repeating units. Monomers for cationic polymerization are nucleophilic and form a stable cation upon polymerization.

## Olefins

Cationic polymerization of olefin monomers occurs with olefins that contain electron-donating substituents. These electron-donating groups make the olefin nucleophilic enough to attack electrophilic initiators or growing polymer chains. At the same time, these electron-donating groups attached to the monomer must be able to stabilize the resulting cationic charge for further polymerization. Some reactive olefin monomers are shown below in order of decreasing reactivity, with heteroatom groups being more reactive than alkyl or aryl groups. Note, however, that the reactivity of the carbenium ion formed is the opposite of the monomer reactivity.<sup>[5]</sup>



## Heterocyclic monomers



Heterocyclic monomers that are cationically polymerized are lactones, lactams, and cyclic amines. Upon addition of an initiator, cyclic monomers go on to form linear polymers. The reactivity of heterocyclic monomers depends on their ring strain. Monomers with large ring strain, such as oxirane, are more reactive than 1,3-dioxepane which has considerably less ring strain. Rings that are six-membered and larger are less likely to polymerize due to lower ring strain.

## Synthesis


### Initiation

Initiation is the first step in cationic polymerization. During initiation, a carbenium ion is generated from which the polymer chain is made. The counterion should be non-nucleophilic, otherwise the reaction is terminated instantaneously. There are a variety of initiators available for cationic polymerization, and some of them require a coinitiator to generate the needed cationic species.<sup>[7]</sup>

### Classical protonic acids


Strong protic acids can be used to form a cationic initiating species. High concentrations of the acid are needed in order to produce sufficient quantities of the cationic species.

The counterion ( $A^-$ ) produced must be weakly nucleophilic so as to prevent early termination due to combination with the protonated olefin. Common acids used are phosphoric, sulfuric, fluoro-, and triflic acids. Only low molecular weight polymers are formed with these initiators.




### Lewis acids/Friedel-Crafts catalysts

Lewis acids are the most common compounds used for initiation of cationic polymerization. The more popular Lewis acids are  $SnCl_4$ ,  $AlCl_3$ ,  $BF_3$ , and  $TiCl_4$ . Although these Lewis acids alone are able to induce polymerization, the reaction occurs much faster with a suitable cation source. The cation source can be water, alcohols, or even a carbocation donor such as an ester or an anhydride. In these systems the Lewis acid is referred to as a coinitiator while the cation source is the initiator. Upon reaction of the initiator with the coinitiator, an intermediate complex is formed which then goes on to react with the monomer unit. The counterion produced by the initiator-coinitiator complex is less nucleophilic than that of the Brønsted acid  $A^-$  counterion. Halogens, such as chlorine and bromine, can also initiate cationic polymerization upon addition of the more active Lewis acids.<sup>[1]</sup>



### Carbenium ion salts


Stable carbenium ions are used to initiate chain growth of only the most reactive olefins and are known to give well defined structures. These initiators are most often used in kinetic studies due to the ease of being able to measure the disappearance of the carbenium ion absorbance. Common carbenium ions are trityl and tropylium cations.






### ***Ionizing radiation***

Ionizing radiation can form a radical-cation pair that can then react with a monomer to start cationic polymerization. Control of the radical-cation pairs are difficult and often depend on the monomer and reaction conditions. Formation of radical and anionic species are often observed.



### **Propagation**

Propagation proceeds via addition of monomer to the active species, i.e. the carbenium ion. The monomer is added to the growing chain in a head-to-tail fashion; in the process, the cationic end group is regenerated to allow for the next round of monomer addition.



### ***Effect of temperature***

The temperature of the reaction has an effect on the rate of propagation. The overall activation energy for the polymerization ( $E$ ) is based upon the activation energies for the initiation ( $E_i$ ), propagation ( $E_p$ ), and termination ( $E_t$ ) steps:


$$E = E_i + E_p - E_t$$

Generally,  $E$  is larger than the sum of  $E_i$  and  $E_p$ , meaning the overall activation energy is negative. When this is the case, a decrease in temperature leads to an increase in the rate of propagation. The converse is true when the overall activation energy is positive.


Chain length is also affected by temperature. Low reaction temperatures, in the range of 170–190 K, are preferred for producing longer chains. This comes as a result of the activation energy for termination and other side reactions being larger than the activation energy for propagation. As the temperature is raised, the energy barrier for the termination reaction is overcome, causing shorter chains to be produced during the polymerization process.

### ***Effect of solvent and counterion***

The solvent and the counterion (the gegen ion) have a significant effect on the rate of propagation. The counterion and the carbenium ion can have different associations according to intimate ion pair theory; ranging from a covalent bond, tight ion pair (unseparated), solvent-separated ion pair (partially separated), and free ions (completely dissociated).








The association is strongest as a covalent bond and weakest when the pair exists as free ions.<sup>[6]</sup> In cationic polymerization, the ions tend to be in equilibrium between an ion pair (either tight or solvent-separated) and free ions. The more polar the solvent used in the reaction, the better the solvation and separation of the ions. Since free ions are more reactive than ion pairs, the rate of propagation is faster in more polar solvents.

The size of the counterion is also a factor. A smaller counterion, with a higher charge density, will have stronger electrostatic interactions with the carbenium ion than will a larger counterion which has a lower charge density. Further, a smaller counterion is more easily solvated by a polar solvent than a counterion with low charge density. The result is increased propagation rate with increased solvating capability of the solvent.


### Termination

Termination generally occurs via unimolecular rearrangement with the counterion. In this process, an anionic fragment of the counterion combines with the propagating chain end. This not only inactivates the growing chain, but it also terminates the kinetic chain by reducing the concentration of the initiator-coinitiator complex.



### Chain transfer

Chain transfer can take place in two ways. One method of chain transfer is hydrogen abstraction from the active chain end to the counterion. In this process, the growing chain is terminated, but the initiator-coinitiator complex is regenerated to initiate more chains.



#### Chain transfer by hydrogen abstraction to the counterion


The second method involves hydrogen abstraction from the active chain end to the monomer. This terminates the growing chain and also forms a new active carbenium ion-counterion complex which can continue to propagate, thus keeping the kinetic chain intact.



Chain transfer by hydrogen abstraction to the monomer

### Cationic ring-opening polymerization




Cationic ring-opening polymerization follows the same mechanistic steps of initiation, propagation, and termination. However, in this polymerization reaction, the monomer units are cyclic in comparison to the resulting polymer chains which are linear. The linear polymers produced can have low ceiling temperatures, hence end-capping of the polymer chains is often necessary to prevent depolymerization.



Cationic ring-opening polymerization of oxetane involving (a and b) initiation, (c) propagation, and (d) termination with methanol

### Kinetics

The rate of propagation and the degree of polymerization can be determined from an analysis of the kinetics of the polymerization. The reaction equations for initiation, propagation, termination, and chain transfer can be written in a general form:



In which  $I^+$  is the initiator,  $M$  is the monomer,  $M^+$  is the propagating center, and  $k_i$ ,  $k_p$ ,  $k_t$ , and  $k_{tr}$  are the rate constants for initiation, propagation, termination, and chain transfer, respectively. For simplicity, counterions are not shown in the above reaction equations and only chain transfer to monomer is considered. The resulting rate equations are as follows, where brackets denote concentrations:

$$\text{Rate (initiation)} = k_i [I^+][M]$$

$$\text{Rate (propagation)} = k_p [M^+][M]$$

$$\text{Rate (termination)} = k_t [M^+]$$

$$\text{Rate (chain transfer)} = k_{tr} [M^+][M]$$

Assuming steady-state conditions, i.e. the rate of initiation = rate of termination

$$M^+ = \frac{k_i[I^+][M]}{k_t}$$

This equation for  $[M^+]$  can then be used in the equation for the rate of propagation

$$\text{rate(propagation)} = \frac{k_p k_i [M]^2 [I^+]}{k_t}$$

From this equation, it is seen that propagation rate increases with increasing monomer and initiator concentration.

The degree of polymerization,  $X_n$ , can be determined from the rates of propagation and termination.

$$X_n = \frac{\text{rate (propagation)}}{\text{rate (termination)}} = \frac{k_p [M]}{k_t}$$

If chain transfer rather than termination is dominant, the equation for  $X_n$  becomes

$$X_n = \frac{\text{rate (propagation)}}{\text{rate (chain transfer)}} = \frac{k_p}{k_{tr}}$$


### **Anionic addition polymerization**

**Anionic addition polymerization** is a form of chain-growth polymerization or addition polymerization that involves the polymerization of vinyl monomers with strong electronegative groups. This polymerization is carried out through a carbanion active species. Like all chain-growth polymerizations, it takes place in three steps: chain initiation, chain propagation, and chain termination. Living polymerizations, which lack a formal termination pathway, occur in many anionic addition polymerizations. The advantage of living anionic addition polymerizations is that they allow for the control of structure and composition.


Anionic polymerizations are used in the production of polydiene synthetic rubbers, solution styrene/butadiene rubbers (SBR), and styrenic thermoplastic elastomers.

### **Monomer characteristics**

In order for polymerization to occur with vinyl monomers, the substituents on the double bond must be able to stabilize a negative charge. Stabilization occurs through delocalization of the negative charge. Because of the nature of the carbanion propagating center, substituents that react with bases or nucleophiles either must not be present or be protected.



Vinyl monomers with substituents that stabilize the negative charge through charge delocalization, undergo polymerization without termination or chain transfer.<sup>[4]</sup> These monomers include styrene, dienes, methacrylate, vinyl pyridine, aldehydes, epoxide, episulfide, cyclic siloxane, and lactones. Polar monomers, using controlled conditions and low temperatures, can undergo anionic polymerization. However, at higher temperatures they do not produce living stable, carbanionic chain ends because their polar substituents can undergo side reactions with both initiators and propagating chain centers. The effects of counterion, solvent, temperature, Lewis base additives, and inorganic solvents have been investigated to increase the potential of anionic polymerizations of polar monomers.<sup>[4]</sup> Polar monomers include acrylonitrile, cyanoacrylate, propylene oxide, vinyl ketone, acrolein, vinyl sulfone, vinyl sulfoxide, vinyl silane and isocyanate.



## Solvent

The solvent used in anionic addition polymerizations are determined by the reactivity of both the initiator and carbanion of the propagating chain end. Anionic species with low reactivity, such as heterocyclic monomers, can use a wide range of solvents.


## Initiation

The reactivity of initiators used in anionic polymerization should be similar to that of the monomer that is the propagating species. The pK<sub>a</sub> values for the conjugate acids of the carbanions formed from monomers can be used to deduce the reactivity of the monomer. The least reactive monomers have the largest pK<sub>a</sub> values for their corresponding conjugate acid and thus, require the most reactive initiator. Two main initiation pathways involve electron transfer (through alkali metals) and strong anions.

### Initiation by electron transfer

Szwarc and coworkers studied the initiation of polymerization through the use of aromatic radical-anions such as sodium naphthenate. In this reaction, an electron is transferred from the alkali metal to naphthalene. Polar solvents are necessary for this type of initiation both for


stability of the anion-radical and to solvate the cation species formed. The anion-radical can then transfer an electron to the monomer.



Initiation can also involve the transfer of an electron from the alkali metal to the monomer to form an anion-radical. Initiation occurs on the surface of the metal, with the reversible transfer of an electron to the adsorbed monomer.

### Initiation by strong anions


Nucleophilic initiators include covalent or ionic metal amides, alkoxides, hydroxides, cyanides, phosphines, amines and organometallic compounds (alkyllithium compounds and Grignard reagents). The initiation process involves the addition of a neutral (B:) or negative (B:-) nucleophile to the monomer.



The most commercially useful of these initiators has been the alkyllithium initiators. They are primarily used for the polymerization of styrenes and dienes.

Monomers activated by strong electronegative groups may be initiated even by weak anionic or neutral nucleophiles (i.e. amines, phosphines). Most prominent example is the curing of cyanoacrylate, which constitutes the basis for superglue. Here, only traces of basic impurities are sufficient to induce an anionic addition polymerization or zwitterionic addition polymerization, respectively.

### Propagation



Propagation in anionic addition polymerization results in the complete consumption of monomer. It is very fast and occurs at low temperatures. This is due to the anion not being very stable, the speed of the reaction as well as that heat is released during the reaction. The stability can be greatly enhanced by reducing the temperatures to near 0°C. The propagation rates are generally fairly high compared to the decay reaction, so the overall polymerization rates is generally not affected.


## Termination

Anionic addition polymerizations have no formal termination pathways because proton transfer from solvent or other positive species does not occur. However, termination can occur through unintentional quenching due to trace impurities. This includes trace amounts of oxygen, carbon dioxide or water. Intentional termination can occur through the addition of water or alcohol. Another method of termination, chain transfer, can occur when an agent can act as a Brønsted acid. In this case, the pK<sub>a</sub> value of the agent is similar to the conjugate acid of the propagating carbanionic chain end. Spontaneous termination occurs because the concentration of carbanion centers decay over time and eventually results in hydride elimination. Polar monomers are more reactive because they are stabilized by their polar substituents. These polar substituents can react with nucleophiles which results in termination as well as side reactions that compete with both initiation and propagation.

## Kinetics

The kinetics of anionic addition polymerization depend on whether or not a termination pathway occurs.

In general, the reaction mechanism for living anionic addition polymerization are as follows:



where I = initiator,  $k_{\text{init}}$  = the initiation reaction rate constant, M = monomer,  $\text{M}^-$  = propagating species, and  $k_{\text{prop}}$  = the propagation reaction rate constant.

As most polymerizations of this type do not have a termination pathway, the rate of polymerization is the rate of propagation:

$$\text{Rate (prop)} = k_p [\text{M}^-][\text{M}]$$

where  $k_p$  is the rate of constant of propagation,  $[\text{M}^-]$  is the total concentration of propagating centers, and  $[\text{M}]$  is the concentration of monomer. Since there is no termination pathway in living polymerizations, the concentration of propagating centers is equal to the concentration of initiator ( $[\text{I}]$ ). Thus,

$$\text{rate (prop)} = k_p [\text{I}][\text{M}]$$

The degree of polymerization,  $X_n$  is also affected by no termination pathway. It is the ratio of concentration of reacted monomer ( $[\text{M}]_0$ ) to initiator( $[\text{I}]_0$ ) times the percent conversion  $p$ . In this case, the chain length ( $\nu$ ) is equal to  $X_n$ .

$$v = \frac{[M]_0}{[I]_0} p$$

When conversion,  $p = 1$  (100% conversion), chain length is simply the ratio of reacted monomer to initiator.

$$v = \frac{[M]_0}{[I]_0}$$

### **Kinetics: termination due to impurities**

When termination occurs due to impurities, the impurities must be taken into account in determining the reaction rate. The reaction mechanisms would begin the same as that of a living anionic addition (initiation and propagation). However, there would now be a termination step to account for the effect of the impurities on the reaction.



where  $M^-$  = propagating species,  $HX$  = impurity and  $k_{term}$  = the termination reaction rate constant.

Using the steady-state approximation, the rate of propagation becomes

$$rate(prop) = \frac{k_{init}k_{prop}[I][M]^2}{k_{term}[H - X]}$$

Since


$$V = \frac{rate(prop)}{rate(term)} = \frac{k_{prop}[M]}{k_{term}[H - X]}$$

Thus chain length and rate of propagation are negatively impacted by the presence of impurities in the reaction.

### **Free-Radical polymerization**

Initiation The initiation reaction produces free radicals. There are several ways to do this: •

Chemical initiation The decomposition of the initiator (e.g. AIBN) forms free radicals:



where  $f$  is the initiator efficiency, typically  $f = [0.5, 1]$ . Note that in order to ensure a continuous production of radicals all over the process,  $1/k_d$  should be larger than the characteristic time of the polymerization reaction. Examples of the decomposition characteristic time,  $\tau_d$  for some commercial initiators are:

Acetyl peroxide 2 h 80 °C  
 Cumyl peroxide 12 h 110 °C  
*t*-Butyl hydroperoxide 45 h 150 °C  
 Since this is a first order process,  $\tau_d = 1/k_d$ .

- Thermal initiation: thermal decomposition of the monomer (e.g. styrene).

This represents a danger, for example during monomer transportation, since it may lead to undesired polymerization of the monomer. For this reason, inhibitors (scavengers of radicals) are usually added to the monomers before storage. This causes the occurrence of a non reproducible induction period when such monomers are polymerized.


- Initiation by radiation

The decomposition of the initiator is caused by light or another source of radiation. Since this method is quite expensive, it is only applied to polymerization systems operating at very low temperatures.

## Propagation

Propagation is the addition of a monomer molecule to a radical chain.






### Chain Transfer

- Chain transfer to monomer



The reactants are the same as for the propagation reaction, but the activation energy is much larger. Accordingly,  $k_{fm}$  is usually at least 10<sup>3</sup> times smaller than  $k_p$ . This reaction




leads to the formation of a polymer chain with a terminal double bond. This can induce chain branching through the terminal double bond propagation reaction.

- Chain transfer to chain transfer agent



A chain transfer agent, S is a molecule containing a weak bond that can be broken to lead to radical transfer, similarly as in the case of monomer above (e.g. CCl<sub>4</sub>, CBr<sub>4</sub>, mercaptans).

- Chain transfer to polymer



In this reaction the growing radical chain,  $R\cdot n$  extracts a hydrogen from the dead chain,  $Pm$ . Since this extraction can occur on any of the  $m$  monomer units along the chain, the rate of this reaction is proportional to the length of  $Pm$ .

General observations on the role of chain transfer reactions:

- The concentration of radicals is not affected and therefore the rate of monomer consumption is also unchanged.
- The growth of polymer chains is stopped and therefore shorter chains are produced.
- Each transfer event leaves a different end-group on the chain that can be detected (NMR, titration) so as to identify and quantify the corresponding chain transfer reaction.
- Nonlinear (branched) polymer chains are produced: directly by chain transfer to polymer or indirectly through the propagation of the terminal double bond left by a chain transfer to monomer event.

**Text book:**

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.

**Reference book**

**R1:** M.S Bhatnagar, 2004, " A text book of polymers". I<sup>st</sup> Edition, S.Chand & Company.

	Questions	Opt-1	Opt-2	Opt-3	Opt-4	Answers
1	Which is obtained from the reaction of diamines with diacids?	Polyamides	polyester	Acrylicfibre	poly vinyl chloride	Polyamides
2	In step polymerization the reactivity of a functional group depends on?	The collision frequency of the group	b. diffusion rate of the whole molecule	Nature of the functional group	Size of the group	The collision frequency of the group
3	The alkyl resins are condensation polymers obtained from dibasic acids and	phenol	formaldehyde	Acetaldehyde	Glycol	Phenol
4	Reactivity of a functional group depends on ?	Collision frequency	diffusion rate	Size	Molecular weight	Collision frequency
5	In a polymer chain the functional group has appreciable mobility due to	the conformational rearrangements	different stereochemical forms	Tautomeric arrangements	Optical activity	The conformational rearrangements
6	The first step in the reaction of the diol and diacid monomer is to form ?	dimer	trimer	Pentamer	Tetramer	Dimer
7	The rate of a step polymerization is conveniently expressed in terms of the	Concentrations of the reacting functional groups.	concentration of the monomeric	Concentration of monomer and the solvent	Concentration of the functional groups and monomers	Concentration of the functional groups and monomers
8	A dimer reacts with a monomer to give	Trimer	Dimer	Pentamer	Tetramer	Trimer

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE CODE: 17CHU305A

COURSE NAME: POLYMER CHEMISTRY

UNIT: I (Coordination Chemistry)

BATCH-2017-2019

9	In thermal catalyzed polymerizations the most widely used mode of generating radicals to initiate polymerization ?	Homolytic dissociation of initiators	Heterolytic dissociation of initiators	Decomposition of the initiator	Association of the initiator	Homolytic dissociation of initiators
10	The Polyesterification of a diol and a diacid will illustrate the general kinetics of a typical ?	Step polymerization	Ionic polymerization	Radical polymerization	Self catalyzed polymerization	Step polymerization
11	The carboxyl concentration is comprised of two first-order dependencies, one for the carboxyl as the reactant and another one as?	Product	Reactant	Reagent	Catalyst	Catalyst
12	The polyesterification becomes a much more economically feasible reaction when it is catalyzed by an ?	Base	Acid	Alkali	Neutral	Acid
13	Example for radical sources for the polymerization reactions?	Peroxides	Epoxides	Nitrenes	Carbenes	Peroxides
14	A titanium atom at the surface is bonded by?	Five chlorines	Six chlorines	Three chlorines	Two chlorines	Five chlorines
15	In free radical vinyl polymerization	The electrons in the pi bond split up	The electrons in the sigma bond split up	Non bonding electrons are used	Electrons from the functional group splits.	The electrons in the pi bond split up
16	The general linearity of the plot in the higher conversion region is a strong confirmation of the concept of functional group reactivity independent of?	Frequency	Molecular Weight	Density	Molecular size	Molecular size

17	In the acid hydrolysis of cellulose there is no effect of ?	Frequency	Molecular weight	Density	Molecular size	Molecular size
18	Isotactic polymerization depends intimately on the ?	Crystal structure of the initiator surface	Surface area of the initiator	Volume of the initiator	Concentration of the initiator	Crystal structure of the initiator surface
19	In isotactic polymerization the polymerization occurs at active sites found on the ?	Edges (surfaces) of elementary sheets of the crystal	Edges of the basal planes	Corners of the basal planes	Inside the pores of the catalyst	Edges (surfaces) of elementary sheets of the crystal
20	Which find extensive use as radical sources?	Peroxides	Epoxides	Nitrenes	Carbenes	Peroxides
21	The enantiomorphic site control model attributes stereo control in ?	Isospecific polymerization	Isotactic polymerization	Free radical polymerization	Ionic polymerization	Isospecific polymerization
22	The C–N bond dissociation energy is?	~ 190 kJ mol <sup>-1</sup>	~ 390 kJ mol <sup>-1</sup>	~ 290 kJ mol <sup>-1</sup>	~ 360 kJ mol <sup>-1</sup>	~ 290 kJ mol <sup>-1</sup>
23	The various initiators are used at different temperatures depending on their rates of	Reaction	Decomposition	Composition	Entropy	Decomposition
24	The azobisisobutyronitrile (AIBN) is commonly used at?	60-70 °C	50–70 °C	80-90 °C	40-50 °C	50–70 °C
25	Teflon is a polymer of the monomer or Teflon is obtained by the polymerisation of ?	Monofluoroethene	Difluoroethene	Trifluoroethene	Tetrafluoroethene	Tetrafluoroethene

26	Which of the following is an example of condensation polymer?	PVC	Polyamide	Terylene	Polyester	Terylene
27	two trimers react together to form	Trimer	Hexamer	Monomer	Heptamer	Hexamer
28	Ionic vinyl polymerizations are very similar to	Free radical vinyl polymerizations	Step polymerizations	Self catalyzed vinyl polymerization	Free radical polymerizations	Free radical vinyl polymerizations
29	A tetramer reacts with a trimer to form	Trimer	Dimer	Pentamer	Heptamer	Heptamer
30	A pentamer reacts with a trimer to form	Trimer	Dimer	Pentamer	Octamer	Octamer
31	Monomer concentration decreases steadily throughout reaction in?	Step polymerization	Ionic polymerization	Radical polymerization	Self catalyzed polymerization	Ionic polymerization
32	Polymer molecular weight rises steadily throughout reaction in ?	Step polymerization	Ionic polymerization	Radical polymerization	Self catalyzed polymerization	Step polymerization
33	In which step of cationic polymerization follows the first order kinetics	Initiation	propagation	termination	transformation	termination
34	A simple termination or chain transfer depending to	chain growth	degree of polymerization	kinetics	polymer deformation	degree of polymerization

35	The temperature would decrease the	molecular weight of polymer	chain formation	initiator	monomer	molecular weight of polymer
36	In the radical polymerization, the propagation rate depends on	monomer	concentration of monomer radical	concentration of catalyst	reaction rate	concentration of monomer radical
37	In Cationic vinyl polymerization electron flow is ?	Same direction	Same and opposite direction	Opposite direction	Same or opposite direction	Opposite direction
38	Ionic polymerization necessarily carry along a?	Counter ion	Cation	Anion	Cation or anion	Counter ion
39	The fraction of the radicals produced in the homolysis reaction that initiate polymer chains is defined as?	Initiator efficiency	High efficiency	Low efficiency	Closer efficiency	Initiator efficiency
40	A dimer react with another dimer to form a	Trimer	Dimer	Pentamer	Tetramer	Tetramer
41	In most polymerizations, the second step is?	Much faster than the first step	Much slower than the first step	Less faster than the first step	Slower than the first step	Much faster than the first step
42	Which is impossible under any and all reaction conditions if it does not pass the test of thermodynamic feasibility?	Cationic vinyl polymerization	Ionic polymerization	Polymerization	Wastage reactions	Polymerization
43	which of the following is an example of bifunctional monomer	methyl isocyanate	acetylene	malic acid	glycine	glycine

44	Which of the following is the functionality of Gallic acid	monofunctional	bifunctional	tetra functional	tri functional	tetra functional
45	Monomers show high selectivity towards?	Cationic initiators	Cationic and anionic initiators	Ionic initiators	Anionic initiators	Ionic initiators
46	Most monomers will undergo polymerization with a radical initiator, although at?	Varying rates	Reliable rates	Stable rates	Positive rates	Varying rates
47	Polymerization is possible only if the free-energy difference -G between monomer and polymer is?	Positive	Negative	Both negative and positive	Neither negative nor positive	Negative
48	The property of fabric which influences drape the most is?	Tensile	Compressional	Shear	Surface	Shear
49	The Q-e scheme is best considered as an empirical approach to placing monomer reactivity on a?	Qualitative basis	Quantitative basis	Qualitative radical	Quantitative radical	Quantitative basis
50	To remove the residual metals, a process referred as ?	Ashing	Reashing	Ashing and reashing	Deashing	Deashing
51	3,4-Difluorophenylamine is a weaker base than ?	Phenylamine	Phenylacetate	Phenol	Henepthyl alcohol	Phenylamine
52	What method would you use to synthesize a triblock copolymer?	Free radical polymerization	Anionic polymerization	Using a Ziegler Natta catalyst	Condensation polymerization	Free radical polymerization



53	Suspension free radical polymerization of styrene would be preferred over bulk polymerization to overcome the problem of ?	Branching	Cross-linking	Stereo-isomerism	Polymeric impurities	Branching
54	Polymers are ?	Large molecule	Small molecule	Small chain molecule	Large chain molecule	Large chain molecule
55	Polymers are high molecular weight in the range of ?	$10^4$ to $10^7$	$10^3$ to $10^7$	$10^2$ to $10^7$	$10^5$ to $10^7$	$10^3$ to $10^7$
56	Tetramer + monomer is ?	Trimer	Dimer	Pentamer	Tetramer	Pentamer
57	Which one is not a polymer?	Carbohydrates	Proteins	Carboxylic acid	Nucleic acid	Carboxylic acid
58	Due to the presence of carbon atom in polymers all large biological molecules are made of ?	Ionic bond	Covalent bond	Triple bond	Metalic bond	Covalent bond
59	Amino acids are building blocks of ?	Carbohydrates	Proteins	Carboxylic acid	Lipids	Proteins
60	polyethylene is ?	Colourless liquid	Colourless gas	Gas	Liquid	Colourless gas

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY COURSE NAME: POLYMER CHEMISTRY

COURSE CODE:17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH: 2017-2019

## UNIT – II

### Co-ordination Polymerization

**Co-ordination Polymerization:** Kinetics, mono and bimetallic mechanism of co-ordination polymers. Zeigler Natta catalyst, co-polymerization: Block and graft co-polymers, kinetics of copolymerization. Types of co-polymerization. Reactivity ratio.

#### Coordination polymerization

**Coordination polymerisation** is a form of addition polymerization in which monomer adds to a growing macromolecule through an organometallic active center. The development of this polymerization technique started in the 1950s with heterogeneous Ziegler-Natta catalysts based on titanium tetrachloride and an aluminium co-catalyst such as methylaluminoxane. Coordination polymerization has a great impact on the physical properties of vinyl polymers such as polyethylene and polypropylene compared to the same polymers prepared by other techniques such as free-radical polymerization. The polymers tend to be linear and not branched and have much higher molar mass. Coordination type polymers are also stereoregular and can be isotactic or syndiotactic instead of just atactic. This tacticity introduces crystallinity in otherwise amorphous polymers. From these differences in polymerization type the distinction originates between low-density polyethylene (LDPE), high-density polyethylene (HDPE) or even ultra-high-molecular-weight polyethylene (UHMWPE).

Polymerizations catalysed by metallocenes occur via the Cossee-Arlman mechanism. The active site is usually anionic but cationic coordination polymerization also exists.

In many applications Ziegler-Natta polymerization is succeeded by metallocene catalysis polymerization. This method is based on homogeneous metallocene catalysts such as the Kaminsky catalyst discovered in the 1970s. The 1990s brought forward a new range of post-metallocene catalysts.

Typical monomers are nonpolar ethylene and propylene. The development of coordination polymerization that enables copolymerization with polar monomers is more recent. Examples of monomers that can be incorporated are methyl vinyl ketones methyl acrylate and acrylonitrile.

#### Kinetics

A case of heterogeneous polymerization.

It is defined : H is the surface of the transition-metal compound,

AR is the metal alkyl,


M is the monomer,

M<sub>x</sub> is the polymer.


Adsorption of metal alkyl from solution to form the active site




Adsorption of M from solution



Initiation




Propagation




Termination

(transfer)



Termination

(monomer forms an inactive site)



It is assumed that the process occurs in Langmuir isotherm condition and it is defined that :

$\theta_A$  and  $\theta_M$  are the fractions of the available surface covered by AR and M respectively,

$[C^*]$  is the concentration of growing chains,

Then the overall rate can be determined.

$$\theta_A = \frac{K_1 [AR]}{1 + K_1 [AR] + K_2 [M]} \quad \theta_M = \frac{K_2 [M]}{1 + K_1 [AR] + K_2 [M]}$$

The overall rate :

$$R_o = - \frac{d[M]}{dt} = (k_p + k_{tr}) \theta_M [C^*]$$

Assume that  $[C^*]$  reaches steady state so that the initiation rate is similar to the termination rate.

$$k_i \theta_A \theta_M = k_t [C^*] \theta_M$$

The overall rate :

$$R_o = - \frac{d[M]}{dt} = \frac{(k_p + k_{tr}) k_i}{k_t} \frac{K_1 K_2 [AR] [M]}{(1 + K_1 [AR] + K_2 [M])^2}$$

### Ziegler-Natta catalysis and polymerization

#### **Historical Development of Ziegler-Natta Initiators**

Various mechanisms have been proposed to explain the stereoselectivity of Ziegler-Natta initiators [Boor, 1979; Carrick, 1973; Corradini et al., 1989; Cossee, 1967; Ketley, 1967a,b; Tait and Watkins, 1989; Zambelli and Tosi, 1974]. Most mechanisms contain considerable details that distinguish them from each other but usually cannot be verified. In this

section the mechanistic features of Ziegler–Natta polymerizations are considered with emphasis on those features that hold for most initiator systems.

The major interest will be on the titanium–aluminum systems for isoselective polymerization, more specifically,  $\text{TiCl}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$  and  $\text{TiCl}_4$  with  $\text{Al}(\text{C}_2\text{H}_5)_3$ —probably the most widely studied systems, and certainly the most important systems for industrial polymerizations. Before proceeding with the mechanistic consideration it is useful to review the evolution of the Ti–Al initiator system for industrial applications. The original initiator used by Ziegler for ethylene polymerization was obtained in situ as a precipitate on mixing the components  $\text{TiCl}_4$  and  $\text{Al}(\text{C}_2\text{H}_5)_3$  in a hydrocarbon solvent. The mixture was used directly for initiating polymerization. Natta, recognizing that the major product of the reaction was  $\text{b-TiCl}_3$  (brown in color), explored various methods of preforming it outside the polymerization system, for example, by reduction of  $\text{TiCl}_4$  with hydrogen, aluminum, and various alkylaluminum compounds. The stereoselectivity of these early initiator systems was low with isotactic indices of only 20–40% for polypropene. The isotactic index, a measure of the isotactic content of a polymer, is the percentage of the sample insoluble in a hydrocarbon solvent such as boiling n-heptane. This is not as informative a technique as high-resolution NMR since insoluble molecules may contain some syndiotactic and atactic sequences and soluble molecules may contain some isotactic sequences. It does, however, give a simple measure of isotacticity that is usually within about 10% of the value obtained from NMR, especially for highly isotactic samples.

There was a dramatic increase in stereoselectivity when the  $\alpha$ -,  $\beta$ -, or  $\gamma$ -crystalline form of  $\text{TiCl}_3$  (all violet in color) was used directly. The early generations of industrial processes used  $\text{TiCl}_3$  together with  $\text{Al}(\text{C}_2\text{H}_5)_3$  and/or  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$ . Over a two decade period starting in the late 1950s, the isotactic indices for polypropene increased to the low 90 percentile range. The initiator activity was enhanced by various ball milling and heat treatments of the initiator components before and after mixing. Ball milling involves mechanical grinding and not only increases surface area but also facilitates reactions between the initiator components.

However, the activities were too low to allow the polymer products to be used without purification (by treatment with base or acid) to remove the residual metals, a process referred to as deashing. Also, optimization of the physical properties of the product often required removal of the atactic fraction. The initiator systems were inefficient with less than 1% of the Ti being active in polymerization. The later generations of initiators, starting in the late 1970s, increased initiator efficiency and activity without sacrificing stereoselectivity [Bohm, 2001; Busico and Cipullo, 2001; Cecchin et al., 2001; Chadwick, 2001; Chadwick et al., 2001; Chien et al., 1982; Hu and Chien, 1988]. The effective surface area of the active component of the initiator system was increased by close to 2 orders of magnitude by using  $\text{MgCl}_2$  as a solid support in which  $\text{TiCl}_4$  is finely dispersed. Stereoselectivity was kept high and actually increased by the addition of electron-donor additives.

A typical recipe for a present-day superactive or high-mileage initiator system involve ball milling of  $\text{MgCl}_2$  (or the alkoxide) and  $\text{TiCl}_4$  followed by the addition of  $\text{Al}(\text{C}_2\text{H}_5)_3$  with an electron donor (such as dialkyl phthalate and alkoxy silane) usually added in each step of preparation. Activity is 50–200 kg polymer per gram of initiator system. Typically, the initiator system is no more than 2–4% Ti, which makes the activity about 1500–6000 kg polymer per

gram of Ti. The high activity not only minimizes initiator and production costs but also avoids the costly task of initiator removal from the polymer product (except possibly for food- and medical-grade products). Isotactic indices for polypropene have been increased to 98% or higher with (mmmm) pentad fractions up to 98% and higher. This not only improves the product's physical properties but also avoids the need to remove the a tactic fraction.

### Chemical Nature of Propagating Species

Some early polymerizations reported as Ziegler–Natta polymerizations were conventional free-radical, cationic, or anionic polymerizations proceeding with low stereoselectivity. Some Ziegler–Natta initiators contain components that are capable of initiating conventional ionic polymerizations of certain monomers, such as anionic polymerization of methacrylates by alkyllithium and cationic polymerization of vinyl ethers by  $\text{TiCl}_4$ . Most Ziegler–Natta components participate in a complex set of reactions involving alkylation and reduction of the transition-metal component by the group I–III component as shown below for  $\text{TiCl}_4 + \text{AlR}_3$ :




Radicals produced in Eq. 8-31 are capable of initiating radical polymerizations with some monomers, for example, vinyl chloride. The mechanism for the stereoselective polymerization of  $\alpha$ -olefins and other nonpolar alkenes is a  $\pi$ -complexation of monomer and transition metal (utilizing the latter's d-orbitals) followed by a four-center anionic coordination insertion process in which monomer is inserted into a metal–carbon bond as described in Fig. 8-10. Support for the initial  $\pi$ -complexation has come from ESR, NMR, and IR studies [Burfield, 1984]. The insertion reaction has both cationic and anionic features. There is a concerted nucleophilic attack by the incipient carbanion polymer chain end on the  $\alpha$ -carbon of the double bond together with an electrophilic attack by the cationic counterion on the alkene  $\pi$ -electrons. The anionic character of the polymerization is consistent with the polymerization rate decreasing in the order ethylene > propene > 1-butene [Bier, 1961; Boor, 1967].

The reverse order is expected for a polymerization involving the conversion of a monomer into the corresponding carbocation. For addition of a carbanion to the monomers, attack occurs at the  $\alpha$ -carbon to form the less substituted (and more stable) carbanion. Further,  $\alpha$ -substituents sterically hinder the approach of a carbanion and/or counterion with the result that reactivity decreases with increasing substituent size. Evidence for the anionic nature of propagation also comes from studies in which labeled methanol is used to terminate chain growth. The terminated polymer is radioactive when  $\text{CH}_3\text{O}^{14}\text{H}$  is used, while termination by  $^{14}\text{CH}_3\text{OH}$  yields a nonradioactive polymer.

### **Mechanism of Isoselective Propagation**


A variety of structures have been proposed for the active species in Ziegler–Natta initiator systems [Allegra, 1971; Arlman and Cossee, 1964; Corradini et al., 1989; Natta, 1960a,b; Patat and Sinn, 1958; Rodriguez and van Looy, 1966; Tait and Watkins, 1989]. Structure XX is generally considered as the active species formed from titanium chloride and alkylaluminum components..



The Cl in the structure represents an unoccupied (vacant) site of the octahedral titanium complex. XX represents an active titanium site at the surface of a  $\text{TiCl}_3$  crystal after modification by reaction with the alkylaluminum component. The titanium atom shares four chloride ligands with its neighboring titanium atoms and has an alkyl ligand (incorporated via exchange of alkyl from the alkylaluminum for chloride) and a vacant orbital.

There are molecular mechanics calculations that indicate dimeric  $\text{Ti}_2\text{Cl}_6$  may be the active species instead of monomeric  $\text{TiCl}_3$  [Monaco et al., 2000]. Other proposals for the active species include bimetallic species that contain both titanium and aluminum [Liu et al., 2002]. To simplify matters, our discussions will center on the monomeric and monometallic titanium species, especially since the mechanistic details of stereoselectivity and activity are essentially the same for both monomeric and dimeric titanium species as well as titanium–aluminum species. The high-mileage supported initiators previously mentioned involve a species similar to XX as part of a mixed titanium–magnesium–chloride lattice, usually involving Mg–Cl–Ti bonds. Ti and Mg are interchangeable within the metal lattice.

Figure 8-11 shows the proposed mechanism for isoselective propagation. Monomer coordinates at the vacant site of titanium, resulting in a four-center transition state and subsequent insertion of monomer into the polymer–transition metal bond. The insertion is referred to as migratory insertion since the polymer chain migrates from its original site to that occupied by monomer. The whole polymer chain does not migrate, only the active end of the polymer chain migrates. This follows the principle of least nuclear motions. For the polymer chain to remain at its original coordination site after monomer insertion, all or at least most of the polymer chain atoms must move, specifically back away from the coordination site. For Cossee-Arlman mechanism, .




*Fig. Mechanism for catalyst site control model of isoselective polymerization.* migratory insertion only the atoms of the first few repeat units move. This regenerates a vacant site with its configuration opposite from the original vacancy.

If propagation continued with this species, the result might be syndiospecific propagation. Isoselective propagation requires migration of the polymer chain to its original position with regeneration of the original configuration of the vacant site, often referred to as back skip or back-flip. The chain migrates twice for insertion of each monomer unit, and the overall process can also be regarded as a site epimerization. This mechanism, referred to as the Cossee-Arlman mechanism, is based on the observed stereoselectivity and molecular modeling studies [Arlman and Cossee, 1964; Ewen, 1999; Rappe et al., 2000; Resconi et al., 2000]. A variation on this mechanism involves a lowering of the transition state barrier to insertion by an  $\alpha$ -agostic interaction, specifically, an attractive interaction between titanium and a hydrogen on the first carbon attached to Ti.



Isotactic polymerization depends intimately on the crystal structure of the initiator surface. For a coordination lattice, as opposed to a molecular crystal lattice, the crystal contains a number of ligand vacancies in order to achieve overall electrical neutrality of the crystal.  $\alpha$ - $\text{TiCl}_3$  crystals are made up of elementary crystal sheets of alternating titanium and chlorine layers aligned along the principal crystal axis [Natta et al., 1961a,b,c,d]. Figure 8-12 is a representation of a portion of the crystal [Corradini et al., 1989]. The titanium and chlorine atoms are represented by solid black and open spheres, respectively. The titaniums are at the octahedral interstices of the chlorine lattice while chlorines are hexagonally close-packed. Every third titanium in the lattice is missing, that is, there is a vacancy in between pairs of titanium atoms. Vacancies are represented by & in Fig. 8-12.

Polymerization occurs at active sites found on the edges (surfaces) of elementary sheets of the crystal and not in the basal planes. This is supported by microscopic observations of polymer growth at the crystal edges [Cossee, 1967; Kollar et al., 1968a,b; Rodriguez and van Looy, 1966]. A titanium atom at the surface is bonded to only five chlorines instead of six because of the imposed requirement of electroneutrality. Of the five chlorines, four are more strongly bonded since they are bridged to other titanium atoms. The fifth, nonbridged chlorine may be replaced by an alkyl group when the titanium component interacts with the group I–III component. The octahedral vacancy remains as a vacancy. Neighboring metal atoms (bridged by two chlorines) have opposite chirality [Allegra, 1971]. The two enantiomeric titaniums can be represented as XXI and XXII where one of the chlorine ligands has been



replaced by R via alkylation by the group I–III metal component. Propagation occurs by coordination of monomer at the vacancy, migratory insertion into the  $\text{Ti}-\text{R}$  bond, and migration of the newly formed bond to regenerate the vacancy in the original configuration. Considering either XXI or XXII, coordination of monomer can occur through either of the two monomer enantiofaces (si or re), which results in two diastereomeric transition states. The two diastereomeric states give rise to the two possible placements of monomer units in the polymer chain—meso and racemo [Corradini et al., 1984, 1985; Zambelli et al., 1978, 1980].

The driving force for isoselective propagation results from steric and electrostatic interactions between the substituent of the incoming monomer and the ligands of the transition metal. The chirality of the active site dictates that monomer coordinate to the transition metal vacancy primarily through one of the two enantiofaces. Active sites XXI and XXII each yield isotactic polymer molecules through nearly exclusive coordination with the re and si monomer enantioface, respectively, or vice versa. That is, we may not know which enantioface will coordinate with XXI and which enantioface with XXII, but it is clear that only one of the enantiofaces will coordinate with XXI while the opposite enantioface will coordinate with XXII.




This is the catalyst (initiator) site control or enantiomorphic site control model for isoselective polymerization.


The enantiomorphic site control model attributes stereocontrol in isoselective polymerization to the initiator active site with no influence of the structure of the propagating chain end. The mechanism is supported by several observations:

1.  $^{13}\text{C}$  NMR of isotactic polypropene shows the main error is pairs of racemic dyads instead of isolated racemic dyads (Table 8-3) [Heatley et al., 1969; Resconi et al., 2000; Wolfsgruber et al., 1975]. A stereoerror in the addition of a monomer molecule is immediately corrected when stereocontrol is by the chiral active site. If stereocontrol was due to the propagating chain end, an error would continue to propagate in an isotactic manner to yield a polymer, referred to as an isotactic stereoblock, containing long isotactic all-R and all-S stereoblocks on each side of the error.
2.  $^{13}\text{C}$  NMR of ethylene-propene copolymers of low ethylene content produced by initiators that yield isotactic polypropene shows that the isotactic propene units on each side of an ethylene unit have the same configuration (i.e., all-R or all-S) [Zambelli et al., 1971, 1978, 1979]. For stereocontrol by the propagating chain end, the amount of polymer in which the polypropene blocks on either side of an ethylene unit have the same configuration would equal that in which the blocks have the opposite configuration.
3. Statistical analysis of the stereochemical sequence distributions (Table 8-3 and Sec. 8-16) also supports the enantiomorphic site control model.

### Isotactic Polymerization Mechanism




Surface titanium wants to fill its orbitals. But first,  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$  enters the picture. It donates one of its ethyl groups to the impoverished titanium, but kicks out one of the chlorines in the process. We still have an empty orbital. But more about that in a moment.




As you can see in this picture, the aluminum has a hard time letting go. It stays coordinated, though not covalently bonded, to the  $\text{CH}_2$  carbon atom of the ethyl group it just donated to the titanium. Not only that, but it also coordinates itself to one of the chlorine atoms adjacent to the titanium. But titanium still has one empty orbital left to be filled.

So then a vinyl monomer like propylene comes along. There are two electrons in the  $\pi$ -system of a carbon-carbon double bond. Those electrons can be used to fill the empty orbital of the titanium. We say that the propylene and the titanium form a *complex*, and we draw it like this:



### Natta- Bimetallic Polymerization mechanism



### Copolymerization

Copolymerization of ethylene and  $\alpha$ -olefins have been demonstrated soon after the discovery that Ziegler-Natta catalysts homopolymerize  $\alpha$ -olefins. Copolymers have gained much interest in polymer field due to their elastomeric characteristics. Therefore, many research works were carried out to prepare better catalyst systems and to obtain more interesting elastomeric copolymers. The properties of the copolymers formed can be controlled by operating conditions, chemical composition and physical state of catalyst and comonomers structure. The most

important copolymer is prepared from ethylene and propylene. The production of ethylene-propylene copolymers were traditionally carried out with homogenous Ziegler-Natta catalyst based on vanadium compounds. The application of the Ziegler-Natta heterogenous catalytic system based on titanium compounds for the production of copolymers has recently become more important, due to high activity of the catalyst systems and low production costs. The best coordinated anionic type catalyst suitable for the production of ethylene-propylene copolymers are obtained by reaction of alkylaluminium compounds with transition metals such as vanadium, chromium, niobium and titanium. Recently, Soga and coworkers<sup>53</sup> successfully copolymerized ethylene and propylene using a soluble chromium catalytic system composed of  $\text{Cr}(\text{C}_{17}\text{H}_{35}\text{COO})_3$  and  $\text{AlEt}_2\text{Cl}$ . The catalytic system produced random copolymer with a narrow molecular weight distribution.

### **Kinetics of Copolymerization**

Although radical copolymerization has been more extensively studied and is more important than ionic copolymerization, we will consider the general case without specification as to whether the mode of initiation is by a radical, anionic, or cationic species. Copolymerization of the two monomers leads to two types of propagating species—one with  $\text{M}_1$  at the propagating end and the other with  $\text{M}_2$ . These can be represented by  $\text{M}_1^*$  and  $\text{M}_2^*$  where the asterisk represents either a radical, a carbocation, or a carbanion as the propagating species depending on the particular case. If it is assumed that the reactivity of the propagating species is dependent only on the monomer unit at the end of the chain (referred to as the end or ultimate unit), four propagation reactions are then possible. Monomers  $\text{M}_1$  and  $\text{M}_2$  can each add either to a propagating chain ending in  $\text{M}_1$  or to one ending in  $\text{M}_2$ , that is,



where  $k_{11}$  is the rate constant for a propagating chain ending in  $\text{M}_1$  adding to monomer  $\text{M}_1$ ,  $k_{12}$  that for a propagating chain ending in  $\text{M}_1$  adding to monomer  $\text{M}_2$ , and so on. The propagation of a reactive center by addition of the same monomer (i.e., Reaction 1-4) is often referred to as homopropagation or self-propagation; propagation of a reactive center by addition of the other monomer (Reactions 2 and 3) is referred to as cross propagation or a crossover reaction. All propagation reactions are assumed to be irreversible.

Monomer  $\text{M}_1$  disappears by Reactions 1 and 3, while monomer  $\text{M}_2$  disappears by Reactions 2 and 4. The rates of disappearance of the two monomers, which are synonymous with their rates of entry into the copolymer, are given by

$$-d[\text{M}_1]/dt = k_{11}[\text{M}_1^*][\text{M}_1] + k_{21}[\text{M}_2^*][\text{M}_1] \quad 5$$

$$-d[M_2]/dt = k_{12}[M_1^*][M_2] + k_{22}[M_2^*][M_2] \quad 6$$

Dividing Eq. 6-6 by Eq. 6-7 yields the ratio of the rates at which the two monomers enter the copolymer, that is, the copolymer composition, as

$$d[M_1]/d[M_2] = (k_{11}[M_1^*][M_1] + k_{21}[M_2^*][M_1]) / (k_{12}[M_1^*][M_2] + k_{22}[M_2^*][M_2]) \quad 7$$

In order to remove the concentration terms in  $M_1^*$  and  $M_2^*$  from Eq. 7, a steady-state concentration is assumed for each of the reactive species  $M_1^*$  and  $M_2^*$  separately. For the concentrations of  $M_1^*$  and  $M_2^*$  to remain constant, their rates of interconversion must be equal. In other words, the rates of Reactions 2 and 3 must be equal:

$$k_{21}[M_2^*][M_1^*] = k_{12}[M_1^*][M_2] \quad 8$$

Equation 8 can be rearranged and combined with Eq. 7 to yield

$$d[M_1] / d[M_2] = ((k_{11}k_{21}[M_2^*][M_1]^2 / k_{12}[M_2]) + k_{21}[M_2^*][M_1]) / (k_{22}[M_2^*][M_2] + k_{21}[M_2^*][M_1]) \quad 9$$

Dividing the top and bottom of the right side of Eq. 6-10 by  $k_{21}[M_2^*][M_1]$  and combining the result with the parameters  $r_1$  and  $r_2$ , which are defined by

$$r_1 = k_{11}/k_{12} \quad \text{and} \quad r_2 = k_{22}/k_{21} \quad 10$$

one finally obtains

$$d[M_1] / d[M_2] = [M_1] (r_1[M_1] + [M_2]) / [M_2] ([M_1] + r_2 [M_2]) \quad 11$$

Equation 11 is known as the copolymerization equation or the copolymer composition equation. The copolymer composition,  $d[M_1] = d[M_2]$ , is the molar ratio of the two monomer units in the copolymer.  $d[M_1] = d[M_2]$  is expressed by Eq. 6-12 as being related to the concentrations of the two monomers in the feed,  $[M_1]$  and  $[M_2]$ , and the parameters  $r_1$  and  $r_2$ . The parameters  $r_1$  and  $r_2$  are termed the monomer reactivity ratios. Each  $r$  as defined above in Eq. 6-11 is the ratio of the rate constant for a reactive propagating species adding its own type of monomer to the rate constant for its addition of the other monomer. The tendency of two monomers to copolymerize is noted by  $r$  values between zero and unity. An  $r_1$  value greater than unity means that  $M_1^*$  preferentially adds  $M_1$  instead of  $M_2$ , while an  $r_1$  value less than unity means that  $M_1^*$  preferentially adds  $M_2$ . An  $r_1$  value of zero would mean that  $M_1$  is incapable of undergoing homopolymerization.

The copolymerization equation can also be expressed in terms of mole fractions instead of concentrations. If  $f_1$  and  $f_2$  are the mole fractions of monomers  $M_1$  and  $M_2$  in the feed, and  $F_1$  and  $F_2$  are the mole fractions of  $M_1$  and  $M_2$  in the copolymer, then

$$f_1 = 1 - f_2 = [M_1] / ([M_1] + [M_2]) \quad 12$$

and

$$F_1 = 1 - F_2 = d[M_1] / (d[M_1] + d[M_2]) \quad 13$$

Combining Eqs. 12 and 13 with above Eq. yields

$$F_1 = (r_1 f_1^2 + f_1 f_2) / (r_1 f_1^2 + 2f_1 f_2 + r_2 f_2^2)$$

or

$$f_1 / f_2 = f_1(r_1 f_1 + f_2) / f_2 (r_2 f_2 + f_1)$$

14

The equation 14 gives the copolymer composition as the mole fraction of monomer  $M_1$  in the copolymer and is often more convenient to use than the previous form of the copolymerization equation.

### Types of copolymers



### Different types of copolymers

Since a copolymer consists of at least two types of constituent units (also structural units), copolymers can be classified based on how these units are arranged along the chain.<sup>[3]</sup> These include:


- **Alternating copolymers** with regular alternating A and B units (structure 2 in diagram)
- **Periodic copolymers** with A and B units arranged in a repeating sequence (e.g.  $(A-B-A-B-B-A-A-A-A-B-B-B)_n$ )
- **Statistical copolymers** are copolymers in which the sequence of monomer residues follows a statistical rule. If the probability of finding a given type monomer residue at a particular point in the chain is equal to the mole fraction of that monomer residue in the chain, then the polymer may be referred to as a truly **random copolymer**<sup>[4]</sup> (structure 3).
- **Block copolymers** comprise two or more homopolymer subunits linked by covalent bonds (structure 4). The union of the homopolymer subunits may require an intermediate non-repeating subunit, known as a **junction block**. Block copolymers with two or three distinct blocks are called **diblock copolymers** and **triblock copolymers**, respectively.

Copolymers may also be described in terms of the existence of or arrangement of **branches** in the polymer structure. **Linear copolymers** consist of a single main chain whereas **branched copolymers** consist of a single main chain with one or more polymeric side chains.

Other special types of branched copolymers include **star copolymers**, **brush copolymers**, and **comb copolymers**. In gradient copolymers the monomer composition changes gradually along the chain.

A **terpolymer** is a copolymer consisting of three distinct monomers. The term is derived from *ter* (Latin), meaning thrice, and polymer.

- **Stereoblock copolymers**



A special structure can be formed from one monomer where now the distinguishing feature is the tacticity of each block.

### **Statistical copolymers**

Statistical copolymers are dictated by the reaction kinetics of the two chemically distinct monomer reactants, and are commonly referred to interchangeably as “random” in the polymer literature. As with other types of copolymers, random copolymers can have interesting and commercially desirable properties that blend those of the individual homopolymers. Examples of commercially relevant random copolymers include rubbers made from styrene-butadiene copolymers and resins from styrene-acrylic or methacrylic acid derivatives.<sup>[6]</sup> Copolymerization is particularly useful in tuning the glass transition temperature, which is important in the operating conditions of polymers; it is assumed that each monomer occupies the same amount of free volume whether it is in a copolymer or homopolymer, so the glass transition temperature falls between the T<sub>g</sub> of each homopolymer and is dictated by the mole or mass fraction of each component.

A number of parameters are relevant in the composition of the polymer product; namely, one must consider the reactivity ratio of each component. Reactivity ratios describe whether the monomer reacts preferentially with a segment of the same type or of the other type. For example, a reactivity ratio that is less than one for component 1 indicates that this component reacts with the other type of monomer more readily. Given this information, which is available for a multitude of monomer combinations in the “Wiley Database of Polymer Properties”, the Mayo-Lewis equation can be used to predict the composition of the polymer product for all initial mole fractions of monomer. This equation is derived using the Markov model, which only considers the last segment added as affecting the kinetics of the next addition; the Penultimate Model considers the second-to-last segment as well, but is more complicated than is required for most systems. When both reactivity ratios are less than one, there is an azeotropic point in the Mayo-Lewis plot. At this point, the mole fraction of monomer equals the composition of the component in the polymer.

There are several ways to synthesize random copolymers. The most common synthesis method is free radical polymerization; this is especially useful when the desired properties rely on the composition of the copolymer rather than the molecular weight, since free radical polymerization produces relatively disperse polymer chains. Free radical polymerization is less expensive than other methods, and produces high-molecular weight polymer quickly. Several methods offer better control over dispersity. Anionic polymerization can be used to create random copolymers, but with several caveats: if carbanions of the two components do not have the same stability, only one of the species will add to the other. Additionally, anionic polymerization is expensive and requires very clean reaction conditions, and is therefore difficult to implement on a large scale.<sup>[5]</sup> Monodisperse random copolymers are also synthesized by living controlled radical polymerization methods, such as atom-transfer radical-polymerization (ATRP), nitroxide mediated radical polymerization (NMP), or Reversible addition-fragmentation chain-transfer polymerization (RAFT). These methods are favored over anionic polymerization because they can be performed in conditions similar to free radical polymerization. The reactions require

longer experimentation periods than free radical polymerization, but still achieve reasonable reaction rates.

### **Graft copolymers**

**Graft copolymers** are a special type of branched copolymer in which the side chains are structurally distinct from the main chain. The illustration (structure 5) depicts a special case where the main chain and side chains are composed of distinct homopolymers. However, the individual chains of a graft copolymer may be homopolymers or copolymers. Note that different copolymer sequencing is sufficient to define a structural difference, thus an A-B diblock copolymer with A-B alternating copolymer side chains is properly called a graft copolymer.

For example, suppose we perform a free-radical polymerization of styrene in the presence of polybutadiene, a synthetic rubber, which retains one reactive C=C double bond per residue. We get polystyrene chains growing out in either direction from some of the places where there were double bonds, with a one-carbon rearrangement. Or to look at it the other way around, the result is a polystyrene backbone with polybutadiene chains growing out of it in both directions. This is an interesting copolymer variant in that one of the ingredients was a polymer to begin with.

As with block copolymers, the quasi-composite product has properties of both "components". In the example cited, the rubbery chains absorb energy when the substance is hit, so it is much less brittle than ordinary polystyrene. The product is called high-impact polystyrene, or HIPS.

### **Block copolymers**

One kind of copolymer is called a "block copolymer". Recently the terminology "block polymer" has been used. Block copolymers are made up of blocks of different polymerized monomers and is usually made by first polymerizing styrene, and then subsequently polymerizing methyl methacrylate (MMA) from the reactive end of the polystyrene chains. This polymer is a "diblock copolymer" because it contains two different chemical blocks. Triblocks, tetrablocks, multiblocks, etc. can also be made. Diblock copolymers are made using living polymerization techniques, such as atom transfer free radical polymerization (ATRP), reversible addition fragmentation chain transfer (RAFT), ring-opening metathesis polymerization (ROMP), and living cationic or living anionic polymerizations.<sup>[11]</sup> An emerging technique is chain shuttling polymerization.

The "**blockiness**" of a copolymer is a measure of the adjacency of comonomers vs their statistical distribution. Many or even most synthetic polymers are in fact copolymers, containing about 1-20% of a minority monomer. In such cases, blockiness is undesirable.

### **Copolymer Composition**

#### **Terminal Model; Monomer Reactivity Ratios**

The instantaneous copolymer composition—the composition of the copolymer formed at very low conversions (about <5%)—is usually different from the composition of the comonomer feed from which the copolymer is produced, because different monomers have differing tendencies to undergo copolymerization. It was observed early that the relative copolymerization tendencies of monomers often bore little resemblance to their relative rates of homopolymerization [Staudinger and Schneiders, 1939]. Some monomers are more reactive in



copolymerization than indicated by their rates of homopolymerization; other monomers are less reactive. Further, and most dramatically, a few monomers, such as maleic anhydride and stilbene undergo facile copolymerization with radical initiation, although they have very little or no tendency to undergo homopolymerization.

The composition of a copolymer thus cannot be determined simply from a knowledge of the homopolymerization rates of the two monomers. The determinants of copolymerization composition have been elucidated by several workers by assuming the chemical reactivity of the propagating chain (which may be a free radical, carbocation, or carbanion) in a copolymerization is dependent only on the identity of the monomer unit at the growing end and independent of the chain composition preceding the last monomer unit [Alfrey and Goldfinger, 1944; Mayo and Lewis, 1944; Wall, 1944; Walling, 1957]. This is referred to as the firstorder Markov or terminal model of copolymerization. Consider the case for the copolymerization of the two monomers  $M_1$  and  $M_2$ .

### Q-e Scheme

Various attempts have been made to place the radical-monomer reaction on a quantitative basis in terms of correlating structure with reactivity. Success in this area would give a better understanding of copolymerization behavior and allow the prediction of the monomer reactivity ratios for comonomer pairs that have not yet been copolymerized. A useful correlation is the Q-e scheme of Alfrey and Price [1947], who proposed that the rate constant for a radical-monomer reaction, for example, for the reaction of  $M_1\cdot$  radical with  $M_2$  monomer, be written as

$$K_{12} = P_1 Q_2 \exp(-e_1 e_2) \quad 15$$

where  $P_1$  represents the intrinsic reactivity of  $M_1\cdot$  radical,  $Q_2$  represents the intrinsic reactivity of  $M_2$  monomer,  $e_1$  represents the polarity of  $M_1\cdot$  radical, and  $e_2$  represents the polarity of  $M_2$  monomer. By assuming that the same  $e$  value applies to both a monomer and its corresponding radical (i.e.,  $e_1$  defines the polarities of  $M_1$  and  $M_1\cdot$ , while  $e_2$  defines the polarities of  $M_2$  and  $M_2\cdot$ ), one can write expressions for  $k_{11}$ ,  $k_{22}$ ,  $k_{21}$  analogous to Eq. 15. These can be appropriately combined to yield the monomer reactivity ratios in the forms

$$r_1 = Q_1 / Q_2 \exp[-e_1(e_1 - e_2)] \quad 16$$

$$r_2 = Q_2 / Q_1 \exp[-e_2(e_2 - e_1)] \quad 17$$

which correlate monomer-radical reactivity with the parameters  $Q_1$ ,  $Q_2$ ,  $e_1$ , and  $e_2$ . The basis of the Q-e scheme (Eqs. 15 to 17) is the theoretically unsatisfactory suggestion that the alternating tendency is due to ground-state electrostatic interactions between permanent charges in the monomer and radical [Price, 1948].

Although there have been attempts to place it on a solid theoretical basis [Colthup, 1982; O'Driscoll and Yonezawa, 1966], the Q-e scheme is best considered as an empirical approach to placing monomer reactivity on a quantitative basis. Monomer reactivity is separated into the parameter  $Q$ , which describes the resonance factor (and to a slight extent the steric factor) present in the monomer, and the parameter  $e$ , which describes the polar factor.

Consider now the use of the Q-e scheme to predict monomer reactivity ratios. Values of  $Q$  and  $e$  have been assigned to monomers on the basis of their  $r$  values and the arbitrarily chosen reference values of  $Q = 1$  and  $e = -0.80$  for styrene [Greenley, 1989b, 1999]. Table 6-7 shows the



average Q and e values for some common monomers. The practical success of the Q–e scheme in predicting the  $r_1$  and  $r_2$  values for comonomer pairs not previously copolymerized has been limited in its quantitative aspects. The reason for this is that the Q and e values for a monomer are not unique values for both experimental and theoretical reasons. The precision of the calculated Q and e values is often poor as a result of inaccuracies in the experimentally determined r values. Further, the Q and e values for a monomer vary considerably depending on the monomer with which it is copolymerized as a result of inherent deficiencies of the Q–e scheme. It does not explicitly take into account steric factors that may affect monomer reactivity ratios for certain radical–monomer combinations. The assumption of the same e value for a monomer and its corresponding radical is also inadequate. Attempts to refine the Q–e scheme by using separate e values for monomer and radical have not been successful.

In spite of these deficiencies the Q–e scheme is a reasonable qualitative and even semi quantitative approach to the effect of structure on monomer reactivity. It can be used to give a general idea of the behavior to be expected from a comonomer pair that has not been studied. The Q–e values can be used to more quantitatively discuss reactivity data such as those in Table 6-4 and 6-6. The monomers are lined up in Table 6-6 in order of their e values. This order defines the polarities of the various monomers. The relative importance of resonance and polar factors in determining monomer reactivity can be discussed by considering the data in Table 6-4 in terms of the Q and e values of the monomers.

The various reference radicals can be divided into two groups: one composed of the relatively unreactive radicals and the other composed of reactive radicals. For the reactive radicals, such as vinyl chloride and vinyl acetate, monomer reactivity depends on Q with  $k_{12}$  increasing with increasing Q and polar effects are too subtle to discern. The unreactive radicals from styrene and, 3-butadiene show the same trends except that one can discern the polar effects. There is enhanced reactivity of these radicals (possessing negative e values) toward a monomer such as acrylonitrile with relatively high positive e values. The resonance factor is, however, more important than the polar factor; the former determines the magnitude of monomer reactivity. Thus monomer reactivities toward the 1,3-butadiene and styrene radicals fall into two groups—one group of monomers with high Q values and high reactivities and another group with low Q values and low reactivities.

A number of useful generalizations are possible regarding which pairs of monomers will copolymerize and the behavior to be expected. Copolymerization proceeds poorly with monomers whose Q values are very different, since copolymer formation would require the energetically unfavorable conversion of a resonance-stabilized radical to a less stabilized radical and vice versa. Thus vinyl chloride and vinyl acetate do not copolymerize well with styrene or 1,3-butadiene. Copolymerization is more suitable between monomers of similar Q values, preferably high Q values, for example, styrene and 1,3-butadiene. Ideal copolymerization occurs between two monomers having similar Q and e values, for example, styrene–1,3-butadiene, vinyl chloride–vinyl acetate, and acrylonitrile–methyl acrylate. The tendency toward alternation is greatest for monomers having the same Q values with high e values of opposite sign.

TABLE: Q and e Values for Monomers; a Data from Greenley [1989b, 1999].

Monomer	Q	e
Ethyl vinyl ether	0.018	-1.80

Propene	0.009	-1.69
N-Vinylpyrrolidone	0.088	-1.62
n-Butyl vinyl ether	0.038	-1.50
p-Methoxystyrene	1.53	-1.40
Isobutylene	0.023	-1.20
Vinyl acetate	0.026	-0.88
-Methylstyrene	0.97	-0.81
Styrene	1.00	-0.80
Isoprene	1.99	-0.55
1,3-Butadiene	1.70	-0.50
Ethylene	0.016	0.05
Vinyl chloride	0.056	0.16
Vinylidene chloride	0.31	0.34
Methyl methacrylate	0.78	0.40
Acrylamide	0.23	0.54
Methacrylic acid	0.98	0.62
Methyl acrylate	0.45	0.64
Methacrylonitrile	0.86	0.68
Vinyl fluoride	0.008	0.72
4-Vinylpyridine	2.47	0.84
Acrylic acid	0.83	0.88
Methyl vinyl ketone	0.66	1.05
Diethyl maleate	0.053	1.08
Acrylonitrile	0.48	1.23
Tetrafluoroethylene	0.032	1.63
Diethyl fumarate	0.25	2.26
Fumaronitrile	0.29	2.73
Maleic anhydride	0.86	3.69

**Text book:**

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.

**Reference book**

**R1:** M.S Bhatnagar, 2004, " A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

**POSSIBLE QUESTIONS**

**Multiple choice questions (Each Carry 1 Marks)**

1. The polyethene polymer formed by the addition polymerisation process using the Ziegler-Natta catalyst is a?  
a. **High density and high melting point**      b. Low density and high melting point  
c. High density and low melting point      d. Low density and low melting point
2. The catalyst used for the Ziegler–Natta polymerizations?  
a. **TiCl<sub>3</sub> with Al(C<sub>2</sub>H<sub>5</sub>)<sub>2</sub>Cl**      b. BCl<sub>3</sub> with Al(C<sub>2</sub>H<sub>5</sub>)<sub>2</sub>Cl      c. TiCl<sub>3</sub> with Fe(C<sub>2</sub>H<sub>5</sub>)<sub>2</sub>Cl  
d. TiF<sub>3</sub> with Al(C<sub>2</sub>H<sub>5</sub>)<sub>2</sub>F
3. Melting Point of Low Density Polyethylene (LDPE) is?  
a. **~115° C**      b. ~116 °C      c. ~117°C      d. ~118°C
4. Which polymer is not an copolymer?  
a. CCDDCCDDCCD      b. **AAAAAAAAAAAA**      c. BBBBBAAAAAAAAA  
d. CCCDDCCDDCCC
5. The metal in the co-catalyst is come from  
a. I to III      b. III to IV      c. IV and V      d. **IV-VIII**
6. R-Ti-Cl<sub>4</sub> is an  
a. bi-metallic catalyst      b. **mono metallic catalyst**      c. tri metallic catalyst  
d. alkyl catalyst
7. Monometallic mechanism proposed by  
a. Natta      b. **Cossee**      c. Robert      d. Wilson
8. The Ti metal have a ---- number of co-ordination  
a. **5**      b. 4      c. 7      d. 6
9. Ti halide is acting as a  
a. adsorbate      b. co-catalyst      c. secondary catalyst      d. **Surface catalyst**
10. In the ziegler-natta catalyst the aluminium halide ----- on Ti halide  
a. **chemisorbed**      b. physisorbed      c. bonded      d. absorbed
11. The insertition of monomer in the alternative spatial arrangement form the  
a. isotactic polymer      b. **syndiotactic polymer**      c. copolymer      d. radical polymer
12. Which of the following is not depend on the formation of vaccant sites  
a. coming monomeric unit      b. chlorine atom of catalyst      c. substituent of monomer unit  
d. **Transition metal atom**
13. Which is the step to form the activesite catalyst in co-ordination polymerization  
a. **initiation**      b. propagation      c. termination      d. transformation
14. In the monometallic mechanism monmer attacks the  
a. Ti-Cl bond      b. Al-R bond      c. **Ti-R bond**      d. Al-Cl bond
15. Who fractionated the vinyl chloride-vinyl acetate co-polymer  
a. Cossee      b. Natta      c. **Staudinger**      d. Ziegler
16. Two or more monomers are combined to form  
a. Co-ordination polymer      b. **Co-polymer**      c. Crystalline polymer      d. Homo polymer
17. The polymer production in the co-polymerisation depends on the  
a. anyone monomer unit      b. **reactivity ratio**      c. reaction path      d. two monomers
18. The reactivity ratio is represented as  
a. r<sub>1</sub>      b. r<sub>2</sub>      c. **r<sub>1</sub>/r<sub>2</sub>**      d. m<sub>1</sub>/m<sub>2</sub>
19. [m<sub>1</sub>] and [m<sub>2</sub>] represents the  
a. **mole fraction**      b. molar concentration      c. molecular mass      d. number of moles

20. The plot between  $r_1$  (assumed values) Vs  $r_2$  (calculated values) is drawn in the method of  
**a. Mayo-Lewis method**    b. Fineman-Rose method    c. Lewis method    d. molecular method

**Questions (Each carry 6 Marks)**

1. Derive the kinetic equation of co-ordination polymerization?
2. Explain the kinetics of co-polymerisation?
3. What is Co-polymer and explain its types?
4. Explain the most useful co-ordination catalyst?
5. Explain the types of co-polymerisation?
6. What is Ziegler-Natta catalyst explain it briefly?
7. Give an account about reactivity ratio?
8. Derive the kinetic equation of co-polymerization?
9. What is reactivity ratio and explain its concepts?
10. How to determine the reactivity ratio of the polymers?

**Compulsory Questions (Each carry 10 Marks)**

1. Explain the mono and bi metallic mechanism of co-ordination catalyst?
2. Explain the influence of reactivity ratio in the co-polymerization?

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

	Questions	Opt-1	Opt-2	Opt-3	Opt-4	Answers
1	The alternating copolymer contains ?	2 monomer units	3 monomer units	4 monomer units	1 monomer units	2 monomer units
2	The copolymer is not an?	Alloy	Trimer	Monomer	Initiator	Alloy
3	The polyethene polymer formed by the addition polymerisation process using the Ziegler- Natta catalyst is a?	High density and high melting point	Low density and high melting point	High density and low melting point	Low density and low melting point	High density and high melting point
4	The catalyst used for the Ziegler–Natta polymerizations?	TiCl <sub>3</sub> with Al(C <sub>2</sub> H <sub>5</sub> ) <sub>2</sub> Cl	BCl <sub>3</sub> with Al(C <sub>2</sub> H <sub>5</sub> ) <sub>2</sub> Cl	TiCl <sub>3</sub> with Fe(C <sub>2</sub> H <sub>5</sub> ) <sub>2</sub> Cl	TiF <sub>3</sub> with Al(C <sub>2</sub> H <sub>5</sub> ) <sub>2</sub> F	TiCl <sub>3</sub> with Al(C <sub>2</sub> H <sub>5</sub> ) <sub>2</sub> Cl
5	Melting Point of Low Density Polyethylene (LDPE) is?	~115o C	~116 oC	~117oC	~118 oC	~115o C
6	Which polymer is not an copolymer?	CCDDCCDDDC CD	AAAAAAAAAA	BBBBBBBAAAAAAAA	CCDDCCDDCCC	AAAAAAAAAA
7	Which, speeds up the oxidation process in polymerization?	Heat	Catalyst	Initiator	Reactants	Heat

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

8	Highly unsaturated polymers are much more sensitive to ?	Reduction	Addition	Oxidation	Redox	oxidation
9	Stability of a polymer depends on?	Physical structure	Chemical properties	Physical properties	Chemical structure	Chemical structure
10	Most polymers are?	Thermally stable	Physically stable	Chemically stable	Unstable	Thermally stable
11	Carbon Black and other colorants may also protect plastics from the effects of?	Temperature	Melting point	Pressure	Light	Light
12	Ultraviolet absorber is?	2-hydroxyphenyl benzotriazoles	Hydroxybenzophenones	Hindered amines	Benzophenones	Hydroxybenzophenones
13	Any of a group of substances that are used in plastics to impart viscosity, flexibility, softness to the finished product is defined as?	Light stabilizers	Colouarants	Plasticizers	Flame retardents	Plasticizers
14	Which of the following is used to form a stereo regular polymer	co-polymer	Acid catalyst	Ziegler-natta catalyst	alkyl catalyst	Ziegler-natta catalyst
15	higher alpha olefins form the	isotactic polymer	syndiotactic polymer	stereo polymer	copolymer	isotactic polymer

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

16	Polymerization reaction done by the presence of organo-metallic compounds is	co-ordinaion polymerisation	co-polymerization	addition polymerisation	chain polymerization	co-ordinaion polymerisation
17	In the zieglar-natta catalyst, the alkyl metals from group	I to III	III to IV	IV and V	IV-VIII	I to III
18	The metal in the co-catalyst is come from	I to III	III to IV	IV and V	IV-VIII	IV-VIII
19	R-Ti-Cl <sub>4</sub> is an	bi-metallic catalyst	mono metallic catalyst	tri metallic catalyst	alkyl catalyst	mono metallic catalyst
20	Monometallic mechanism proposed by	natta	cossee	Robert	Wilson	cossee
21	The Ti metal have a ---- number of co-ordination	5	4	7	6	5
22	Ti halide is acting as a	adsorbate	co-catalyst	secondary catalyst	Surfae catalyst	Surfae catalyst
23	In the zieglar-natta catalyst the aluminium halide ----- on Ti halide	chemisorbed	physisorbed	bonded	absorption	chemisorbed
24	In the Zieglar-natta catalyst, the Ti halide have a	vacant d-orbital	vacant p-orbital	filled d-orbitals	filled p-orbitals	vacant d-orbital

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

25	Which of the following is the active site of the ziegler-natta catalyst	metal in I-III group	metal in I group	metal in IV-VIII group	only in II group metal	metal in IV-VIII group
26	In the bi metallic mechanism forms the	bi-complex	intermediate compound	intermediate ion	Catalyst	bi-complex
27	Which of the following metal is not present in the ziegler-natta catalyst	Ti	Mo	V	Li	Li
28	The metal present in the ziegler-natta catalyst is	non-metal	semi metal	transition metal	radio-active metal	transition metal
29	Which of the following is used for the stereo-regular polymer	ziegler-natta catalyst	Acid catalyst	basic catalyst	intermediate	ziegler-natta catalyst
30	The insertion of monomer in the same spatial arrangement form the	isotactic polymer	syndiotactic polymer	copolymer	radical polymer	isotactic polymer
31	The insertion of monomer in the alternative spatial arrangement form the	isotactic polymer	syndiotactic polymer	copolymer	radical polymer	syndiotactic polymer
32	which of the following is not depend on the formation of vacant sites	coming monomeric unit	chlorine atom of catalyst	substituent of monomer unit	Transition metal atom	Transition metal atom
33	In the syndiotactic polymer, the substituent monomer units are insert in the	alternative sites	same position	opposite position	regular position	alternative sites



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

34	In the isotactic polymer, the monomer insertion in the - -- spatial arrangements	Same direction	opposite direction	alternative direction	either same or alternative	Same direction
35	Which is the step to form the activesite catalyst	initiation	propagation	termination	transformation	propagation
36	In the monometallic mechanism monomer attacks the	Ti-Cl bond	Al-R bond	Ti-R bond	Al-Cl bond	Ti-R bond
37	Who fractionated the vinyl chloride-vinyl acetate co-polymer	Cossee	natta	Staudinger	Ziegler	Staudinger
38	Two or more monomers are combined to form	co-ordination polymer	co-polymer	crystalline polymer	homo polymer	co-polymer
39	The polymer production in the co-polymerisation depends on the	anyone monomer unit	reactivity ratio	reaction path	two monomers	reactivity ratio
40	The reactivity ration is represented as	$r_1$	$r_2$	$r_1/r_2$	$m_1/m_2$	$r_1/r_2$
41	The $r_1 > 1$ means the preference of the add	M1 monomer	M2 monomer	either M1 or M2	neither M1 nor M2	M1 monomer
42	The $r_2 > 1$ prefer the addition of	M1 monomer	M2 monomer	either M1 or M2	neither M1 nor M2	M2 monomer

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

43	The two monomers in the co-polymerisation have same preference of addition to produce	ideal co-polymer	alternative co-polymer	block polymer	non-ideal polymer	ideal co-polymer
44	In the ideal co-polymer, the reactivity ratio is equal to	1	0	not equal to 0	not equal to unity	1
45	In the alternating co-polymer, the reactivity ratio is equal to	0	1	not equal to 0	above 1	0
46	In which of the following condition form the block co-polymer	$r_1/r_2 = 1$	$r_1/r_2 = 0$	$r_1, r_2 < 1$	$r_1, r_2 > 1$	$r_1, r_2 > 1$
47	The over all rate of co-polymerization depends on the	initiation step only	propagation step only	termination step only	both initiation and termination	both initiation and termination
48	Most of the graft polymers are formed by	chain polymerization	co-ordination polymerization	radical polymerization	Ionic polymerization	radical polymerization
49	$[m_1]$ and $[m_2]$ represents the	mole fraction	molar concentration	molecular mass	number of moles	mole fraction
50	the plot between $r_1$ (assumed values) Vs $r_2$ (calculated values) is drawn in the method of	Mayo-Lewis method	Finemann-Rose method	Lewis method	molecular method	Mayo-Lewis method
51	equation belongs to the	Mayo-Lewis method	Finemann-Rose method	Lewis method	molecular method	Finemann-Rose method

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019

52	the slope of graph in the fineman-ross method give the value of	M	P	$r_1$	$r_2$	$r_1$
53	In the fineman-Ross method, the ordinate intercept give the	$r_1$ value	negative $r_1$ value	negative $r_2$ value	positive $r_1$ value	negative $r_2$ value
54	Which of the following condition make the M1 radical prefers to add M2 monomer and the M2 radical prefer to add M1 monomer	$r_1/r_2 = 0$	$r_1, r_2 < 1$	$r_1, r_2 > 1$	$r_1 = r_2 = 0$	$r_1 = r_2 = 0$
55	Which of the following condition make the both M1 and M2 radical have same preference for M1 and M2 monomers	$r_1 = r_2 = 1$	$r_1, r_2 < 1$	$r_1, r_2 > 1$	$r_1 = r_2 = 0$	$r_1 = r_2 = 1$
56	The composition of two monomers are constant means it forms	azeotropic co-polymerisation	an azeotropic co-polymerisation	alternating co-polymerization	block co-polymer	azeotropic co-polymerisation
57	Which of the following conditions form the M1 richer co-polymer	$r_1, r_2 < 1$	$r_1, r_2 > 1$	$r_1 = r_2 = 0$	$r_1 > 1, r_2 < 1$	$r_1 > 1, r_2 < 1$
58	The condition $r_1 < 1$ and $r_2 > 1$ condition preferse the	M1 radical prefer to M1 monomer	M2 radical prefer to the M2 monomer	M1 radical prefer to M2 monomer and M2 radical prefer the M1 monomer	M1 radical prefer to M1 and monomer and M2 radical prefer the M1 and M2 monomer	M1 radical prefer to M2 monomer and M2 radical prefer the M1 monomer

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: II (CO-ORDINATION POLYMERIZATION) BATCH-2017-2019


59	The $r_1$ is less than $r_2$ , the azeotropic composition should be	increases	decreases	constant	first increases then decreases	decreases
60	The $r_1 < 1$ and $r_2 > 1$ condition to form the polymer richer in	M1 monomer	M2 monomer	M1 radical	M2 radical	M2 monomer

### UNIT-III

### **SYLLABUS**

Polydispersion – average molecular weight concept, number, weight and viscosity average molecular weights. Measurement of molecular weights. Viscosity, light scattering, osmotic and ultracentrifugation methods. Polymer structure and physical properties – crystalline melting point  $T_m$ . The glass transition temperature. Determination of  $T_g$ . Relationship between  $T_m$  and  $T_g$ .

#### Polydispersion



A uniform (monodisperse) collection



A non-uniform (polydisperse) collection

In physical and organic chemistry, the **dispersity** is a measure of the heterogeneity of sizes of molecules or particles in a mixture. A collection of objects is called **uniform** if the objects have the same size, shape, or mass. A sample of objects that have an inconsistent size, shape and mass distribution is called **non-uniform**. The objects can be in any form of chemical dispersion, such as particles in a colloid, droplets in a cloud, crystals in a rock, or polymer macromolecules in a solution or a solid polymer mass. Polymers can be described by molecular mass distribution; a population of particles can be described by size, surface area, and/or mass distribution; and thin films can be described by film thickness distribution.

IUPAC has deprecated the use of the term **polydispersity index**, having replaced it with the term **dispersity**, represented by the symbol  $\bar{M}_w/\bar{M}_n$  (pronounced D-stroke) which can refer to either molecular mass or degree of polymerization. It can be calculated using the equation  $\bar{M}_w/\bar{M}_n$ , where  $\bar{M}_w$  is the weight-average molar mass and  $\bar{M}_n$  is the number-average molar mass. It can also be calculated according to degree of polymerization, where  $\bar{X}_w/\bar{X}_n$ , where  $\bar{X}_w$  is the weight-average degree of polymerization and  $\bar{X}_n$  is the number-average degree of polymerization. In certain limiting cases where  $\bar{M}_w/\bar{M}_n = \bar{X}_w/\bar{X}_n$ , it is simply referred to as  $\bar{M}_w/\bar{M}_n$ . IUPAC

has also deprecated the terms *monodisperse*, which is considered to be self-contradictory, and *polydisperse*, which is considered redundant, preferring the terms *uniform* and *non-uniform* instead.

The **dispersity index**, or formerly polydispersity index (**PDI**), or heterogeneity index, or simply dispersity ( ), is a measure of the distribution of molecular mass in a given polymer sample. (PDI) of a polymer is calculated:

$$\text{PDI} = M_w / M_n$$

Where  $M_w$  is the weight average molecular weight and  $M_n$  is the number average molecular weight.  $M_n$  is more sensitive to molecules of low molecular mass, while  $M_w$  is more sensitive to molecules of high molecular mass. The dispersity indicates the distribution of individual molecular masses in a batch of polymers. has a value equal to or greater than 1, but as the polymer chains approach uniform chain length, approaches unity

Since molecular weight is central to the entire polymer field, students in this short course are assumed to understand the need for measuring polymer molecular weight and to be familiar, from textbooks or course notes, with the basic principles underlying the most common molecular weight measurement techniques - light scattering, osmometry, GPC, end group analysis, and intrinsic viscosity. For some polymer samples, textbook familiarity with a method and an instrument manual are all that is needed to make a meaningful measurement. For others, matters are not so simple, especially if a target polymer is of a new chemistry and/or not a linear neutral homopolymer that dissolves in an ordinary solvent.

After going through common methods in some detail, “problem” polymers and a few less common measurement methods will be discussed. In this first handout, principles and terminology associated with molecular weight and its distribution will be overviewed.

**Methods** - Some variation of the following table [adapted from Elias et al., Adv. Polym. Sci. **11** (1973), 111] is cited in many introductory polymer textbooks. This table lists measurement methods by type (A=absolute, R=relative, E=equivalent), by applicable molecular weight range, and if a specific mean molecular weight value is determined, by the type of average produced.

	Method	Type	Molecular Weight Range, g/mol	Mean Value Measured
1.	Membrane osmometry	A	$10^4$ - $10^6$	$M_n$
2.	Ebullioscopy (boiling point elevation)	A	$<10^4$	$M_n$

3.	Cryoscopy (freezing point depression)	A	$<10^4$	$M_n$
4.	Isothermal distillation	A	$<10^4$	$M_n$
5.	Vapor Phase osmometry	A*	$<10^5$	$M_n$
6.	End group analysis	E	$<10^5$	$M_n$
7.	Static light scattering	A	$10^2$ - $10^8$	$M_w$
8.	Sedimentation equilibrium	A	$<10^6$	$M_w, M_z, M_{z+1}$
9.	Sedimentation in a density gradient	A	$>10^5$	depends
10.	Sedimentation velocity/diffusion	A	$10^3$ - $10^8$	depends
11.	Solution viscosity	R	$10^2$ - $10^8$	$M_\eta$
12.	Gel Permeation Chromatography	R	$10^2$ - $10^7$	different values

“absolute” – the measurement is directly related to the molecular weight without assumptions about chemical and/or physical properties of the polymer

“equivalent” – the chemical structure of the polymer must be known to obtain molecular weight

“relative” – the quantity measured depends on the physical structure of the tested polymer and so a calibration curve relating measurement and molecular weight values must be known *a priori*; typically, this molecular weight calibration is established by companion measurements on a series narrow molecular weight polydispersity standards of the same chemical and physical structure as the tested polymer

### Classification of Methods -

*Calibration:* The terms “absolute”, “relative”, and “equivalent” are not always distinct. GPC, for example, may be absolute or relative, depending on the method of calibration. Vapor phase osmometry, as presented in the method’s underlying theory, is an absolute method, but in actual practice, the instrument requires calibration with a standard compound of known molecular weight, making the method relative. Even an absolute method such as mass spectrometry is usually calibrated by molecular weight standards.

*Molecular Weight Range:* Molecular weight ranges for each method are limited by constraints unique to that method. These limits will be discussed separately as methods are introduced.

*Molecular Weight Averages:* The common molecular weight averages ( $M_n, M_w, M_z, M_{z+1}$ ) are well understood by polymer students; they are associated with increasingly higher moments of



the molecular weight distribution. However, students often do not grasp why different experimental methods are sensitive to different averages.

### 1.3 Why Different Methods Provide Different Molecular Weight Averages

If the quantity measured by a given method directly manifests the number of polymer molecules - but not their molecular weights - this quantity can only be used to deduce  $M_n$ .

As an example, consider vapor phase osmometry. In a thermodynamically ideal solution, vapor pressure  $\pi$  is lowered by  $kT/V$  as each nonvolatile solute molecule of molecular mass  $M$  is added to volume  $V$  of volatile solvent. The lowered vapor pressure  $\Delta\pi$  of  $N$  polymer solutes is thus  $NkT/V$ , a combination independent of  $M$  but dependent on  $N$ . Upon writing this product in terms of  $c$ , the mass concentration of the solutes,  $M$  merges as a measurable parameter,

$$\Delta f = \frac{N}{V} kT = \frac{c}{M} kT$$

so that

$$M = \frac{c}{\Delta f} kT$$

For the polydisperse molecular weight case, suppose that  $N_i$  polymers of molecular weight  $M_i$  are added to the solvent, each molecular weight fraction  $i$  in the mixture present at mass concentration  $c_i$ . Only the total mass concentration  $c$  [ $=\sum c_i$ ] is known and only  $\Delta\pi$  measured, the latter parameter summing contribution  $kT/V$  from each molecule irrespective of  $M_i$ ,

$$\Delta f = \frac{kT}{V} \sum N_i$$

Applying the formula previously analyzed for monodisperse  $M$  now yields

$$\frac{ckT}{\Delta f} = \frac{V \sum c_i}{\sum N_i} = \frac{\sum V c_i}{N_i} = \frac{\sum N_i M_i}{\sum N_i} = M_n$$

This is the “true” average molecular weight as the word “average” is used in nontechnical contexts.

In essence, vapor phase osmometry allows a “count” of the number of molecules in a known mass of polymer. The same concept of molecular counting applies to all colligative property-based measurements (colligative properties are measured in osmometry, freezing point



depression, boiling point elevation, etc.), which detect the solvent activity in the presence of solute.

Contrarily, other methods manifest not just the number of dissolved molecules but also their molecular weight. Consider static light scattering. In the absence of optical interference, each polymer molecule dissolved in a fixed volume of solution contributes equally to the measured quantity, the reduced scattered intensity  $R$  ( $R$ =Rayleigh factor or ratio),

$$R = \frac{N}{V} k = \frac{c}{M} k$$

where  $k$  is a molecular contrast factor (reflecting the optical contrast between polymer and solvent surroundings, the property ultimately responsible for all light scattering phenomena). Without inter- and intramolecular interference of scattered light,  $k$  is given by the Rayleigh scattering formula,

$$k = \frac{16\pi^2 r^2 n_o^4}{\lambda_o^4}$$

where  $n_o$  is the solvent refractive index,  $\lambda_o$  is the wavelength of incident light in vacuum, and  $\alpha$  is the molecular polarizability.

If all subunits of a linear polymer (i.e., its repeat units) contribute equally to the polymer's net polarizability, as expected for a homopolymer,  $\alpha$  is proportional to  $M$ : a longer polymer scatters more light than a shorter one. It then follows from the above formulas that the reduced scattered intensity  $R$  is proportional to the product of  $c$  and  $M$ .

$$R = KcM$$

where the proportionality constant  $K$  is known as the optical constant; it has no dependence on  $M$ . By simple rearrangement,

$$M = \frac{R}{Kc}$$

Contrasting vapor phase osmometry with light scattering, the contribution of individual molecules to the measured signals are quite distinct,

$$\Delta f = \frac{N}{V} kT \quad \text{vs.} \quad R = \frac{N}{V} M^2 K$$

In light scattering, each molecule contributes to the overall measurement according to the square of its molecular weight. In osmometry, all molecules contribute equally, independently of molecular

weight. Turning to the analogous polydisperse molecular weight case, and using the same notation as before, contributions to R by each molecular weight fraction simply add,

$$R = K \sum c_i M_i$$

The M formula for the monodisperse sample now yields

$$\frac{R}{Kc} = \frac{\sum c_i M_i}{\sum c_i} = \frac{\sum N_i M_i^2}{\sum N_i M_i} = M_w$$

In essence, light scattering “sums” the product of the number of polymer molecules multiplied by the square of their molecular weight.

One could naively imagine a measurement method exactly intermediate to the two just evaluated, i.e., a method based on a property sensitive to the product of N and M. This product, however, is simply the total mass of polymer; it could not be employed to calculate M.

Because in vapor phase osmometry and similar techniques each molecule contributes to the overall measurement a constant, universal quantity independent of chemistry or structure, these techniques require, at least in theory, no calibration. As the previous discussion reveals, light scattering does require calibration, i.e., the value of K must be known to calculate M from R.


K is typically obtained by measuring the refractive index increment  $dn/dc$  as polymer is added to solvent, and as a consequence, I would prefer the light scattering method instead be termed the light scattering-refractive index method. The standard formula for K is written,

$$K = \frac{4f^2 n_o^2}{\sum_o^4 N_A} \left( \frac{dn}{dc} \right)^2$$

This formula, offering K via measurement of  $dn/dc$ , is derived through an optical model that supposes a polymer consists of independent, identical, and isotropic scattering sites immersed an optically homogeneous medium of infinite extent. The scattering from such sites is then proportional to the square of the scattering site-solvent optical mismatch [ $\sim (dn/dc)^2$ ], while the contribution from such sites to solution refraction index is linearly proportional to the same quantity [ $\sim (dn/dc)$ ]. These assumptions, due to Debye, are far from obvious. The local symmetry of a polymer chain is cylindrical, not spherical (i.e., not isotropic); also, the interaction of light with a single scattering site could be influenced by neighboring scattering sites. If one represents the chain as an optically mismatched cylinder rather than a string of isotropic, optically independent scattering sites, a slightly different prefactor appears in the theoretical formula for K. The difference can be associated with depolarized light scattering, which fortunately, is usually small for high M polymers.


### Molecular Weight Distributions -

Consider ways that this molecular weight distribution might be graphically presented. Most commonly, the distribution is shown as the raw GPC trace, which is given next. A single, well-defined molecular weight peak is noted. [To define the molecular weight distribution better, there should be more data points spread over the peak; I didn't want to do more hand calculations, so the table has only enough data to illustrate trends clearly.]



Despite this sample's large PDI, the peak looks relatively narrow. This trace, termed the chromatogram, is by itself pretty meaningless, since we don't know how  $M_i$  and  $V_i$  are related: the poorer the molecular weight separation, for example, the narrower is the chromatogram peak. Notwithstanding this trivial fact, raw GPC traces are frequently cited when arguing for low polydispersity.

In this instance, the relationship between  $M_i$  and  $V_i$  is known by a calibration with polystyrene standards, so we can do much better than the chromatogram. Given below are the weight and number fraction distributions derived above.



These bear no resemblance to the raw trace, and the significant polydispersity of the sample is amply evident. Indeed, the  $x(M)$  curve shows that the most common polymer species has a molecular weight of 7,200 g/mol even though  $M_n$  and  $M_w$  both exceed 100,000 g/mol. Approximately 10% of the molecules by weight have molecular weights in excess of 800,000

g/mol, while 10% by weight have molecular weights less than 50,000 g/mol. The value of  $M_n$  falls slightly above the maximum of  $w(M)$ , whereas the value of  $M_w$  lies well above this maximum, a fact commonly mentioned in introductory polymer texts. The difference between  $x(M)$  and  $w(M)$  simply manifests that it takes many small chains to balance the mass of a few larger chains. By number, the short chains dominate, while by weight, the converse is true. Surveying a whole year of Macromolecules, one is likely to never see a  $x(M)$  curve and just a handful of  $w(M)$  curves.

In most polymer situations, greatest interest lies in the logarithmic spread of  $M$ . This is the case, for example, if we are interested in the power law exponents of polymer physics, where an increase from 10,000 g/mol to 100,000 g/mol leads to property changes comparable to those for an increase from 100,000 g/mol to 1,000,000 g/mol. Unfortunately, the logarithmic spread of  $M$  is too often incorrectly displayed in a plot that simply switches the x-axis variable from  $M$  to  $\log M$ , leaving the y-axis magnitude unchanged. [Unfortunately, my name is listed on a paper with such an error; I didn't see the paper until it was too late to make a correction.]

To make the logarithmic plot properly, one must recognize that the plotted functions are distributions. Thus, the y-axis variable reflects the number of occurrences per unit change of x-axis variable. Here, for example,  $w(M)dM$  represents the number of chains with  $M$  in the range between  $M$  and  $M+dM$ . In logarithmic form, the y-axis variable must represent the number of chains with  $\log M$  in the range between  $\log M$  and  $\log M+d\log M$ . The y-axis variable in a logarithmic plot of a distribution thus has a different functional form than the y-axis variable in a linear plot of this same distribution. To avoid the spontaneous creation of chains in converting plotting formats, the new y-axis variable  $y'$  must be related to the old y-axis variable  $y$  by,


$$y \, dx = y' d\log(x)$$

Solving,

$$y' = yx$$

Thus, to present the weight fraction distribution in its logarithmic form, one must plot  $w(M)M$  vs.  $\log M$ . Similarly,  $x(M)$ , the number fraction distribution, must be plotted as  $x(M)M$  vs.  $\log M$ . Don't simply check the  $\log(x)$  box in the plotting software!

For the distribution of the example, these plots are given next.



The peak in the logarithmic weight fraction distribution is at 430,000 g/mol, well above  $M_w$ . This value nicely corresponds to the “peak molecular weight”  $M_p$  defined by the maximum of the GPC trace. When plotted in linear rather than logarithmic form, the peak is at 80,000 g/mol, which is quite different.  $M_p$ , although often used in GPC characterization, has no fundamental significance unless the distribution of molecular weights is very narrow. Loose definition of  $M_p$  creates confusion. This parameter usually represents the molecular weight position of the peak in the GPC trace.

Because the calibration curve in GPC offers an almost semi-logarithmic relationship between  $V_i$  and  $M_i$ , the function  $w(M)M$ , the weight fraction distribution in its logarithmic form, appears similar to a horizontal reflection of the original GPC trace.

### **End Group Method**

The molecular weight of polymers which have an end group amenable to analysis could be principally analyzed by an end-group assay [42]. The biggest drawback of this method is the decrease in sensitivity with an increased chain length. The first measurements with this method were performed by Staudinger and Eder and gave determination limits of about 15,000 g·mol<sup>-1</sup>. Weber and Husemann treated cellulose with an alkaline copper sulfate solution to oxidize aldehydes to aldonic acids. Afterwards, they determined the so-called “*Monosezahl*” (number of glucose units per carboxyl group). With this method, they were able to determine molecular weights up to 200,000 g·mol<sup>-1</sup>. However, due to processing, cellulose usually already contains oxidized end groups and additional carbonyl groups. Hence, a direct relationship between carboxyl groups (aldonic acid) and molecular weight determined with a high rate of accuracy.

### **Osmotic Pressure**

Osmometry is among the methods for determining molecular mass which rely on colligative properties (from the Latin word *colligere* for “collect”), meaning that only the number of dissolved molecules influences the properties of a solution [46]. In addition, the osmotic pressure, boiling point elevation, vapor pressure reduction, and the freezing point depression are

based on colligative properties. Out of the four colligative methods, only membrane osmometry (MO) is of interest for cellulosic samples.

However, vapor pressure osmometry (VPO) is superior for analyzing samples with  $M_n < 20,000 \text{ g}\cdot\text{mol}^{-1}$ . This is because the diffusion of low molecular weight molecules through the membrane limits the utility of membrane osmometry for this especially low molecular weight region. Only a few publications address the use of VPO experiments on directly-dissolved cellulose and these will be discussed at the end of this chapter.

Since the osmotic pressure of a solution depends on molecular weight and concentration  $c$ , the following equation can be used to determine the number average of the molecular weight

$$\frac{\Pi}{c} = RT \left( \frac{1}{M_n} + A_2c + A_3c^2 + \dots \right)$$

where  $\Pi$  is the osmotic pressure,  $c$  is the solute concentration,  $R$  is the ideal gas constant,  $T$  the temperature,  $M_n$  is the number average, and  $A_2$  and  $A_3$  are the second and third virial coefficients. The most common method of osmometry is membrane osmometry. In membrane osmometry, the osmotic pressure is measured directly using a semi-permeable membrane [42]. In experiments, the osmotic pressure must be measured at several different concentrations. By extrapolating the  $\Pi/c$  versus  $c$  plot to zero, the intercept gives the molecular weight, whereas slope yields  $A_2$ . Note, that  $A_2$  is an empirical constant for a given solute/solvent system and it depends on the temperature. It represents the interaction of a single molecule with the solvent. For the fundamental theory of osmometry.

Using osmometry for cellulose molecular weight determination creates a few problems. First, the osmotic pressure is inversely proportional to molecular weight, so molecules with a high molecular weight contribute very little. Therefore, the sample must be free of low molecular compounds when applying osmometry. This is especially true for salts and, therefore, for aqueous cellulose solutions. This is the main reason that osmometry is ordinarily used with cellulose derivatives in organic solvents.

In most cases, cellulose-based membranes such as cellophane or bacterial cellulose are used for membrane osmometry. However, these membranes are not completely resistant against solvents used for cellulose. Hence, the usual cellophane membrane gels which are used in an osmometer would dissolve in, for example, cuen solutions.

Working with those membranes, they measured the molecular weights of two cellulose samples directly. Since cellulose in cuen behaves as a polyelectrolyte, they faced another problem beyond membrane instability. However, by proper conditioning of the membranes, the polyelectrolyte character of the solution can be compensated and allow for a valid measurement. Immergut's paper is one of the few dealing with the direct osmometry of pure cellulose.

This method continues to play a minor role today, even for derivatized cellulose.

It is worth noting that osmometry was originally used to determine the relationship between intrinsic viscosity and molecular weight. It has been shown that under mild conditions, the degradation during cellulose nitration is negligible. In his pioneering work, Staudinger used the osmometry of cellulose nitrates in acetone to determine the constant  $K_{cm}$  of the Staudinger Equation:

$$\log \eta_r = K_{cm} * M * c$$

where  $\eta_{sp}$  is the relative viscosity (see Chapter 2.4),  $M$  is the molecular weight, and  $K'$  is the molecular weight-concentration constant. The Staudinger equation was later the basis for the Mark-Houwink equation (see Chapter 2.4).

Using VPO instruments with increased sensitivity, Kamide *et al.* detected an upper limit of  $1 \times 10^5 \text{ g} \cdot \text{mol}^{-1}$ . Compared with the results for cellulose acetate obtained by MO and SEC, VPO values differed by only a small percentage.

### **Ultracentrifugation**

When polymer chemistry was in its early stages in the 1920s, analytical ultracentrifugation experiments played an important role. Svedberg introduced two analytical ultracentrifugation methods: the sedimentation velocity method and the sedimentation equilibrium method [56]. The sedimentation velocity method (performed at, for example, 70,000 RPM) provides information on the physical homogeneity of a sample, its conformation, interaction or co-sedimentation, and flexibility information.

The sedimentation equilibrium, which is carried out at lower rotor speeds such as 15,000 RPM, yields information on absolute weight averages ( $M_w$ , and  $M_z$ ) and molecular weight distributions.

Ultracentrifugation is also capable of measuring the molecular charge in polysaccharides. Diffusion parameters can also be obtained by ultracentrifugation experiments; however, strictly speaking, diffusion has nothing to do with ultracentrifugation, though it is very closely connected to the theoretical and practical background. See Vollmert [57] for a detailed theoretical discussion.

The first studies of cellulose in which ultracentrifugation was used were performed by Stamm between 1926 and 1930. Stamm investigated cellulose dissolved in cuprammonium (tetraaminecopper(II) sulfate) and cellulose xanthogenate in diluted alkali solutions. He and his coworkers investigated the state of dispersion of cellulose in cuprammonium solutions. They found diffusion coefficients of cellulose and also claimed that cellulose was uniform with a molecular weight of  $55,000 \pm 7000 \text{ g} \cdot \text{mol}^{-1}$ . However, they realized that under an oxygen atmosphere, the cellulose is degraded.

A typical equilibrium run time was 190 h; therefore, severe degradation of the molecule during the measurements can be assumed.

Gralén and Svedberg measured cellulose in cuprammonium solutions under a nitrogen atmosphere.

In the area of synthetic polymers, ultracentrifugation experiments have been nearly completely replaced by other techniques. For biopolymers, especially cellulose, ultracentrifugation still plays a minor role in analytics. Two recent review articles published by Harding *et al.* discuss the possibilities of ultracentrifugation experiments in polysaccharide analysis today; especially in combination with SEC and MALLS, it can provide complementary information such as the heterogeneity of materials. Like SEC-MALLS, the sedimentation equilibrium method provides a molecular weight distribution, although there is no column or separation device and therefore no limitations concerning the column's medium inertness or available pore sizes.

Today, the ultracentrifuge is used to obtain fundamental biophysical information about solutions of cellulose rather than to determine molecular weight. In his perspective papers, however, Harding demonstrated that sedimentation equilibrium is a powerful and valuable independent check on the results generated with other methods such as SEC-MALLS experiments.



## Viscosity Method

Polymers are, in general, less soluble than their corresponding monomers. Dissolving polymers in solvents leads to an increase in viscosity; the longer the average chain length of the polymer molecules, the more the viscosity changes (known as positive viscosity). The viscosity of a solution can be easily measured; therefore, viscosity measurements are widely used in determining the average DP of cellulose.

In 1930, Hermann Staudinger was the first to recognize an empirical relationship between the relative magnitude of the increase in viscosity and the molecular weight of the polymer [27]. The simplest method for determining the viscosity of a polymer solution is by capillary viscometry, using the Ubbelohde U-tube viscometer. Here, the flow time  $t$  of the polymer solution and of pure solvent  $t_0$  are recorded. The ratio of the flow time of a polymer solution  $t$  to that of pure solvent is equal to the ratio of their viscosities ( $\eta / \eta_0$ ) if their densities are equal. This is only feasible for dilute solutions (in which density differences level out). Because unity is the lower limit of the relative viscosity  $\eta_r$ , the specific viscosity  $\eta_{sp}$  is more useful, as it depicts the relative increase brought about by the dissolved polymer.

Relating the specific viscosity to concentration gives the reduced viscosity. The intrinsic viscosity is expressed as the limit of the reduced viscosity at zero concentrations. The inherent viscosity is given as the natural logarithm of the relative viscosity divided by the concentration. At concentration zero the inherent viscosity becomes equal to the intrinsic viscosity. Thus, either the extrapolation of the reduced viscosity or the inherent viscosity gives the intrinsic viscosity:

$$\begin{aligned}\text{Relative Viscosity: } \eta_r &= \frac{\eta}{\eta_0} \\ \text{Specific Viscosity: } \eta_{sp} &= \frac{\eta - \eta_0}{\eta_0} = \eta_r - 1 \\ \text{Reduced Viscosity: } \eta_{red} &= \frac{\eta_{sp}}{c} \\ \text{Intrinsic Viscosity: } [\eta] &= \lim_{c \rightarrow 0} \frac{\eta_{red}}{c} \\ \text{Inherent Viscosity: } \eta_{inh} &= \frac{\ln \eta_r}{c}\end{aligned}$$

For a given polymer-solvent pair the intrinsic viscosity is a unique function of molecular mass. The Mark-Houwink (or Kuhn-Mark-Houwink-Sakurada) equation then relates the molecular weight of the polymer plus solvent at a specified temperature to the intrinsic viscosity

$$[\eta] = K_v M^\nu$$

$K_v$  (or sometimes  $KM$ ) and  $\nu$  (sometimes notated  $a$ ) must be established by calibrating with polymers of known molecular weights. Once this has been performed, only  $[\eta]$  will give the molecular weight for an unknown molecule, which is normally done by plotting  $\log [\eta]$  against  $\log M$  and subsequent interpolation.

For a theta solvent,  $\nu = 0.5$ , and as the solvent becomes thermodynamically better,  $\nu$  increases. For most practical systems, these values can be found in data handbooks. The extrapolation factors for cellulose to zero concentration are also listed. Under these assumptions, it is possible to calculate the intrinsic viscosity by measuring only one concentration of the sample. Molecular weights derived via the



Mark-Houwink equation and viscometry yield the viscosity average molar mass  $[M_v]$ , which is given by:

$$M_v = \left[ \frac{\sum n_i M_i^{1+v}}{\sum n_i M_i} \right]^{1/v}$$

where  $n_i$  is the number of molecules of molar mass  $M_i$  and the exponent  $v$  is the exponent of the Mark-Houwink equation. It should be noted that the viscosity average is not an absolute average and depends on solvent and/or temperature; therefore, viscosity measurements yield relative values.  $M_v$  is not a fixed quantity—it depends on  $v$ . If  $v$  becomes unity, viscosity and weight average are equal;  $M_v$  lies therefore, in between  $M_n$  and  $M_w$  in magnitude but will be usually closer to  $M_w$ .

Viscometry is the leading method for determining average molecular weight in industrial applications. As a standalone method, it delivers  $M_v$  values, typically by using an Ubbelohde capillary viscometer. In industrial applications, the measurement of  $[\eta]$  provides a quick and easy route to the molecular weight. For viscosity measurements, a minimum requirement is the knowledge of the dependence of  $[\eta]$  on  $(M)$ .

The solvent most commonly used for viscometry measurements is the complex-forming solvent cuen, largely because of its rapidity and simplicity in dissolving cellulose. One drawback of cuen lies in the cuen solution's high alkalinity, which may induce degradation reactions at oxidized functionalities.

Cellulose solutions in cuen are not very stable, and the solubility for cellulose with high molecular weight ( $DP > 5000$ ) is relatively poor.

Viscometry was actually one of the first methods used to determine polymer molecular weights.

It was Hermann Staudinger who applied viscometry to cellulose analytics in the 1930s. Staudinger described the  $K_m$  value (for the Staudinger equation) of cellulose in cuen with  $1 \times 10^{-4}$ ; in 1938 he published the  $K_m$  values for cellulose in Schweizer's Reagent as  $5 \times 10^{-4}$ .

It is important to remember that  $K_v$  and  $v$  are empirical constants. There are several standard methods for estimating the degree of polymerization of a cellulose sample from its intrinsic viscosity in cuen solution. In process control practices in industrial environments, the intrinsic viscosity is often estimated from a single viscosity measurement. There are several published warnings when using such standard methods. Evans *et al.* showed that the Mark-Houwink-Sakurada (MHS) equations used in the SCAN.

The relationship between intrinsic viscosity and the DP (or the molecular weight) is very often derived from osmometric measurements of cellulose trinitrate samples in acetone. Such measurements date back to very early experiments and should be evaluated with modern methods. It is commonly assumed that the molecular weight average determined by viscosity is very close to  $M_w$  and that  $M_v$  therefore is an approximation of  $M_w$ . In fact,  $M_v$  can often be very far from  $M_w$ , depending on the MHS parameters used and on the molecular weight distribution of the sample. Only if the sample is very narrowly distributed or if uniform standards are used can  $M_v$  be used as an approximation of  $M_w$ . MHS parameters found in the literature can be excessively variable, with  $K_v$  values ranging from 0.42 to 1.87 and  $v$  values ranging from 0.771 to 0.905.

In spite of these factors, viscometry remains a primary method for obtaining cellulose molecular weight averages because it does not require calibration. It is also a feasible method for

monitoring cellulose degradation during process steps, which results in relative data. This is mainly because it does not require advanced equipment, the method is relatively simple, and it is specifically recommended by industrial standards. It is essential to remember that the parameters for the Mark-Houwink equations are specified for cellulose and that it is problematic to use such parameters for samples with, for example, high lignin or hemicellulose content.

The equations also depend on the expected DP range; a DP larger than 950 requires a different equation than the equation used for lower DPs. According to the current knowledge, there is no equation available for cellulose with a large oligomeric portion, so the  $\eta_{sp}/c$ -DP values in such cases may be prone to error. It is standard practice to use linear fits for data when drawing a  $\log [\eta]$ - $\log M_w$  plot. In general, there is no justification for the linearity, and it is questionable whether such fits are applicable for cellulose oligomers or samples containing oligomers in such high amounts.

Thus far, most Mark-Houwink equations for cellulose were established for cellulose in  $\text{CuCl}_2/\text{H}_2\text{O}$  or  $\text{CaCl}_2/\text{H}_2\text{O}$  solutions [68–70] because these solvents demonstrate beneficial properties for the rapid dissolution of cellulose. However, the instability of cellulose in this solvent must be noted, as should the limited dissolving power for very large molecules.

The viscosity of cellulose in NMMO, a very important solvent within the technology sector, was first measured by Eckelt *et al.*, who reported the following equation

$$\log \left( \frac{[\eta]}{\text{ml} \cdot \text{g}^{-1}} \right) = -1.465 + 0.735 \log M$$

The Kuhn Mark-Houwink plot for cellulose in  $\text{NMMO} \cdot \text{H}_2\text{O}$  shows a non-linear behavior of the fit. After reaching a critical value, the straight line deviates. Thus far, this study is the only paper in which the cellulose viscosity in NMMO solutions is addressed. For analytical purposes, this solvent system has no practical importance because of the elevated temperature it requires.

### **Light Scattering Methods**

Scattering methods are some of the most popular methods for determining molecular weight averages  $M_w$ . The fundamentals of the light scattering phenomena were expounded by Lord Rayleigh in 1871.

Light scattering (LS) is one of the few absolute methods that provide access to molecular weight and structure. Light scattering is often used as a tandem technique together with separation using SEC [74]. As a standalone technique, it delivers the weight average  $M_w$ , the corresponding z-average square radii  $\langle r_g^2 \rangle_z$ , and the second virial coefficient  $A_2$  of cellulose. Since it is an absolute method, it does not require calibration. One limitation of the LS method is that for a given concentration  $c$  ( $\text{g} \cdot \text{mL}^{-1}$ ), the scattered light signal is proportional to  $c \times M_w$ , such that molecules below a few thousand  $\text{g} \cdot \text{mol}^{-1}$  need relatively high concentrations in order to produce a detectable signal. Raising the concentration of, for example, a broad distributed sample, leads to problems, especially in the SEC portion of the process in which cellulose is analyzed. Dust will also scatter light and contribute to the intensity; therefore, dust has to be removed using ultra-fine filters or centrifugation prior to measurements. The source of radiation is, in most cases, visible light from a laser; therefore, using colored solvents (e.g., Cu- and Fe-containing complexes) is challenging and cellulose is often derivatized and dissolved in an organic solvent or colorless solvent instead. Thus far, DMAc/LiCl is the solvent of choice for an LS experiment coupled to an SEC.

Measuring cellulosic samples with fluorescence activity (e.g., pulp with high lignin content) also poses some challenges. Due to the laser excitation, even small amounts of fluorophores will disrupt a measurement. There are two types of LS experiments: the batch mode and the chromatographic (online) measurement. In the batch mode (off-line), MALLS detector can be used as a standalone instrument to characterize an unfractionated polymer sample; the online use of an LS detector is described in

In this static light scattering experiment (SLS), a vertically polarized (laser) light is scattered by the macromolecules of a polymer in solution. The scattered light is detected by a photometer or a photodiode: either one photometer is used to encircle the sample in a horizontal plane or several photodiodes are placed around the measurement cell, which detects the scattered light from several positions and angles.

The ratio:

$$R_{\theta} = \frac{I_{\text{scattered}}}{I_{\text{incident}}}$$

depends on:

- The concentration of solution  $c$ ;
- The specific refractive increment obtained at chemical equilibrium  $dn/dc$  or, more accurately,  $(dn/dc)_{\mu}$ ;
- The molecular weight of dissolved particles ( $M$ );
- Scattering angle  $\theta$ .

The scattering intensity is dependent on the angle and reflects the diminution of the light intensity by intra-particle interference. For light scattering experiments, the Zimm equation forms for calculating the molecular weight:

$$\frac{K^* c}{R(\theta, c)} = \frac{1}{M_w P(\theta)} + 2A_2 c$$

Where  $K^*$  is the optical constant,  $R(\theta, c)$  is the excess Rayleigh ratio of the solution as a function of scattering angle  $\theta$  and concentration  $c$ ,  $M_w$  is the molar mass weight average,  $P(\theta)$  is the angular dependence of the scattered light,  $A_2$  is the second virial coefficient, and  $c$  is the concentration of the solute.

The optical constant is described by the following equation:

$$K^* = \frac{4 * \pi^2 (dn/dc)^2 n_0^2}{N_a \lambda^4}$$

Where  $dn/dc$  is the specific refractive increment at chemical equilibrium,  $N_a$  is the Avogadro's Number,  $\lambda_0$  is the wavelength of the incident light, and  $n_0$  is the solvent refractive index.

The measured data can be extrapolated to zero concentration and zero-degree scattering angle, which can be achieved for the batch mode by using the so-called Zimm-plot to derive three valuable quantities: the weight average  $M_w$ , the second virial coefficient of osmotic pressure  $A_2$

(both with extrapolation to zero angle), and the radius of gyration (z-average) by extrapolating the concentration to zero. The specific refractive increment at chemical equilibrium must be measured separately by using a differential refractometer.

## **Polymer morphology**

Polymer morphology generally describes the arrangement and microscale ordering of polymer chains in space.

### ***Crystallinity***

When applied to polymers, the term *crystalline* has a somewhat ambiguous usage. In some cases, the term *crystalline* finds identical usage to that used in conventional crystallography. For example, the structure of a crystalline protein or polynucleotide, such as a sample prepared for x-ray crystallography, may be defined in terms of a conventional unit cell composed of one or more polymer molecules with cell dimensions of hundreds of angstroms or more.

A synthetic polymer may be loosely described as crystalline if it contains regions of three-dimensional ordering on atomic (rather than macromolecular) length scales, usually arising from intramolecular folding and/or stacking of adjacent chains. Synthetic polymers may consist of both crystalline and amorphous regions; the degree of crystallinity may be expressed in terms of a weight fraction or volume fraction of crystalline material. Few synthetic polymers are entirely crystalline.

The crystallinity of polymers is characterized by their degree of crystallinity, ranging from zero for a completely non-crystalline polymer to one for a theoretical completely crystalline polymer. Polymers with microcrystalline regions are generally tougher (can be bent more without breaking) and more impact-resistant than totally amorphous polymers.

Polymers with a degree of crystallinity approaching zero or one will tend to be transparent, while polymers with intermediate degrees of crystallinity will tend to be opaque due to light scattering by crystalline or glassy regions. Thus for many polymers, reduced crystallinity may also be associated with increased transparency.

### ***Chain conformation***

The space occupied by a polymer molecule is generally expressed in terms of radius of gyration, which is an average distance from the center of mass of the chain to the chain itself. Alternatively, it may be expressed in terms of pervaded volume, which is the volume of solution spanned by the polymer chain and scales with the cube of the radius of gyration.

## **Phase behavior**

### ***Melting point***

The term *melting point*, when applied to polymers, suggests not a solid–liquid phase transition but a transition from a crystalline or semi-crystalline phase to a solid amorphous phase. Though abbreviated as simply  $T_m$ , the property in question is more properly called the crystalline melting temperature. Among synthetic polymers, crystalline melting is only discussed with regards to thermoplastics, as thermosetting polymers will decompose at high temperatures rather than melt.

### ***Glass transition temperature***

A parameter of particular interest in synthetic polymer manufacturing is the glass transition temperature ( $T_g$ ), at which amorphous polymers undergo a transition from a rubbery, viscous liquid, to a brittle, glassy amorphous solid on cooling. The glass transition temperature may be engineered by altering the degree of branching or crosslinking in the polymer or by the addition of plasticizer

### **Glass transition**

The **glass-liquid transition** or **glass transition** for short is the reversible transition in amorphous materials (or in amorphous regions within semicrystalline materials) from a hard and relatively brittle "glassy" state into a viscous or rubbery state as the temperature is increased. An amorphous solid that exhibits a glass transition is called a glass. The reverse transition, achieved by supercooling a viscous liquid into the glass state, is called vitrification.

The **glass-transition temperature**  $T_g$  of a material characterizes the range of temperatures over which this glass transition occurs. It is always lower than the melting temperature,  $T_m$ , of the crystalline state of the material, if one exists.

Hard plastics like polystyrene and poly(methyl methacrylate) are used well below their glass transition temperatures, that is in their glassy state. Their  $T_g$  values are well above room temperature, both at around  $100\text{ }^{\circ}\text{C}$  ( $212\text{ }^{\circ}\text{F}$ ). Rubber elastomers like polyisoprene and polyisobutylene are used above their  $T_g$ , that is, in the rubbery state, where they are soft and flexible.


Despite the change in the physical properties of a material through its glass transition, the transition is not considered a phase transition; rather it is a phenomenon extending over a range of temperature and defined by one of several conventions. Such conventions include a constant cooling rate ( $20\text{ kelvins per minute}$  ( $36\text{ }^{\circ}\text{F/min}$ )) and a viscosity threshold of  $10^{12}\text{ Pa}\cdot\text{s}$ , among others. Upon cooling or heating through this glass-transition range, the material also exhibits a smooth step in the thermal-expansion coefficient and in the specific heat, with the location of these effects again being dependent on the history of the material.

### **Relationship between $T_g$ and $T_m$**

In polymers the glass transition temperature,  $T_g$ , is often expressed as the temperature at which the Gibbs free energy is such that the activation energy for the cooperative movement of 50 or so elements of the polymer is exceeded. This allows molecular chains to slide past each other when a force is applied. From this definition, we can see that the introduction of relatively stiff chemical groups (such as benzene rings) will interfere with the flowing process and hence increase  $T_g$ . The stiffness of thermoplastics decreases due to this effect (see figure.) When the glass temperature has been reached, the stiffness stays the same for a while, i.e., at or near  $E_2$ , until the temperature exceeds  $T_m$ , and the material melts. This region is called the rubber plateau.

In ironing, a fabric is heated through this transition so that the polymer chains become mobile. The weight of the iron then imposes a preferred orientation.  $T_g$  can be significantly decreased by addition of plasticizers into the polymer matrix. Smaller molecules of plasticizer embed themselves between the polymer chains, increasing the spacing and free volume, and allowing them to move past one another even at lower temperatures. The "new-car smell" is due to the initial outgassing of volatile small-molecule plasticizers (most commonly known as phthalates)

used to modify interior plastics (e.g., dashboards) to keep them from cracking in the cold of winter weather. The addition of nonreactive side groups to a polymer can also make the chains stand off from one another, reducing  $T_g$ . If a plastic with some desirable properties has a  $T_g$  that is too high, it can sometimes be combined with another in a copolymer or composite material with a  $T_g$  below the temperature of intended use. Note that some plastics are used at high temperatures, e.g., in automobile engines, and others at low temperatures.



Stiffness versus temperature

In viscoelastic materials, the presence of liquid-like behavior depends on the properties of and so varies with rate of applied load, i.e., how quickly a force is applied. The silicone toy Silly Putty behaves quite differently depending on the time rate of applying a force: pull slowly and it flows, acting as a heavily viscous liquid; hit it with a hammer and it shatters, acting as a glass.

On cooling, rubber undergoes a *liquid-glass transition*, which has also been called a *rubber-glass transition*.

### **Determination of $T_g$**


The glass transition temperature ( $T_g$ ) of a polymer adhesive is actually a range of temperatures during which the solid polymer material experiences some substantial changes in its physical properties (transitions from glassy to rubbery solid).

### **Differential Scanning Calorimetry (DSC)**

The basic concept of this method is that as a polymer transitions from a glassy to a rubbery state, one of the physical properties of the material that substantially changes is its heat capacity - the amount of heat it takes to raise the temperature of the material by one degree.

A DSC gradually adds more and more heat to a sample of a polymer material and at the same time measures how much the material changes its temperature as a result. When the polymer reaches the lower end of its glass transition temperature its heat capacity will spike up and the DSC will use this information to ultimately estimate the glass transition temperature of the material ( $T_g$  is point B on the graph below).





Estimating the  $T_g$  of a material using a DSC is a cost effective method, however, it is not always accurate. Many materials will only have a small increase in heat capacity, making the transition hard to identify.

### Thermo Mechanical Analysis (TMA)


TMA estimates the glass transition temperature of a material by tracking its coefficient of thermal expansion (CTE). In many cases the CTE of a polymer material will increase 3-5x as it transitions from the glassy to the rubbery state.

Similar to DSC testing, TMA involves slowly adding heat to a sample material and simultaneously tracking changes in physical properties. In the case of TMA, the physical dimensions of the material are tracked and the  $T_g$  is identified as the temperature where there is a dramatic change in these dimensions.

TMA testing is slightly more involved than DSC testing, however, this method generally yields more accurate results.

### Dynamic Mechanical Analysis (DMA)

One of the most immediate and obvious differences between a glassy and a rubbery material is of course the stiffness. DMA testing uses this fundamental physical differentiator as a guide and tracks the stiffness of a polymeric material over a range of temperatures in order to determine its  $T_g$ . The graph below plots stiffness vs. temperature and points out



*"Rubber plateau"*

This method is extremely accurate and sensitive, however, is also very time consuming and costly compared to the other two methods described.

**Text book:**

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.

**Reference book**

**R1:** M.S Bhatnagar, 2004, " A text book of polymers". 1<sup>st</sup> Edition, S.Chand & Company.

**POSSIBLE QUESTIONS****Multiple choice questions (Each carry 1 Marks)**

1. The freezing point depression depends on the  
a. Number of dissolved solutes    b. Average weight of solute    **c. Size and nature of solute**  
d. solvent nature
2. The difference temperature between the freezing point of solute and solvent in the range of  
a. 10°C    b. 0.01°C    **c. 0.001°C**    d. 0.1°C
3. By this method, accurately determine the molecular weights upto  
a. 10,000    b. 20,000    **c. 30,000**    d. 50,000
4. The method based on observation of boiling point of a solution and solvent is known as  
a. cryoscopic    **b. Ebulliometry**    c. membrane Osmometry  
d. Equilibrium Osmometry
5.  $\sum_{i=1}^{\infty} N_i$  the equation belongs to  
a. **Number-average concept**    b. Weight average concept    c. Viscosity concept  
d. Osmotic concept
6. The weight average molecular degree of polymerisation indicates as  
a.  $D_p$     **b.  $(D_p)_w$**     c.  $(D_p)_n$     d.  $D$
7. A simple chemical compounds which have same molecular weight to form  
**a. monodispersion**    b. bi dispersion    c. poly dispersion    d. polymer solution
8. The symbol  $M_v$  represents the  
a. Number-average molecular weight    **b. Weight average molecular weight**



- c. **Viscosity average molecular weight**      d. Vapour pressure molecular weight
9. A polymer contains different molecular weight compounds to form  
a. monodispersion      b. bi dispersion      c. **poly dispersion**      d. polymer solution
10. The symbol  $M_w$  represents the  
a. Number-average molecular weight      b. **Weight average molecular weight**  
c. Viscosity average molecular weight      d. Vapour pressure molecular weight
11. The symbol  $M_v$  represents the  
a. Number-average molecular weight      b. Weight average molecular weight  
c. **Viscosity average molecular weight**      d. Vapour pressure molecular weight
12. The phenomenon of depressing the freezing point of a liquid by the addition of solute is known as  
a. **Cryoscopy**      b. Ebulliometry      c. Osmometry      d. Vapour phase Osmometry
13. The freezing point depression depends on the  
a. Number of dissolved solutes      b. Average weight of solute      c. **Size and nature of solute**  
d. solvent nature
14. The difference temperature between the freezing point of solute and solvent in the range of  
a.  $10^\circ\text{C}$       b.  $0.01^\circ\text{C}$       c.  **$0.001^\circ\text{C}$**       d.  $0.1^\circ\text{C}$
15. By this method, accurately determine the molecular weights upto  
a. 10,000      b. 20,000      c. **30,000**      d. 50,000
16. The method based on observation of boiling point of a solution and solvent is known as  
a. cryoscopic      b. **Ebulliometry**      c. membrane Osmometry  
d. Equilibrium Osmometry
17.  $[\eta]$ , dl/g is equal to the  
a. specific viscosity      b. reduced viscosity      c. inherent viscosity      d. **intrinsic viscosity**
18. The intrinsic viscosity is also known as  
a. specific viscosity      b. reduced viscosity      c. inherent viscosity      d. **Staudinger viscosity**
19. The rpm maintained for minute in the sedimentation equilibrium method is  
a. 30,000      b. 50,000      c. 15,000      d. **65,000**
20. The error occurred in the viscometer due to the measurement of  
a. level of solute      b. density      c. nature      d. **flow time**

### Questions (Each Carry 6 Marks)

- How to calculate the molecular weight of the polymer based on the number average method. Explain anyone of its experimental method?
- Give an account of viscosity methods?
- How to calculate the molecular weight of the polymer based on viscosity?
- Give an account of light scattering method?
- How to calculate the molecular weight of the polymer based on the weight average method. Explain anyone of its experimental method?
- Give an account of vapour phase osmometry methods?
- How to determine the molecular weight by osmometry?
- Give an account of viscosity methods?
- How to calculate the molecular weight of the polymer by Cryoscopic and Ebulliometric method?

10. What are the difference between  $T_g$  and  $T_m$ ?
11. What is Glass Transition Temperature? How to determine it experimentally?

**Compulsory Questions (Each Carry 10 Marks)**

1. What is glass transition temperature and how will you determine the  $T_g$  by experimentally?
2. How to calculate the polymer weight of the polymer based on weight average method?
3. What is number average method? Explain its experimental methods to determine the molecular weight of the polymers?

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

	Questions	Opt-1	Opt-2	Opt-3	Opt-4	Answers
1	$\sum_{i=1}^{\infty} N_i$ the equation belongs to	Number-average concept	Weight average concept	Viscosity concept	Osmotic concept	Number-average concept
2	The weight average molecular degree of polymerisation indicates as	Dp	(Dp)w	(Dp)n	D	(Dp)w
3	A simple chemical compounds which have same molecular weight to form	monodispersion	bi dispersion	poly dispersion	polymer solution	monodispersion
4	A polymer contains different molecular weight compounds to form	monodispersion	bi dispersion	poly dispersion	polymer solution	poly dispersion
5	The symbol $\bar{M}_n$ represents the	Number-average molecular weight	Weight average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Number-average molecular weight
6	The symbol $\bar{M}_w$ represents the	Number-average molecular weight	Weight average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Weight average molecular weight
7	The symbol $\bar{M}_v$ represents the	Number-average molecular weight	Weight average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Viscosity average molecular weight

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

8	The experiments based on viscosity yield the	Number-average molecular weight	Weight average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Viscosity average molecular weight
9	The phenomenon of depressing the freezing point of a liquid by the addition of solute is known as	Cryoscopy	Ebuliometry	Osmometry	Vapour phase Osmometry	Cryoscopy
10	The freezing point depression depends on the	Number of dissolved solutes	Average weight of solute	solvent concentration	solvent nature	Number of dissolved solutes
11	The freezing point depression not to depends on the	size and nature of solute	nature of solvent	number of solutes	weight of solvent	size and nature of solute
12	Cryoscopic method is applied to determine the	Weight average molecular weight	Number-average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Number-average molecular weight
13	The freezing point of the solvent indicates the	F	TF	Tf	Ts	Tf
14	$\Delta T_f$ is the difference of	freezing point between solute and solvent	freezing point of solutes	freezing point between solvent molecules	the temperature between solute and solvent	freezing point between solute and solvent
15	In the cryoscopic method, the error occurred to measure the	weight of monomer	temperature	freezing point	melting point	temperature
16	The difference temperature between the freezing point of solute and solvent in the range of	10°C	0.01°C	0.001°C	0.1°C	0.001°C

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

17	By this method, accurately determine the molecular weights upto	10,000	20,000	30,000	50,000	30,000
18	The method based on observation of boiling point of a solution and solvent is known as	cryoscopic	Ebuliometry	membrane Osmometry	Equilibrium Osmometry	Ebuliometry
19	The Ebulliometry is a method based on the observation of	freezing point	boiling point	melting point	crystalline point	boiling point
20	The difference in the heat of vapourisation is indicates as	$\Delta H_v$	$\Delta S_v$	$\Delta T_v$	$\Delta G_v$	$\Delta H_v$
21	The $T_b$ is the symbol for	freezing point of solvent	boiling point of solvent	melting point of solvent	crystalline point of solvent	boiling point of solvent
22	The osmosis based method is known as	membrane osmometry	Ebuliometry	Cryoscopic	Viscometry	membrane osmometry
23	The membrane osmometry method based on	freezing point	osmotic pressure	boiling point	crystalline point	osmotic pressure
24	In the membrane osmometry, the pressure applied to the solution should prevent	nature of solvent	flow of solvent	nature of solute	concentration of solvent	flow of solvent
25	The osmotic pressure is represented as	$\sigma$	$\theta$	$\mu$	$\pi$	$\pi$

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

26	The osmotic pressure is related to the	Weight average molecular weight	Number-average molecular weight	Viscosity average molecular weight	Vapour pressure molecular weight	Number-average molecular weight
27	The Ebulliometry method, the boiling point of solution is	higher than solvent	less than solvent	same to the solvent	decrease than solvent	higher than solvent
28	The Ebulliometry method is applicable for	volatile solute	non-volatile solute	ionised solute	low molecular weight solute	non-volatile solute
29	The solution and solvent levels are measured by using	cathetometer	anometer	thermometer	osmometry	cathetometer
30	The cathetometer is used to measure the	height of solute and solvent	density of solute and solvent	Viscosity of solute and solvent	concentration of solute and solvent	height of solute and solvent
31	1 atmosphere is equal to the	1033 g wt/cm <sup>2</sup>	1110 g wt/cm <sup>2</sup>	1200 g wt/cm <sup>2</sup>	1040 g wt/cm <sup>2</sup>	1033 g wt/cm <sup>2</sup>
32	The membrane osmometry is used to measure the molecular weight in the range of	30,000	30,000 to 40,000	30,000 to 1000000	50,000 to 100000	30,000 to 1000000
33	The vapour pressure of a solution is --- than pure solvent	more	less	same	constant	less
34	The total rise in temperature is proportional to the	molecular weight	mole fraction of solute	number of solutes	nature of solute	mole fraction of solute

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

35	The ratio between the functionality divided by functional group equivalent is known as	$\bar{M}_n$	$\bar{M}_w$	$\bar{M}_v$	$\bar{M}_s$	$\bar{M}_n$
36	The viscosity of the polymer solution is high compared to	solute	solvent	monomer	catalyst	solvent
37	The relative viscosity is equal to the	$\eta/\eta_0 = t/t_0 = \eta_r$	$\eta_{sp}$	$\eta_{red}$	$\ln \eta_r / C$	$\eta/\eta_0 = t/t_0 = \eta_r$
38	The specific viscosity is equal to the	$\eta_r - 1$	$\eta_r$	$\eta_{red}$	$\ln \eta_r / C$	$\eta_r - 1$
39	The reduced viscosity is equal to the	$\eta_{sp} / C = \eta_{red}$	$\eta_r - 1$	$\eta_r$	$\ln \eta_r / C$	$\eta_{sp} / C = \eta_{red}$
40	$\ln \eta_r / C$ is the	specific viscosity	reduced viscosity	inherent viscosity	intrinsic viscosity	inherent viscosity
41	$[\eta]$ , dl/g is equal to the	specific viscosity	reduced viscosity	inherent viscosity	intrinsic viscosity	intrinsic viscosity
42	The intrinsic viscosity is also known as	specific viscosity	reduced viscosity	inherent viscosity	Staudinger viscosity	Staudinger viscosity
43	The limiting viscosity number known as	specific viscosity	reduced viscosity	inherent viscosity	intrinsic viscosity	intrinsic viscosity

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019

44	The USLV is the	osmometer	viscometer	cathetometer	speedometer	viscometer
45	The viscosity highly depends on the	temperature	density	size	nature	temperature
46	The range of constant temperature maintained at viscometer is	0.01°C	± 0.001°C	± 0.1°C	± 0.01°C	± 0.01°C
47	The error occurred in the viscometer due to the measurement of	level of solute	density	nature	flow time	flow time
48	All the solutions are free from impurities, it reduces the	Number of dissolved solutes	yield	error	density	error
49	Which one of the following is most complex method	viscometry	osmometry	ultracentrifugation	light scattering	ultracentrifugation
50	In the ultracentrifugation, which force is used for polymer separation	kinetic force	magnetic force	centrifugal force	vanderwalls force	centrifugal force
51	The sedimentation velocity depends on the	nature of polymer	size of polymer	molecular weight	number of solute	molecular weight
52	The sedimentation velocity method has - ---- revolution per minute	30,000	60,000	65,000	50,000	65,000



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: III (MOLECULAR WEIGHT AND PROPERTIES) BATCH-2017-2019



53	The symbol $\omega$ represents the	angular viscosity	pressure	angular moment	angular velocity	angular velocity
54	The sedimentation constant is denoted as	$\omega_0$	S0	A0	C0	S0
55	The molecular weight distribution form a heterogenous system in the	sedimentation velocity method	sedimentation viscosity method	sedimentation equilibrium method	Osmometric method	sedimentation equilibrium method
56	The sedimentation equilibrium method is one of the	easy method	time consuming	low cost	accurate	time consuming
57	The rpm maintained for minute in the sedimentation equilibrium method is	30,000	50,000	15,000	65,000	15,000
58	The symbol $i_0$ is the equation	intensity of scattered light	intensity of incident light	intensity of solvent	intensity of both solute and solvent	intensity of scattered light
59	The symbol $\eta$ is equal to the	viscosity	velocity	turbidity	density	turbidity
60	the equation belongs to	Number-average concept	Weight average concept	Viscosity concept	Osmotic concept	Number-average concept

**Unit-IV**

**SYLLABUS**

**Polymer Processing:** Plastics, elastomers and fibres. Compounding, processing techniques: calendering, die casting, rotational casting, film casting, injection moulding, blow moulding extrusion, moulding, thermoforming, foaming, reinforcing and fibre spinning.

**Plastics- Introduction**

Property	Low Density Polyethylene (LDPE)	High Density Polyethylene (HDPE)
Melting Point	~115°C	~135°C
Crystallinity	low crystallinity (50-60% crystalline) Main chain contains many side chains of 2-4 carbon atoms leading to irregular packing and low crystallinity (amorphous)	highly crystalline (>90% crystalline) contains less than 1 side chain per 200 carbon atoms in the main chain leading to long linear chains that result in regular packing and high crystallinity
Flexibility	more flexible than HDPE due to lower crystallinity	more rigid than LDPE due to higher crystallinity
Strength	not as strong as HDPE due to irregular packing of polymer chains	strong as a result of regular packing of polymer chains
Heat Resistance	retains toughness & pliability over a wide temperature range, but density drops off dramatically above room temperature.	useful above 100°C
Transparency	good transparency since it is more amorphous (has non-crystalline regions) than HDPE	less transparent than LDPE because it is more crystalline
Density	0.91-0.94 g/cm <sup>3</sup> lower density than HDPE	0.95-0.97 g/cm <sup>3</sup> higher density than LDPE
Chemical Properties	chemically inert Insolvent at room temperature in most solvents. Good resistance to acids and alkalis. Exposure to light and oxygen results in loss of strength and loss of tear resistance.	chemically inert
Schematic diagram		

Uses	sandwich bags, cling wrap, car covers, squeeze bottles, liners for tanks and ponds, moisture barriers in construction	freezer bags, water pipes, wire and cable insulation, extrusion coating
------	---	---

## **Elastomer**

An **elastomer** is a polymer with viscoelasticity (having both viscosity and elasticity) and very weak inter-molecular forces, generally having low Young's modulus and high failure strain compared with other materials.<sup>[1]</sup> The term, which is derived from *elastic polymer*, is often used interchangeably with the term rubber, although the latter is preferred when referring to vulcanisates. Each of the monomers which link to form the polymer is usually made of carbon, hydrogen, oxygen or silicon. Elastomers are amorphous polymers existing above their glass transition temperature, so that considerable segmental motion is possible. At ambient temperatures, rubbers are thus relatively soft ( $E \sim 3\text{MPa}$ ) and deformable. Their primary uses are for seals, adhesives and molded flexible parts. Application areas for different types of rubber are manifold and cover segments as diverse as tires, shoe soles, and damping and insulating elements.

Rubber like solids with elastic properties are called elastomers. Polymer chains are held together in elastomers by weak intermolecular forces. These weak binding forces permit the polymers to be stretched. Natural rubber, neoprene rubber, buna-s and buna-n are elastomers.

## **Fibres**

### **Fiber**



A bundle of optical fibers

**Fiber** or **fibre** (from the Latin *fibra*<sup>[1]</sup>) is a natural or synthetic substance that is significantly longer than it is wide.<sup>[2]</sup> Fibers are often used in the manufacture of other materials. The strongest engineering materials often incorporate fibers, for example carbon fiber and ultra-high-molecular-weight polyethylene.

Synthetic fibers can often be produced very cheaply and in large amounts compared to natural fibers, but for clothing natural fibers can give some benefits, such as comfort, over their synthetic counterparts.

## **Compounding**

**Pharmaceutical compounding** (done in **compounding pharmacies**) is the creation of a particular pharmaceutical product to fit the unique need of a patient. To do this, compounding pharmacists combine or process appropriate ingredients using various tools. This may be done for medically necessary reasons, such as to change the form of the medication from a solid pill to a liquid, to avoid a non-essential ingredient that the patient is allergic to, or to obtain the exact dose(s) needed or deemed best of particular active pharmaceutical ingredient(s). It may also be done for more optional reasons, such as adding flavors to a medication or otherwise altering taste or texture. Compounding is most routine in the case of intravenous/parenteral medication, typically by hospital pharmacists, but is also offered by privately owned compounding pharmacies and certain retail pharmacies for various forms of medication. Whether routine or rare, intravenous or oral, etc., when a given drug product is made or modified to have characteristics that are specifically prescribed for an individual patient, it is known as "**traditional**" compounding.

Due to the rising cost of compounding and the shortage of drugs, many hospitals have shown a tendency to rely more upon large-scale compounding pharmacies to meet their regular requirement, particularly of sterile-injectable medications. When compounding is done on bulk production of a given formulation rather than patient-specific production, it is known as "non-traditional" compounding (which, as discussed below, is arguably not "compounding" but rather "manufacturing"). This development raises concerns about patient safety and makes a case for proper regulatory control and monitoring.

## **Roles**

### **During research and development**

Pharmaceutical compounding is a branch of pharmacy that continues to play the crucial role of drug development. Compounding pharmacists and medicinal chemists develop and test combinations of active pharmaceuticals and delivery systems for new pharmaceutical formulations so that the active ingredients are effective, stable, easy to use, and acceptable to patients. However, for actual clinical trials, production of drug products is generally considered *manufacturing* because *compounding* is typically defined as being for small batch or single individual patient production only.

### **Patients with unique or unusual medication needs**

Physicians may prescribe an individually compounded medication for a patient with an unusual health need. This allows the physician to tailor a prescription to each individual. Compounding preparations are especially prevalent for:


- Patients requiring an individualized compounded formulation to be developed by the pharmacist<sup>[4]</sup>
- Patients who cannot take commercially prepared prescriptions<sup>[4]</sup>
- Patients requiring limited dosage strengths, such as a very small dose for infants
- Patients requiring a different formulation, such as turning a pill into a liquid or transdermal gel for people who cannot swallow pills due to disability
- Patients requiring an allergen-free medication, such as one without gluten or colored dyes
- Patients who absorb or excrete medications abnormally<sup>[5]</sup>
- Patients who need drugs that have been discontinued by pharmaceutical manufacturers because of low profitability
- Patients facing a supply shortage of their normal drug

- Children who want flavored additives in liquid drugs, usually so that the medication tastes like candy or fruit
- Veterinary medicine, for a change in dose, change to a more easily administered form (such as from a pill to a liquid or transdermal gel), or to add a flavor more palatable to the animal. In the United States, compounded veterinary medicine must meet the standards set forth in the Animal Medicinal Drug Use Clarification Act (AMDUCA)
- Many types of bioidentical hormone replacement therapy

## **Polymer processing Techniques**

Plastics are mainly organic polymers of high molecular mass, but they sometimes contain other substances as well. Plastics are usually synthetic, most commonly derived from petrochemicals, but many are partially natural. Plastics are usually classified by their chemical structure of the polymer's backbone and side chains. Some important groups in these classifications are the acrylics, polyesters, silicones, polyurethanes, and halogenated plastics. There are a variety of methods used to process plastic. Each method has its advantages and disadvantages and are better suited for specific applications. There are various plastic processing techniques.

### **1. Calendering**



Calendering is a continuous process which works in much the same way as an old-fashioned clothes mangle. For plastics, there are usually four heated rollers of different sizes rotating at slightly different speeds. The material is fed into these rollers, heated and melted, then shaped into a sheet or film. This is then cooled and rolled up. The sheets can be mono-oriented during this process. The most commonly calendered material is PVC.

### **2. Casting Process**

**Casting** is a manufacturing process in which a liquid material is usually poured into a mold, which contains a hollow cavity of the desired shape, and then allowed to solidify. The solidified part is also known as a *casting*, which is ejected or broken out of the mold to complete the process. Casting materials are usually metals or various *cold setting* materials that cure after mixing two or more components together; examples are epoxy, concrete, plaster and clay. Casting is most often used for making complex shapes that would be otherwise difficult or uneconomical to make by other methods.

1. **Die casting**
2. **Rotational casting**
3. **Film casting**

## 2.1 Die casting

**Die casting** is a metal casting process that is characterized by forcing molten metal under high pressure into a mold cavity. The mold cavity is created using two hardened tool steel dies which have been machined into shape and work similarly to an injection mold during the process. Most die castings are made from non-ferrous metals, specifically zinc, copper, aluminium, magnesium, lead, pewter and tin-based alloys. Depending on the type of metal being cast, a hot- or cold-chamber machine is used.


The casting equipment and the metal dies represent large capital costs and this tends to limit the process to high-volume production. Manufacture of parts using die casting is relatively simple, involving only four main steps, which keeps the incremental cost per item low. It is especially suited for a large quantity of small- to medium-sized castings, which is why die casting produces more castings than any other casting process. Die castings are characterized by a very good surface finish (by casting standards) and dimensional consistency.

Two variants are pore-free die casting, which is used to eliminate gas porosity defects; and direct injection die casting, which is used with zinc castings to reduce scrap and increase yield.

### Equipment

There are two basic types of die casting machines: *hot-chamber machines* and *cold-chamber machines*. These are rated by how much clamping force they can apply. Typical ratings are between 400 and 4,000 st (2,500 and 25,400 kg).

### Hot-chamber die casting




Schematic of a hot-chamber machine

Hot-chamber die casting, also known as *gooseneck machines*, rely upon a pool of molten metal to feed the die. At the beginning of the cycle the piston of the machine is retracted, which allows the molten metal to fill the "gooseneck". The pneumatic- or hydraulic-powered piston then forces this metal out of the gooseneck into the die. The advantages of this system include fast cycle times (approximately 15 cycles a minute) and the convenience of melting the metal in the casting machine. The disadvantages of this system are that it is limited to use with low-melting point metals and that aluminium cannot be used because it picks up some of the iron while in the molten pool. Therefore, hot-chamber machines are primarily used with zinc-, tin-, and lead-based alloys.



## Cold-chamber die casting



A schematic of a cold-chamber die casting machine.

These are used when the casting alloy cannot be used in hot-chamber machines; these include aluminium, zinc alloys with a large composition of aluminium, magnesium and copper. The process for these machines start with melting the metal in a separate furnace.<sup>[14]</sup> Then a precise amount of molten metal is transported to the cold-chamber machine where it is fed into an unheated shot chamber (or injection cylinder). This shot is then driven into the die by a hydraulic or mechanical piston. The biggest disadvantage of this system is the slower cycle time due to the need to transfer the molten metal from the furnace to the cold-chamber machine.

### Advantages and disadvantages


Advantages of die casting:

- Excellent dimensional accuracy (dependent on casting material, but typically 0.1 mm for the first 2.5 cm (0.005 inch for the first inch) and 0.02 mm for each additional centimeter (0.002 inch for each additional inch).
- Smooth cast surfaces (Ra 1–2.5 micrometres or 0.04–0.10 thou rms).
- Thinner walls can be cast as compared to sand and permanent mold casting (approximately 0.75 mm or 0.030 in).
- Inserts can be cast-in (such as threaded inserts, heating elements, and high strength bearing surfaces).
- Reduces or eliminates secondary machining operations.
- Rapid production rates.
- Casting tensile strength as high as 415 megapascals (60 ksi).
- Casting of low fluidity metals.

The main disadvantage to die casting is the very high capital cost. Both the casting equipment required and the dies and related components are very costly, as compared to most other casting processes. Therefore, to make die casting an economic process, a large production volume is needed. Other disadvantages are that the process is limited to high-fluidity metals, and casting weights must be between 30 grams (1 oz) and 10 kg (20 lb). In the standard die casting process the final casting will have a small amount of porosity. This prevents any heat treating or welding, because the heat causes the gas in the pores to expand, which causes micro-cracks inside the part and exfoliation of the surface. Thus a related disadvantage of die casting is that it is only for parts in which softness is acceptable. Parts needing hardening (through hardening or case hardening) and tempering are not cast in dies.

## 2.2 Rotational Casting

**Rotational Molding (BrE moulding)** involves a heated hollow mold which is filled with a charge or shot weight of material. It is then slowly rotated (usually around two perpendicular axes), causing the softened material to disperse and stick to the walls of the mold. In order to maintain even thickness throughout the part, the mold continues to rotate at all times during the heating phase and to avoid sagging or deformation also during the cooling phase. The process was applied to plastics in the 1940s but in the early years was little used because it was a slow process restricted to a small number of plastics. Over the past two decades, improvements in process control and developments with plastic powders have resulted in a significant increase in usage.




Rotocasting (also known as rotacasting), by comparison, uses self-curing resins in an unheated mould, but shares slow rotational speeds in common with rotational molding. Spin casting should not be confused with either, utilizing self-curing resins or white metal in a high-speed centrifugal casting machine.

### **2.3 Film Casting**

Polymer solution casting is a technique that can replace film extrusion to deliver high-quality films with superior optical, mechanical and physical film properties.

In polymer solution casting, polymer is dissolved or dispersed in solution, coated onto a carrier substrate, and then the water or solvent is removed by drying to create a solid layer on the carrier. The resulting cast layer can be stripped from the carrier substrate to produce a standalone film. Before or after stripping, the cast film can be laminated with other webs or coated with other materials to create multi-layer products.



Manufacturing process advantages of polymer solution casting over traditional film extrusion methods include:

- Processing at low temperatures, which is valuable for thermally activated films or applications incorporating temperature-sensitive active ingredients.
- Ability to produce high-temperature resistant films from non-thermoplastic but soluble raw materials.
- Simplified incorporation of additives and fillers.
- Quicker changeovers for platforms with many part numbers that are differentiated based on formula.



- Single pass manufacturing of multi-layer films (g. the ability to cast a free film, then coat an adhesive and laminate release liner on one side, and coat a top coat on the other side).
- Wider range of material choices with casting from either aqueous or solvent-based solutions.

Advantages of the resulting film include:


- Greater film thickness uniformity, as tight as  $\pm 2\%$ .
- Wider range of film thickness, from 150 microns down to less than 12 microns.
- Films that are gel and pinhole free.
- Excellent flatness and dimensional stability.
- Isotropic orientation (mechanical and optical) as film is not stretched during manufacture.
- Absence of typical extrusion process lubricants.

### 3. Moulding

Moulding is one of the most relevant technology to form a plastic products. They are various types. Few of them are Given below


1. Injection molding
2. Extrusion
3. Blow Molding
4. Compression molding
5. Rotational molding

#### 3.1 Injection molding




Injection molding is a manufacturing process for producing parts by injecting material into a mold. The main method used for processing plastic is injection molding. With this process, the plastic is placed into a hopper. The hopper then feeds the plastic into a heated injection unit, where it is pushed through a long chamber with a reciprocating screw. Here, it is softened to a fluid state. A nozzle is located at the end of the chamber. The fluid plastic is forced through the nozzle into a cold, closed mold. The halves of the mold are held shut with a system of clamps. When the plastic is cooled and solidified, the halves open and the finished product is ejected from the press.

#### 3.2 Extrusion




Plastics extrusion is a high volume manufacturing process in which raw plastic material is melted and formed into a continuous profile. The process of extrusion is usually used to make products such as film, continuous sheeting, tubes, profile shapes, rods, coat wire, filaments, cords, and cables. As with injection molding, dry plastic material is placed into a hopper and fed into a long heating chamber. At the end of the chamber, however, the material is forced out of a small opening or a die in the shape of the desired finished product. As the plastic exits the die, it is placed on a conveyor belt where it is allowed to cool. Blowers are sometimes used to aid in this process, or the product may be immersed in water to help it cool.

### **3.3 Blow Molding**



Stretch Blow Molding process is mainly used when the plastic product that needs to be created should be hollow. A molten tube is created with blow molding by using compressed air, which blows up the tube and forces it to conform to the chilled mold. Variations of blow molding include injection, injection-stretch, and extrusion blow molding.

### **3.4 Compression molding**




Compression molding is the most common process used with thermosetting materials and is usually not used for thermoplastics. With this process, the material is squeezed into its desired shape with the help of pressure and heat. Plastic molding powder and other materials are added to the mix in order to create special qualities or to strengthen the final product. When the mold is closed and heated, the material goes through a chemical change that causes it to harden into its

desired shape. The amount temperature, amount of pressure, and length of time utilized during the process depends on the desired outcome.

### **3.5 Rotational molding**



Rotational molding is an extremely popular and well-used process for producing items that are usually hollow. The mold is closed and then spun both vertically and horizontally and moved into an oven. As the powder starts to melt and the mold continues rotating, it is flung onto the walls of the mold by centrifugal force where it forms a skin. After a fixed period, the mold is removed from the oven and allowed to cool carefully to avoid the product shoring.

## **4. Thermoforming**



Thermoforming is a manufacturing process where a plastic sheet is heated to a pliable forming temperature, formed to a specific part shape in a mold, and trimmed to create a usable product. The sheet, or film when referring to thinner gauges and certain material types, is heated in an oven to a high-enough temperature that it can be stretched into or onto a mold and cooled to a finished shape. The second animation shows the twin sheet thermoforming process whereby two individual components are fused together through the application of tremendous pressure which forces two molds together, thereby fusing the materials together.

### **4.1 Vacuum forming**



Vacuum forming is a simplified version of thermoforming, whereby a sheet of plastic is heated to a forming temperature, stretched onto a convex, or into a concave, single-surface mold, and forced against the mold by a vacuum (suction of air).

## 5. Polymeric Foams

The most of the polymeric foams are formed by a process involving nucleation and growth of gas bubbles in a polymer matrix, except in the syntactic foam where micro-beads of encapsulated gas are compounded into a polymer system or latex. According to the nucleation mechanism, the fundamental principle for the formation of polymeric foam involves three different important stages such as, bubble formation, bubble growth and bubble stability. The foam is expanded by increasing the bubble size before stabilizing the system. As the bubbles grow, the foam structure changes through number of stages.<sup>5</sup> These are the following characteristics observed during the formation of foam. *f*Initially, small dispersed spherical bubbles are produced in a liquid polymer matrix, with a small reduction in density. The further growth of cells leads to lower foam density, which involves distortion of cells to form polyhedral structures, sometimes idealized as pentagonal dodecahedrons. *f*Effects of viscosity and surface tension subsequently cause materials to flow towards the uniform cell formation. *f*Extensive rupture before the foam is stabilized may lead to foam collapse. Cooling of closed cell foam before stabilization may lead to shrinkage, because of the reduced pressure in cells. The foaming of polymeric materials can be carried out by mechanical, chemical, or physical methods.<sup>4</sup> Some of the most commonly used methods are; <sup>¾</sup>Thermal decomposition of a chemical blowing agent, generating either nitrogen or carbon dioxide or both, by application of heat or as a result of the exothermic reaction during polymerization. Chemical blowing agents are either inorganic materials such as carbonates, bicarbonates, borohydrides, etc., or organic materials such as, hydrazides, azides, and nitroso compounds, etc. Copyright IIT Kharagpur Chapter 1 <sup>¾</sup>Mechanical whipping (frothing) of gases into a fluid polymer system (melt, solution, or suspension), then it hardens either by catalytic action or heat or both, thus entrapping the gas bubbles in the polymeric matrix. <sup>¾</sup>Volatilization of low-boiling liquids (fluorocarbons or methylene chloride) within the polymer mass as a result of the exothermic reaction or by application of heat. <sup>¾</sup>Chemical blowing action via in-situ reaction during polymerization. (In this in-situ reaction water reacts with isocyanate to form carbon dioxide which is responsible for polyurethane foam formation). <sup>¾</sup>Expansion of dissolved gas in a polymer mass upon reduction of pressure in the system. <sup>¾</sup>Incorporation of tiny beads or microspheres into a polymer mass.



### **Application of Polymeric Foams**

Applications of polymeric foams depend on the nature of polymer and their types. For example, the main applications of flexible foams are for cushioning, packaging, automotive safety, footwear, etc.

## 6. Reinforcement

**Fibre-reinforced plastic (FRP)** (also called **fibre-reinforced polymer**, or **fiber-reinforced plastic**) is a composite material made of a polymer matrix reinforced with fibres. The fibres are usually glass (in fibreglass), carbon, aramid, or basalt. Rarely, other fibres such as paper, wood, or asbestos have been used. The polymer is usually an epoxy, vinylester, or polyester thermosetting plastic, though phenol formaldehyde resins are still in use. FRPs are commonly used in the aerospace, automotive, marine, and construction industries. They are commonly found in ballistic armor as well.



### Process definition

A polymer is generally manufactured by step-growth polymerization or addition polymerization. When combined with various agents to enhance or in any way alter the material properties of polymers the result is referred to as a plastic. Composite plastics refer to those types of plastics that result from bonding two or more homogeneous materials with different material properties to derive a final product with certain desired material and mechanical properties. Fibre-reinforced plastics are a category of composite plastics that specifically use fibre materials to mechanically enhance the strength and elasticity of plastics.

The original plastic material without fibre reinforcement is known as the matrix or binding agent. The matrix is a tough but relatively weak plastic that is reinforced by stronger stiffer reinforcing filaments or fibres. The extent that strength and elasticity are enhanced in a fibre-reinforced plastic depends on the mechanical properties of both the fibre and matrix, their volume relative to one another, and the fibre length and orientation within the matrix.<sup>[1]</sup> Reinforcement of the matrix occurs by definition when the FRP material exhibits increased strength or elasticity relative to the strength and elasticity of the matrix alone.

Reinforcing Fibre is manufactured in both two-dimensional and three-dimensional orientations:

1. Two-dimensional fibreglass-reinforced polymer is characterized by a laminated structure in which the fibers are only aligned along the plane in x-direction, and y-direction of the material. This means that no fibers are aligned in the through-thickness or the z-direction, this lack of alignment in the through thickness can create a disadvantage in cost and processing. Costs and labor increase because conventional processing techniques used to fabricate composites, such as wet hand lay-up, autoclave and resin transfer molding, require a high amount of skilled labor to cut, stack and consolidate into a preformed component.
2. Three-dimensional fiberglass-reinforced polymer composites are materials with three-dimensional fiber structures that incorporate fibers in the x-direction, y-direction and z-direction. The development of three-dimensional orientations arose from industry's need to reduce fabrication costs, to increase through-thickness mechanical properties, and to improve impact damage tolerance; all were problems associated with two-dimensional fibre-reinforced polymers.



## **Material requirements**

A thermoset polymer matrix material, or engineering grade thermoplastic polymer matrix material, must meet certain requirements in order to first be suitable for FRPs and ensure a successful reinforcement of itself. The matrix must be able to properly saturate, and preferably bond chemically with the fibre reinforcement for maximum adhesion within a suitable curing period. The matrix must also completely envelop the fibres to protect them from cuts and notches that would reduce their strength, and to transfer forces to the fibres. The fibres must also be kept separate from each other so that if failure occurs it is localized as much as possible, and if failure occurs the matrix must also debond from the fibre for similar reasons. Finally the matrix should be of a plastic that remains chemically and physically stable during and after the reinforcement and moulding processes. To be suitable as reinforcement material, fibre additives must increase the tensile strength and modulus of elasticity of the matrix and meet the following conditions; fibres must exceed critical fibre content; the strength and rigidity of fibres itself must exceed the strength and rigidity of the matrix alone; and there must be optimum bonding between fibres and matrix

### **Glass fibre**

"Fibreglass reinforced plastics" or FRPs (commonly referred to simply as fibreglass) use textile grade glass fibres. These textile fibres are different from other forms of glass fibres used to deliberately trap air, for insulating applications (see glass wool). Textile glass fibres begin as varying combinations of  $\text{SiO}_2$ ,  $\text{Al}_2\text{O}_3$ ,  $\text{B}_2\text{O}_3$ ,  $\text{CaO}$ , or  $\text{MgO}$  in powder form. These mixtures are then heated through direct melting to temperatures around 1300 degrees Celsius, after which dies are used to extrude filaments of glass fibre in diameter ranging from 9 to 17  $\mu\text{m}$ . These filaments are then wound into larger threads and spun onto bobbins for transportation and further processing. Glass fibre is by far the most popular means to reinforce plastic and thus enjoys a wealth of production processes, some of which are applicable to aramid and carbon fibres as well owing to their shared fibrous qualities.

Roving is a process where filaments are spun into larger diameter threads. These threads are then commonly used for woven reinforcing glass fabrics and mats, and in spray applications.

Fibre fabrics are web-form fabric reinforcing material that has both warp and weft directions. Fibre mats are web-form non-woven mats of glass fibres. Mats are manufactured in cut dimensions with chopped fibres, or in continuous mats using continuous fibres. Chopped fibre glass is used in processes where lengths of glass threads are cut between 3 and 26 mm, threads are then used in plastics most commonly intended for moulding processes. Glass fibre short strands are short 0.2–0.3 mm strands of glass fibres that are used to reinforce thermoplastics most commonly for injection moulding.

### **Carbon fibre**

Carbon fibres are created when polyacrylonitrile fibres (PAN), Pitch resins, or Rayon are carbonized (through oxidation and thermal pyrolysis) at high temperatures. Through further processes of graphitizing or stretching the fibres strength or elasticity can be enhanced respectively. Carbon fibres are manufactured in diameters analogous to glass fibres with diameters ranging from 4 to 17  $\mu\text{m}$ . These fibres wound into larger threads for transportation and further production processes. Further production processes include weaving or braiding into carbon fabrics, cloths and mats analogous to those described for glass that can then be used in actual reinforcements.

### **Aramid fibre**

Aramid fibres are most commonly known as Kevlar, Nomex and Technora. Aramids are generally prepared by the reaction between an amine group and a carboxylic acid halide group (aramid);<sup>[1]</sup> commonly this occurs when an aromatic polyamide is spun from a liquid

concentration of sulphuric acid into a crystallized fibre. Fibres are then spun into larger threads in order to weave into large ropes or woven fabrics (Aramid). Aramid fibres are manufactured with varying grades to based on varying qualities for strength and rigidity, so that the material can be somewhat tailored to specific design needs concerns, such as cutting the tough material during manufacture.

### **Advantages and limitations**

FRP allows the alignment of the glass fibres of thermoplastics to suit specific design programs. Specifying the orientation of reinforcing fibres can increase the strength and resistance to deformation of the polymer. Glass reinforced polymers are strongest and most resistive to deforming forces when the polymers fibres are parallel to the force being exerted, and are weakest when the fibres are perpendicular. Thus this ability is at once both an advantage or a limitation depending on the context of use. Weak spots of perpendicular fibres can be used for natural hinges and connections, but can also lead to material failure when production processes fail to properly orient the fibres parallel to expected forces. When forces are exerted perpendicular to the orientation of fibres the strength and elasticity of the polymer is less than the matrix alone. In cast resin components made of glass reinforced polymers such as UP and EP, the orientation of fibres can be oriented in two-dimensional and three-dimensional weaves. This means that when forces are possibly perpendicular to one orientation, they are parallel to another orientation; this eliminates the potential for weak spots in the polymer.

## **7. Fiber Spinning**

Fiber spinning is used to make synthetic fibers for use in many industries. There are three main types of fiber spinning methods: melt, solution, and reaction spinning. In fiber spinning a liquid polymer is extruded through small holes in a spinneret to form thin filaments, as shown below. Upon leaving the spinneret the filaments solidify. After solidification, filaments can be combined to make threads and/or drawn to change the filaments' properties.

The processes governing the three types of fiber spinning differ mainly in the way the polymer is liquefied and solidified.



### **Melt Spinning**

#### **General Information**


Melt spinning is the most widely used form of fiber spinning. In melt spinning either molten polymer is used or polymer pellets are melted down. Once the filaments are extruded they are cooled in a fluid medium such as air, gas, or even water.

#### **Equipment Design**

In melt spinning, as shown below, the molten or melted polymer is pushed vertically downwards through the spinneret. When the filaments emerge from the spinneret they are cooled by a gas,



usually air, which flows either perpendicularly across, cocurrently , or countercurrently to the filaments.



The filaments can then be brought together and/or twisted together to form a thread. Before winding the thread on the bobbin, it is often treated with water or a wetting agent and then a lubricant . Later, the wound thread may be dyed and drawn on other machines.

Spinneret design , such as those shown below, is dependent on the type of spinning and desired cross sectional shape of the filament. The cross sectional shape determines different features the filament will exhibit, such as how it will reflect light, the ability to insulate, and how easily it shows dirt.



Spin plates and spinnerets may have as many as 80,000 bores spaced less than one millimeter apart. Some spinnerets have superfine capillaries 50 micrometers in diameter. These tiny bores and capillaries are very sensitive to impurities and corrosion; this is one reason why spinnerets are often made of high-grade steel or other metals that can be easily cleaned.

### Usage Examples

Some common fibers produced using melt spinning are: polypropylene, polyester, and nylon which is shown below and to the right. Nylon was the world's first synthetic fiber discovered and was initially used for tooth brush bristles before being used to produce women's stockings during the 1940's.



### Advantages and Disadvantages


- Ability to run at high line speeds.
- Requires no solvent that must be recovered later.
- Necessary high temperatures may damage some polymers.

### Solution Spinning

Solution spinning is used when the desired polymer does not form a stable melt. These polymers are dissolved in a solution to liquefy them rather than melting them. The two main types of solution spinning are dry and wet spinning.

#### Dry Spinning


In dry spinning the polymer is dissolved in a volatile solvent. Once dissolved, the polymer solution is extruded through the spinneret which is in an enclosed drying tower. The solution goes through a drying process in this tower, where the solvent is evaporated.



### Equipment Design

The spinning solution is often filtered many times to remove foreign materials that might cause thread defects or clogging in the machine. The solution is extruded into the drying tower through which hot air or other gases pass. The concentration of the polymer increases as the solvent evaporates, leaving a solid polymer filament behind. The solvent is later recovered from the gas by condensation or absorption and is then recycled.

Solvent selection is very important, and is based on boiling point, latent heat of vaporization, thermal stability, toxicity, and inertness. Non-polar solvents are often preferred because of their low boiling points and heats of vaporization. However, non-polar solvents are prone to build-ups of electrostatic charge, which can be very dangerous.




### Advantages and Disadvantages

- Better than melt spinning for temperature-sensitive polymers.
- Faster production rates than melt and wet spinning.
- Solvent recovery is costly.

### Wet Spinning


In wet spinning the polymer is dissolved in a non-volatile solvent. The spinneret is located in a coagulating bath that causes the fiber to precipitate out.



### Equipment Design

The liquid in the coagulating bath is chosen so that the solvent is readily soluble in the liquid but the polymer is not. This will cause the polymer to precipitate out and form the desired solid filaments. The solvent can later be recovered by treating the wastewater in the bath.

The drag on the filament by the viscous liquid in the coagulating bath significantly reduces the production speed of the process. This makes wet spinning a slower process than melt or dry spinning.



### Advantages and Disadvantages

- Better than melt and dry spinning for temperature sensitive polymers.
- Lower production rates than melt or dry spinning due to viscous drag.
- Solvent recovery is costly.

### Usage Examples

The synthetic fibers produced by solution spinning are made into threads which are woven into fabric for everything from clothes and carpets to airbags and windsails. In addition, sterilized synthetic fibers are used in the medical industry as sutures, dressings, and operating room drapes, face masks, caps and overshoes. Many synthetic fibers can be cut into tiny pieces called flock. Flock is used to make velvet or suede-like materials or added to plastics or papers for a decorative finish.



### Text book:

**T1:** Gowariker, V. R., N. V. Viswanathan and J. Sreedhar, 1986. Polymer Science, *New Age International Private Ltd.*, New Delhi.

**T2:** Billmeyer, F.W., 2003. Text Book of Polymer Science. III Edition, John Wiley, New York.

### Reference book

**R1:** M.S Bhatnagar, 2004, “ A text book of polymers”. I<sup>st</sup> Edition, S.Chand & Company.

## POSSIBLE QUESTIONS

### Multiple Choice Questions (Each Carry 1 Mark)

1. Which one of the following is obtained from acetaldehyde and hydrogen cyanide.  
**a. Acrylonitrile monomer**    b. Polyamide    c. Polyester    d. Polyethylene terephthalate
2. Wet spinning technique is commercially used to produce filament yarn of  
a. Polypropylene    b. Polyester    c. Nylon 66    **d. Acrylic**
3. Too high resistivity leads to the development of static?  
a. Mechanical charges    b. Positive charges    c. Negative charges    **d. Electrical charges**
4. Which properties of fibers are quite complex and have been subject of much experimental work?  
a. Physical    **b. Mechanical**    c. Chemical    d. Thermal

5. In which spinning, the polymer solution is forced through a spinneret?  
a. Melt spinning    **b. Dry spinning**    c. Wet spinning    d. Spinning
6. Birefringence of filament yarn is related to its  
Density    b. Filament denier    **c. Orientation**    d. Crystallinity
7. In melt spinning the temperature used for melting is about ?  
29K    **b. 30K**    c. 31K    d. 32K
8. Which one of the following is the most important fibers produced commercially?  
**Nylons**    b. Wood    c. Cotton    d. Silk
9. In which spinning, the polymer is melted by heating and then passed through a spinneret via  
**Melt spinning**    b. Dry spinning    c. Wet spinning    d. Spinning
10. Which one of the following is used for self-lubricating gears and bearings?  
**Nylons**    b. Wood    c. Cotton    d. Silk
11. Crease resist finishing of cotton fabric does not lead to  
Reduction in tensile strength    b. Increase in dimensional stability  
**c. Increase in moisture regain**    d. Increase in bending length
12. Which property causes the fabric to cling unpleasantly and to be difficult to clean?  
a. Mechanical    **b. Electrical**    c. Chemical    d. Thermal
13. In general, which is a difficult dye?  
a. Polyamide    b. Polyester    **c. Hydrophobic fiber**    d. Acrylic fibre
14. In which spinning, Polymer solutions are converted into fibers by diluting a highly concentrated polymer solution in a coagulating bath?  
a. Melt spinning    b. Dry spinning    **c. Wet spinning**    d. Spinning
15. Which is soluble only in specific solvents?  
a. Fibres    **b. Polymers**    c. Nylon    d. Hydrophobic fibres
16. The PBNA is the standard  
**a. anti-oxidant**    b. anti-toxin    c. anti-malarial    d. anti-poisonous
17. Which one of the following is used as the staining anti-oxidant  
a. DPPD    **b. PBNA**    c. TCS    d. TMS
18. TCS is the example of the  
a. Standard anti-oxidant    b. non standard anti-oxidant    c. staining anti-oxidant  
**d. non-staining anti oxidant**
19. The rayon also known as  
a. nylon    b. orelon    **c. viscose**    d. resin
20. The rayon polymers belongs to the  
**a. silicon polymers**    b. epoxy polymers    c. organic polymer    d. rubber

**6 Marks**

**(Each Carry 6 Marks)**

1. What is calendaring technique? explain it briefly?
2. Write a note on moulding techniques?
3. What are the thermoforming techniques?
4. How to produce the hollow and film products of polymers under casting technique?
5. Write a note on foaming techniques?
6. Write a note on reinforcing?
7. What is the compounding technique of polymer and fiber?
8. Write a note on injection and blow moulding?
9. What is moulding? Explain extrusion moulding in the preparation of polymers?

10. How to prepare the fiber by spinning method?

**Compulsory Questions    (Each Carry 10 Marks)**

1. Give an account of fiber spinning technique?
2. Briefly explain the reinforcing technique?
3. What is moulding? Explain the four types of moulding?



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

	Questions	Opt-1	Opt-2	Opt-3	Opt-4	Answers
1	The fibre that contains nitrogen and sulfur is ?	Polyester	Wool	Nylon	Kevlar	Wool
2	It is the class of a hair like materials that are continues filaments.	Fibre	Rubber	Wood	Glass	Fibre
3	Polyacrylonitrile (PAN), also known as ?	Polyvinyl cyanide	Cyanide	Polyester	Polyethylene terephthalate	Polyvinyl cyanide
4	Which one of the following is produced by ammonidation of propylene.	Acrylonitrile monomer	Polyamide	Polyester	Polyethylene terephthalate	Acrylonitrile monomer
5	Which one of the following is obtained from acetaldehyde and hydrogen cyanide.	Acrylonitrile monomer	Polyamide	Polyester	Polyethylene terephthalate	Acrylonitrile monomer
6	Wet spinning technique is commercially used to produce filament yarn of	Polypropylene	Polyester	Nylon 66	Acrylic	Acrylic
7	Too high resistivity leads to the development of static ?	Mechanical charges	Positive charges	Negative charges	Electrical charges	Electrical charges
8	Which properties of fibres are quite complex and have	Physical	Mechanical	Chemical	Thermal	Mechanical



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

	been subject of much experimental work?					
9	The tenacity at break of typical fibres ranges from about 1 g/denier for ?	Synthetic	Natural	Rayons	Carbon fibres	Rayons
10	Which one of the following is the least satisfactory fibres from the standpoint of weather ability?	Silk	Cotton	Glass	Wood	Silk
11	Natural fibers are consisting of ?	Linear polymers	Nonlinear polymers	Copolymers	Chain polymers	Linear polymers
12	The fibre that dissolves in 59% (w/w) sulfuric acid solution is	Nylon	Viscose	Cotton	Silk	Viscose
13	Polyacrylonitrile is soluble in which solvent?	Dimethylformamide (DMF)	Methanol	Water	Acetone	Dimethylformamide (DMF)
14	In which spinning, the polymer solution is forced through a spinneret?	Melt spinning	Dry spinning	Wet spinning	Spinning	Dry spinning
15	In which spinning, the polymer is melted by heating and then passed through a spinneret via	Melt spinning	Dry spinning	Wet spinning	Spinning	Melt spinning
16	Birefringence of filament yarn is related to its	Density	Filament denier	Orientation	Crystallinity	Orientation

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

17	In melt spinning the temperature used for melting is about ?	29K	30K	31K	32K	30K
18	Which one of the following is the most important fibers produced commercially?	Nylons	Wood	Cotton	Silk	Nylons
19	Which one of the following is used for self-lubricating gears and bearings?	Nylons	Wood	Cotton	Silk	Nylons
20	Why does nylon make such good fibers?	Intramolecular forces	Low Molecular weight	Intermolecular forces	High Molecular weight	Intermolecular forces
21	During bleaching of cotton with H <sub>2</sub> O <sub>2</sub> , the stabilizer used is ?	Sodium hydroxide	Sodium silicate	Acetic acid	Sodium carbonate	Sodium silicate
22	The highest washing fastness in a dyed cotton fabric would be obtained if the dye-fibre bond is	Ionic	Hydrogen	Covalent	Van derWaal's force	Covalent
23	The melt index, is generally used to characterize which properties of polymers?	Electrical	Chemical	Mechanical	Melting	Melting
24	Crease resist finishing of cotton fabric does not lead to	Reduction in tensile strength	Increase in dimensional stability	Increase in moisture regain	Increase in bending length	Increase in moisture regain
25	Which property cause the fabric to cling unpleasantly and to be difficult to clean?	Mechanical	Electrical	Chemical	Thermal	Electrical

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

26	In general, which is difficult to dye ?	Polyamide	Polyester	Hydrophobic fibre	Acrylic fibre	Hydrophobic fibre
27	In which spinning, Polymer solutions are converted into fibers by diluting a highly concentrated polymer solution in a coagulating bath?	Melt spinning	Dry spinning	Wet spinning	Spinning	Wet spinning
28	Which is soluble only in specific solvents?	Fibres	Polymers	Nylon	Hydrophobic fibres	Polymers
29	Cellulose acetate, polyacrylonitrile, and polyurethane are spun by this technique?	Melt spinning	Dry spinning	Wet spinning	Spinning	Dry spinning
30	Nylon ends in?	Building	Ropes	Chair	Watch	Ropes
31	Which one of the following is a polyamide?	Terylene	Nylon 6	Cotton	Watch	Nylon 6
32	Synthetic fibers are consisting of ?	Linear polymers	Nonlinear polymers	Copolymers	Chain polymers	Linear polymers
33	The alkyd resins are condensation polymers obtained from dibasic acids and	Glycol	Phenol	Acetaldehyde	Benzaldehyde	Phenol

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

34	Nylon threads are made of	Polyester polymer	Polyamide polymer	Polyvinyl chloride	Acrylic polymer	Polyamide polymer
35	Acrylic resins are	Brown colour	Colourless	Gold colour	White colour	Colourless
36	Which one of the following can be polymerised to polythene	Ethylene	Ethyl amide	Ethyl ketone	Ethyl acetate	Ethylene
37	Hydrolysis of cellulose gives	D-glucose	L- glucose	D-fructose	L-fructose	D-glucose
38	Orlon is a polymer of	Polyamide	Polyester	Hydrophobic fibre	Acrylic fibre	Acrylic fibre
39	Condensation product of caprolactum is	Nylon 6	Cotton	Nylon 6,10	Nylon 66	Nylon 6
40	Nylon is a example of	condensation polymer	copolymer	coordination polymer	chain polymer	condensation polymer
41	The DPPD is the	Diphenyl phenylene diamine	Diphenyl phenylene diamide	Diphenyl phospho diamine	Diphenyl phospho diamine	Diphenyl phenylene diamine
42	PBNA is the	phenyl $\alpha$ naphthyl amine	phenyl $p$ naphthalene amide	phenyl $\beta$ naphthyl amine	phenyl $\gamma$ naphthyl amine	phenyl $\beta$ naphthyl amine

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

43	The PBNA is the standard	anti-oxidant	anti-toxin	anti-malarial	anti-poisonous	anti-oxidant
44	Which one of the following is used as the staining anti-oxidant	DPPD	PBNA	TCS	TMS	PBNA
45	TCS is the example of the	Standard anti-oxidant	non standard anti-oxidant	staining anti-oxidant	non-staining anti oxidant	non-staining anti oxidant
46	The rayon also known as	nylon	orelon	viscose	resin	viscose
47	The rayon polymers belongs to the	silicon polymers	epoxy polymers	organic polymer	rubber	silicon polymers
48	Which one of the following should give the strength to the paper	urea-formaldehyde	phenol-formaldehyde	polysulphides	polychloroprene	urea-formaldehyde
49	Which one of the following is used as a core binders	urea-formaldehyde	phenol-formaldehyde	polysulphides	polychloroprene	phenol-formaldehyde
50	Which one of the following is used as fuel material	urea-formaldehyde	phenol-formaldehyde	polysulphides	polychloroprene	polysulphides
51	which one of the following is used to coating the wires and cables	urea-formaldehyde	phenol-formaldehyde	polysulphides	polychloroprene	polychloroprene

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: IV (POLYMER PROCESSING) BATCH-2017-2019

52	Which one of the following is used as the insulation material in electrical industry	urea-formaldehyde	phenol-formaldehyde	polybutadiene	polysulphides	polybutadiene
53	Which one of the following is considered as a life saving substance	urea-formaldehyde	phenol-formaldehyde	polybutadiene	polyvinyl pyrrolidine	polyvinyl pyrrolidine
54	Which one of the following is used in the paints and surface coatings	polybutadiene	polysulphides	polyvinyl pyrrolidine	polyvinyl fluoride	polyvinyl fluoride
55	Which one of the following is used to form the thermoplastic material	polyvinylidene chloride	PVC	polybutadiene	polysulphides	polyvinylidene chloride
56	Which one of the following is the liquid resins	PPG	PVC	PEG	PABA	PPG
57	PEG also known as	alcowax	carbowax	hydrowax	rubber	carbowax
58	Which one of the following is used as the surface coating in the supersonic aircraft	polyamines	polyamides	polyimides	polyvinyls	polyimides
59	Which one of the following is used to making the toys	HDPE	LDPE	PPG	PEG	HDPE
60	Nylon is not a ?	Homo polymer	Polyamide	Caprolactum	Condensation polymer	Homo polymer

## **UNIT – V** **SYLLABUS**

Polyethylene, polyvinyl chloride, polyamides, polyesters, phenolic resins, epoxy resins and silicone polymers. Functional polymers, Fire retarding polymers and electrically conducting polymers. Biomedical polymers – contact lens, dental polymers, artificial heart, kidney, skin and blood cells.

### **Commercial Polymers**

**Synthetic polymers** are human-made polymers. From the utility point of view they can be classified into four main categories: thermoplastics, thermosets, elastomers and synthetic fibers. They are found commonly in a variety of consumer products such as money, super glue, etc.

A wide variety of synthetic polymers are available with variations in main chain as well as side chains. The back bones of common synthetic polymers such as polythene, polystyrene and polyacrylates are made up of carbon-carbon bonds, whereas hetero chain polymers such as polyamides, polyesters, polyurethanes, polysulfides and polycarbonates have other elements (e.g. oxygen, sulfur, nitrogen) inserted along the backbone. Also silicon forms similar materials without the need of carbon atoms, such as silicones through siloxane linkages; these compounds are thus said to be inorganic polymers. Coordination polymers may contain a range of metals in the backbone, with non-covalent bonding present.

Some familiar household synthetic polymers include: Nylons in textiles and fabrics, Teflon in non-stick pans, Bakelite for electrical switches, polyvinyl chloride (PVC) in pipes, etc. The common PET bottles are made of a synthetic polymer, polyethylene terephthalate. The plastic kits and covers are mostly made of synthetic polymers like polythene and tires are manufactured from Buna rubbers.<sup>[1]</sup> However, due to the environmental issues created by these synthetic polymers which are mostly non-biodegradable and often synthesized from petroleum, alternatives like bioplastics are also being considered. They are however expensive when compared to the synthetic polymers.

#### **1. Polyethylene**

**Polyethylene** or **polythene** (abbreviated **PE**; IUPAC name **polyethene** or **poly(ethylene)**) is the most common plastic. The annual global production is around 80 million tonnes. Its primary use is in packaging (plastic bags, plastic films, geomembranes, containers including bottles, etc.). Many kinds of polyethylene are known, with most having the chemical formula  $(C_2H_4)_n$ . PE is usually a mixture of similar polymers of ethylene with various values of  $n$ .

### **Properties**

The properties of polyethylene can be divided into mechanical, chemical, electrical, optical, and thermal properties.



**Mechanical properties**

Polyethylene is of low strength, hardness and rigidity, but has a high ductility and impact strength as well as low friction. It shows strong creep under persistent force, which can be reduced by addition of short fibers. It feels waxy when touched.

**Thermal properties**

The usefulness of polyethylene is limited by its melting point of 80 °C (176 °F) (HDPE, types of low crystalline softens earlier). For common commercial grades of medium- and high-density polyethylene the melting point is typically in the range 120 to 180 °C (248 to 356 °F). The melting point for average, commercial, low-density polyethylene is typically 105 to 115 °C (221 to 239 °F). These temperatures vary strongly with the type of polyethylene.

**Chemical properties**

Polyethylene consists of nonpolar, saturated, high molecular weight hydrocarbons. Therefore, its chemical behavior is similar to paraffin. The individual macromolecules are not covalently linked. Because of their symmetric molecular structure, they tend to crystallize; overall polyethylene is partially crystalline. Higher crystallinity increases density and mechanical and chemical stability. Most LDPE, MDPE, and HDPE grades have excellent chemical resistance, meaning they are not attacked by strong acids or strong bases, and are resistant to gentle oxidants and reducing agents. Crystalline samples do not dissolve at room temperature. Polyethylene (other than cross-linked polyethylene) usually can be dissolved at elevated temperatures in aromatic hydrocarbons such as toluene or xylene, or in chlorinated solvents such as trichloroethane or trichlorobenzene. Polyethylene absorbs almost no water. The gas and water vapor permeability (only polar gases) is lower than for most plastics; oxygen, carbon dioxide and flavorings on the other hand can pass it easily.

PE can become brittle when exposed to sunlight, carbon black is usually used as a UV stabilizer. Polyethylene burns slowly with a blue flame having a yellow tip and gives off an odour of paraffin (similar to candle flame). The material continues burning on removal of the flame source and produces a drip.

Polyethylene cannot be imprinted or stuck together without pretreatment.

**Electrical properties**

Polyethylene is a good electrical insulator. It offers good tracking resistance; however, it becomes easily electrostatically charged (which can be reduced by additions of graphite, carbon black or antistatic agents).

**Optical properties**

Depending on thermal history and film thickness PE can vary between almost clear (transparent), milky-opaque (translucent) or opaque. LDPE thereby owns the greatest, LLDPE slightly less and HDPE the least transparency. Transparency is reduced by crystallites if they are larger than the wavelength of visible light

### ***High-density polyethylene (HDPE)***



HDPE is defined by a density of greater or equal to  $0.941 \text{ g/cm}^3$ . HDPE has a low degree of branching. The mostly linear molecules pack together well, so intermolecular forces are stronger than in highly branched polymers. HDPE can be produced by chromium/silica catalysts, ZieglerNatta catalysts or metallocene catalysts; by choosing catalysts and reaction conditions, the small amount of branching that does occur can be controlled. These catalysts prefer the formation of free radicals at the ends of the growing polyethylene molecules. They cause new ethylene monomers to add to the ends of the molecules, rather than along the middle, causing the growth of a linear chain.

HDPE has high tensile strength. It is used in products and packaging such as milk jugs, detergent bottles, butter tubs, garbage containers, and water pipes. One-third of all toys are manufactured from HDPE. In 2007, the global HDPE consumption reached a volume of more than 30 million tons.

### ***Low-density polyethylene (LDPE)***

LDPE is defined by a density range of  $0.910\text{--}0.940 \text{ g/cm}^3$ . LDPE has a high degree of short- and long-chain branching, which means that the chains do not pack into the crystal structure as well. It has, therefore, less strong intermolecular forces as the instantaneous-dipole induced-dipole attraction is less. This results in a lower tensile strength and increased ductility. LDPE is created by free-radical polymerization. The high degree of branching with long chains gives molten LDPE unique and desirable flow properties. LDPE is used for both rigid containers and plastic film applications such as plastic bags and film wrap. In 2013, the global LDPE market had a volume of almost US\$33 billion.

The radical polymerization process used to make LDPE does not include a catalyst that "supervises" the radical sites on the growing PE chains. (In HDPE synthesis, the radical sites are at the ends of the PE chains, because the catalyst stabilizes their formation at the ends.) Secondary radicals (in the middle of a chain) are more stable than primary radicals (at the end of the chain), and tertiary radicals (at a branch point) are more stable yet. Each time an ethylene monomer is added, it creates a primary radical, but often these will rearrange to form more stable secondary or tertiary radicals. Addition of ethylene monomers to the secondary or tertiary sites creates branching.

### ***Production***

Production of LDPE by addition polymerization requires:

- temperature range of 100-300°C
- very high pressure 1500-3000 atmospheres
- oxygen or an organic peroxide such as dibutyl peroxide, benzoyl peroxide or diethyl peroxide as initiator.

An initiator is a substance which is added in small quantities and is decomposed by light or heat to produce a free radical (R·). A free radical is formed when a covalent bond is broken and a bonding electron is left on each part of the broken molecule. Since the O-O covalent bond is weak, free radicals are easily formed from oxygen or peroxides.

- benzene or chlorobenzene used as the solvent since both polymer (polythene) and monomer (ethene) dissolve in these compounds at the temperature and pressure used. Water or other liquids may be added to dissipate the heat of reaction as the polymerization reaction is highly exothermic.



Process continues to form polythene (polyethylene)  $[-\text{CH}_2-\text{CH}_2-]_n$

## Production of HDPE


1. Production of HDPE by addition polymerization with a supported metal oxide catalyst requires:
  - temperature ~300°C
  - 1 atmosphere pressure (101.3kPa)
  - aluminium-based metal oxide catalyst (metallocene catalyst)

The catalyst can be used in a variety of operating modes including fixed-bed, moving-bed, fluid-bed or slurry processes

- The ethene (ethylene) monomer is fed with a paraffin or cycloparaffin diluent (diluting agent). After polymerization the polymer (polythene) is recovered by cooling or by solvent evaporation.
2. Production of HDPE by coordination polymerization requires:
    - temperature 50-75°C
    - slight pressure
    - Coordination catalyst is prepared as a colloidal suspension by reacting an aluminium alkyl and titanium chloride (TiCl<sub>4</sub>) in a solvent such as heptane (C<sub>7</sub>H<sub>16</sub>).
    - The polymer (polythene) forms as a powder or granules which are insoluble in the reaction mixture. When the polymerization is completed, the catalyst is destroyed by adding water or alcohol to the reaction mixture. The polymer (polythene) is then filtered or centrifuged off, washed and dried.

## 2. Polyvinyl chloride

## Polyvinyl chloride



**Polyvinyl chloride** (/ˌpɒlɪvɪnəl ˈklɔːraɪd/), also known as poly vinyl or **vinyl**, commonly abbreviated **PVC**, is the world's third-most widely produced synthetic plastic polymer, after polyethylene and polypropylene.


PVC comes in two basic forms: rigid (sometimes abbreviated as RPVC) and flexible. The rigid form of PVC is used in construction for pipe and in profile applications such as doors and windows. It is also used for bottles, other non-food packaging, and cards (such as bank or membership cards). It can be made softer and more flexible by the addition of plasticizers, the most widely used being phthalates. In this form, it is also used in plumbing, electrical cable insulation, imitation leather, signage, phonograph records, inflatable products, and many applications where it replaces rubber. Pure polyvinyl chloride is a white, brittle solid. It is insoluble in alcohol but slightly soluble in tetrahydrofuran.

### Discovery

PVC was accidentally synthesized in 1872 by German chemist Eugen Baumann. The polymer appeared as a white solid inside a flask of vinyl chloride that had been left exposed to sunlight. In the early 20th century the Russian chemist Ivan Ostromislensky and Fritz Klatte of the German chemical company Griesheim-Elektron both attempted to use PVC in commercial products, but difficulties in processing the rigid, sometimes brittle polymer thwarted their efforts. Waldo Semon and the B.F. Goodrich Company developed a method in 1926 to plasticize PVC by blending it with various additives. The result was a more flexible and more easily processed material that soon achieved widespread commercial use.

### Production

Polyvinyl chloride is produced by polymerization of the vinyl chloride monomer (VCM), as shown.



About 80% of production involves suspension polymerization. Emulsion polymerization accounts for about 12%, and bulk polymerization accounts for 8%. Suspension polymerization affords particles with average diameters of 100–180  $\mu\text{m}$ , whereas emulsion polymerization gives much smaller particles of average size around 0.2  $\mu\text{m}$ . VCM and water are introduced into the reactor along with a polymerization initiator and other additives. The contents of the reaction vessel are pressurized and continually mixed to maintain the suspension and ensure a uniform particle size of the PVC resin. The reaction is exothermic and thus requires cooling. As the volume is reduced

during the reaction (PVC is denser than VCM), water is continually added to the mixture to maintain the suspension.

The polymerization of VCM is started by compounds called initiators that are mixed into the droplets. These compounds break down to start the radical chain reaction. Typical initiators include dioctanoyl peroxide and dicetyl peroxydicarbonate, both of which have fragile O-O bonds. Some initiators start the reaction rapidly but decay quickly, and other initiators have the opposite effect. A combination of two different initiators is often used to give a uniform rate of polymerization. After the polymer has grown by about 10 times, the short polymer precipitates inside the droplet of VCM, and polymerization continues with the precipitated, solvent-swollen particles. The weight average molecular weights of commercial polymers range from 100,000 to 200,000, and the number average molecular weights range from 45,000 to 64,000.

Once the reaction has run its course, the resulting PVC slurry is degassed and stripped to remove excess VCM, which is recycled. The polymer is then passed through a centrifuge to remove water. The slurry is further dried in a hot air bed, and the resulting powder is sieved before storage or pelletization. Normally, the resulting PVC has a VCM content of less than 1 part per million. Other production processes, such as micro-suspension polymerization and emulsion polymerization, produce PVC with smaller particle sizes (10  $\mu\text{m}$  vs. 120–150  $\mu\text{m}$  for suspension PVC) with slightly different properties and with somewhat different sets of applications.

#### Properties

PVC is a thermoplastic polymer. Its properties are usually categorized based on rigid and flexible PVCs.

Density [ $\text{g}/\text{cm}^3$ ]	1.3–1.45	1.1–1.35
Thermal conductivity [ $\text{W}/(\text{m}\cdot\text{K})$ ]	0.14–0.28	0.14–0.17
Yield strength [psi]	4500–8700	1450–3600
Young's modulus [psi]	490,000	
Flexural strength (yield) [psi]	10,500	
Compression strength [psi]	9500	
Coefficient of thermal expansion (linear) [ $\text{mm}/(\text{mm}\ ^\circ\text{C})$ ]	$5\times 10^{-5}$	
Vicat B [ $^\circ\text{C}$ ]	65–100	Not recommended
Resistivity [ $\Omega\ \text{m}$ ]	$10^{16}$	$10^{12}$ – $10^{15}$
Surface resistivity [ $\Omega$ ]	$10^{13}$ – $10^{14}$	$10^{11}$ – $10^{12}$

#### Mechanical

PVC has high hardness and mechanical properties. The mechanical properties enhance with the molecular weight increasing but decrease with the temperature increasing. The mechanical properties of rigid PVC (uPVC) are very good; the elastic modulus can reach 1500–3,000 MPa. The soft PVC (flexible PVC) elastic is 1.5–15 MPa.

#### Thermal and fire

The heat stability of raw PVC is very poor, so the addition of a heat stabilizer during the process is necessary in order to ensure the product's properties. PVC starts to decompose when the temperature reaches 140  $^\circ\text{C}$  (284  $^\circ\text{F}$ ), with melting temperature starting around 160  $^\circ\text{C}$  (320  $^\circ\text{F}$ ). The linear expansion coefficient of rigid PVC is small and has good flame retardancy, the Limiting oxygen index (LOI) being up to 45 or more. The LOI is the minimum concentration of oxygen, expressed as a percentage, that will support combustion of a polymer and noting that air has 20% content of oxygen.



## Electrical

PVC is a polymer with good insulation properties, but because of its higher polar nature the electrical insulating property is inferior to non polar polymers such as polyethylene and polypropylene.

Since the dielectric constant, dielectric loss tangent value, and volume resistivity are high, the corona resistance is not very good, and it is generally suitable for medium or low voltage and low frequency insulation materials.

## Chemical

PVC is chemically resistant to acids, salts, bases, fats, and alcohols; therefore, it is used in sewerage piping. It is also resistant to some solvents, mainly uPVC. Plasticized PVC, also known as PVC-P, is in some cases less resistant to solvents. For example, PVC is resistant to fuel and some paint thinners. Some solvents may only swell it or deform it but not dissolve it, but some of them, like tetrahydrofuran or acetone, may damage it.

## Applications



PVC is used extensively in sewage pipe due to its low cost, chemical resistance and ease of joining **Pipes**

Roughly half of the world's polyvinyl chloride resin manufactured annually is used for producing pipes for municipal and industrial applications. In the water distribution market, it accounts for 66% of the market in the U.S., and in sanitary sewer pipe applications, it accounts for 75%. Buried PVC pipes in both water and sanitary sewer applications that are 4 inches (100 mm) in diameter and larger are typically joined by means of a gasket-sealed joint. The most common type of gasket utilized in North America is a metal reinforced elastomer, commonly referred to as a Rieber sealing system. Its light weight, low cost, and low maintenance make it attractive. However, it must be carefully installed and bedded to ensure longitudinal cracking and overbelling does not occur. Additionally, PVC pipes can be fused together using various solvent cements, or heat-fused (butt-fusion process, similar to joining HDPE pipe), creating permanent joints that are virtually impervious to leakage.

In February 2007 the California Building Standards Code was updated to approve the use of chlorinated polyvinyl chloride (CPVC) pipe for use in residential water supply piping systems. CPVC has been a nationally accepted material in the U.S. since 1982; California, however, has permitted only limited use since 2001. The Department of Housing and Community Development prepared and certified an environmental impact statement resulting in a recommendation that the commission adopt and approve the use of CPVC. The commission's vote was unanimous, and CPVC has been placed in the 2007 California Plumbing Code.

## Electric cables

PVC is commonly used as the insulation on electrical cables; PVC used for this purpose needs to be plasticized. Flexible PVC coated wire and cable for electrical use has traditionally been stabilised with lead, but these are being replaced with calcium-based systems.

In a fire, PVC-coated wires can form hydrogen chloride fumes; the chlorine serves to scavenge free radicals and is the source of the material's fire retardance. While hydrogen chloride fumes can also pose a health hazard in their own right, it dissolves in moisture and breaks down onto surfaces, particularly in areas where the air is cool enough to breathe, and is not available for inhalation. Frequently in applications where smoke is a major hazard (notably in tunnels and communal areas), PVC-free cable insulation is preferred, such as low smoke zero halogen (LSZH) insulation.

## Construction

"A modern Tudorbethan" house with uPVC gutters and downspouts, fascia, decorative imitation "half-timbering", windows, and doors

PVC is a common, strong but lightweight plastic used in construction. It is made softer and more flexible by the addition of plasticizers. If no plasticizers are added, it is known as uPVC (unplasticized polyvinyl chloride) or rigid PVC.

uPVC is extensively used in the building industry as a low-maintenance material, particularly in Ireland, the United Kingdom, in the United States and Canada. In the U.S. and Canada it is known as vinyl or vinyl siding. The material comes in a range of colors and finishes, including a photo-effect wood finish, and is used as a substitute for painted wood, mostly for window frames and sills when installing insulated glazing in new buildings, or to replace older single-glazed windows. Other uses include fascia, and siding or weatherboarding. This material has almost entirely replaced the use of cast iron for plumbing and drainage, being used for waste pipes, drainpipes, gutters and downspouts. uPVC is known as having strong resistance against chemicals, sunlight, and oxidation from water.



Double glazed units

## Signs

Polyvinyl chloride is formed in flat sheets in a variety of thicknesses and colors. As flat sheets, PVC is often expanded to create voids in the interior of the material, providing additional thickness without additional weight and minimal extra cost (see Closed-cell PVC foamboard). Sheets are cut using saws and rotary cutting equipment. Plasticized PVC is also used to produce thin, colored, or clear, adhesive-backed films referred to simply as vinyl. These films are typically cut on a computer-controlled plotter (see Vinyl cutter) or printed in a wide-format printer. These sheets and films are used to produce a wide variety of commercial signage products, including car body stripes and stickers. **Clothing and furniture**





#### Black PVC trousers

PVC has become widely used in clothing, to either create a leather-like material or at times simply for the effect of PVC. PVC clothing is common in Goth, Punk, clothing fetish and alternative fashions. PVC is less expensive than rubber, leather, and latex which it is used to simulate.

PVC fabric is water-resistant, so it is used in coats, skiing equipment, shoes, jackets, aprons, and bags.

#### Healthcare

The two main application areas for single-use medically approved PVC compounds are flexible containers and tubing: containers used for blood and blood components, for urine collection or for ostomy products and tubing used for blood taking and blood giving sets, catheters, heart-lung bypass sets, hemodialysis sets etc. In Europe the consumption of PVC for medical devices is approximately 85,000 tons each year. Almost one third of plastic-based medical devices are made from PVC. The reasons for using flexible PVC in these applications for over 50 years are numerous and based on cost effectiveness linked to transparency, light weight, softness, tear strength, kink resistance, suitability for sterilization and biocompatibility.

#### Flooring

Flexible PVC flooring is inexpensive and used in a variety of buildings covering the home, hospitals, offices, schools, etc. Complex and 3D designs are possible, which are then protected by a clear wear layer. A middle vinyl foam layer also gives a comfortable and safe feel. The smooth, tough surface of the upper wear layer prevents the buildup of dirt, which prevents microbes from breeding in areas that need to be kept sterile, such as hospitals and clinics.

#### Wire rope

PVC coating placed onto wire rope and aircraft cable is used for general purpose applications. The coating process consists of a jacketing application via pressurized extrusion. The benefits of PVC coating on wire rope are for not only aesthetics, but for ergonomics, abrasion protection and visibility. It is found in a variety of industries and environments both indoor and out.

#### Other applications



The handles of the Victorinox Swiss Army knives are made of

PVC has been used for a host of consumer products. One of its earliest mass-market consumer applications was vinyl record production. More recent examples include wallcovering,

greenhouses, home playgrounds, foam and other toys, custom truck toppers (tarpaulins), ceiling tiles and other kinds of interior cladding.

PVC piping is cheaper than metals used in musical instrument making; it is therefore a common alternative when making instruments, often for leisure or for rarer instruments such as the contrabass flute. **3. Polyamide**

A **polyamide** is a macromolecule with repeating units linked by amide bonds.

Polyamides occur both naturally and artificially. Examples of naturally occurring polyamides are proteins, such as wool and silk. Artificially made polyamides can be made through stepgrowth polymerization or solid-phase synthesis yielding materials such as nylons, aramids, and sodium poly(aspartate). Synthetic polyamides are commonly used in textiles, automotive applications, carpets and sportswear due to their high durability and strength. The transportation manufacturing industry is the major consumer, accounting for 35% of polyamide (PA) consumption.

### ***Classification***

Polymers of amino acids are known as polypeptides or proteins.

According to the composition of their main chain, synthetic polyamides are classified as follows:

<b>Polyamide family</b>	<b>Main chain</b>	<b>Examples of polyamides</b>	<b>Examples of commercial products</b>
Aliphatic polyamides	Aliphatic	Nylon PA 6 and PA 66	Zytel from DuPont, Technyl from Solvay, Rilsan and Rilsamid from Arkema, Radipol from Radici Group
Polyphthalamides	Semi-aromatic	PA 6T = hexamethylenediamine + terephthalic acid	Trogamid T from Evonik Industries , Amodel from Solvay
Aramids = aromatic polyamides	Aromatic	Paraphenylenediamine + terephthalic acid	Kevlar and Nomex from DuPont, Teijinconex, Twaron and Technora from Teijin, Kermel from Kermel.

All polyamides are made by the formation of an amide function to link two molecules of monomer together. The monomers can be amides themselves (usually in the form of a cyclic lactam such as caprolactam),  $\alpha$ -amino acids or a stoichiometric mixture of a diamine and a diacid. Both these kinds of precursors give a homopolymer. Polyamides are easily copolymerized, and thus many mixtures of monomers are possible which can in turn lead to many copolymers. Additionally many nylon polymers are miscible with one another allowing the creation of blends.


### ***Polymerization***

Production of polymers requires the repeated joining of two groups to form an amide linkage. In this case this specifically involves amide bonds, and the two groups involved are an amine group, and a terminal carbonyl component of a functional group. These react to produce a carbon-nitrogen bond, creating a singular amide linkage. This process involves the elimination of other atoms

previously part of the functional groups. The carbonyl-component may be part of either a carboxylic acid group or the more reactive acyl halide derivative. The amine group and the carboxylic acid group can be on the same monomer, or the polymer can be constituted of two different bifunctional monomers, one with two amine groups, the other with two carboxylic acid or acid chloride groups.

The condensation reaction is used to synthetically produce nylon polymers in industry. Nylons must specifically include an straight chain (aliphatic) monomer. The amide link is produced from an amine group (alternatively known as an amino group), and a carboxylic acid group. The hydroxyl from the carboxylic acid combines with a hydrogen from the amine, and gives rise to water, the elimination byproduct that is the namesake of the reaction.


As an example of condensation reactions, consider that in living organisms, Amino acids are condensed with one another by an enzyme to form amide linkages (known as peptides). The resulting polyamides are known as proteins or polypeptides. In the diagram below, consider the amino-acids as single aliphatic monomers reacting with identical molecules to form a polyamide, focusing on solely the amine and acid groups. Ignore the substituent R groups – under the assumption the difference between the R groups are negligible:



The reaction of two amino acids. Many of these reactions produce long chain proteins

For fully aromatic polyamides or 'aramids' e.g. Kevlar, the more reactive acyl chloride is used as a monomer. The polymerization reaction with the amine group eliminates hydrogen chloride. The acid chloride route can be used as a laboratory synthesis to avoid heating and obtain an almost instantaneous reaction. The aromatic moiety itself does not participate in elimination reaction, but it does increase the rigidity and strength of the resulting material which leads to Kevlar's renowned strength.


In the diagram below, Aramid is made from two different monomers which continuously alternate to form the polymer. Aramid is an aromatic polyamide:



The reaction of 1,4-phenyl-diamine (para-phenylenediamine) and terephthaloyl chloride to produce Aramid

Polyamides can also be synthesized from dinitriles using acid catalysis via an application of the


Ritter reaction. This method is applicable for preparation of nylon 1,6 from adiponitrile, formaldehyde and water. Additionally, polyamides can be synthesized from glycols and dinitriles using this method as well.



Synthesis of Nylon 1,6 from adiponitrile, formaldehyde, and water using sulfuric acid as a catalyst


### Example: Nylon 66

#### Nylon 66



**Nylon 66 (nylon 6-6, nylon 6/6 or nylon 6,6)** is a type of polyamide or nylon. There are many types of nylon: the two most common for textile and plastics industries are nylon 6 and nylon 66. Nylon 66 is made of two monomers each containing 6 carbon atoms, hexamethylenediamine and adipic acid, which give nylon 66 its name.<sup>[1]</sup>

#### Synthesis and manufacturing



Hexamethylenediamine (top) and adipic acid (bottom), monomers used for polycondensation of Nylon 66.

Nylon 66 is synthesized by polycondensation of hexamethylenediamine and adipic acid. Equivalent amounts of hexamethylenediamine and adipic acid are combined with water in a reactor. This is crystallized to make nylon salt, an ammonium/carboxylate mixture. The nylon salt goes into a reaction vessel where polymerization process takes place either in batches or continuously.  $n \text{ HOOC}-(\text{CH}_2)_4-\text{COOH} + n \text{ H}_2\text{N}-(\text{CH}_2)_6-\text{NH}_2 \rightarrow [-\text{OC}-(\text{CH}_2)_4-\text{CO}-\text{NH}-(\text{CH}_2)_6-\text{NH}-]_n + (2n-1) \text{ H}_2\text{O}$

Removing water drives the reaction toward polymerization through the formation of amide bonds from the acid and amine functions. Thus molten nylon 66 is formed. It can either be extruded and granulated at this point or directly spun into fibers by extrusion through a spinneret (a small metal plate with fine holes) and cooling to form filaments.

#### Applications

In 2011 worldwide production was 2 million tons. At that time fibers consumed just over half of production and engineering resins the rest. It is not used in films due to its inability to be oriented. Fiber markets represented 55% of the 2010 demand with engineering thermoplastics being the remainder.

Nylon 66 is frequently used when high mechanical strength, rigidity, good stability under heat and/or chemical resistance are required. It is used in fibers for textiles and carpets and molded parts. For textiles, fibers are sold under various brands, for example Nilit brands or the Cordura brand for luggage, but it is also used in airbags, apparel, and for carpet fibres under the Ultron brand. Nylon 66 lends itself well to make 3D structural objects, mostly by injection molding finding broad use in auto application under the hood such as radiator end tanks, rocker covers, air intake manifolds, oil pans and numerous other structural parts such as ball bearing cages, electro-insulating elements, pipes, profiles, various machine parts, zip ties, conveyor belts, hoses, polymer framed weapons, and the outer layer of turnout blankets.<sup>[clarification needed]</sup> Nylon 66 is also a popular guitar nut material.

Nylon 66, especially glass fibre grades can be effectively fire retarded with halogen free products. Phosphorus-based flame retardant systems are used in these fire-safe polymers and are based on aluminium diethyl phosphinate and synergists. They are designed to meet UL 94 flammability tests as well as Glow Wire Ignition Tests (GWIT), Glow Wire Flammability Test (GWFI) and Comparative Tracking Index (CTI). Main applications are in the electrical and electronics (E&E) industry.

The Remington Nylon 66 was a .22 rifle manufactured by Remington Arms from 1959 to 1989. It had a stock made from nylon 66.

### 3. Polyester



Close-up of a polyester shirt



Stretching polyester fabric

**Polyester** is a category of polymers that contain the ester functional group in their main chain. As a specific material, it most commonly refers to a type called polyethylene terephthalate (PET). Polyesters include naturally occurring chemicals, such as in the cutin of plant cuticles, as well as synthetics through step-growth polymerization such as polybutyrate. Natural polyesters and a few synthetic ones are biodegradable, but most synthetic polyesters are not. The material is used extensively in clothing.

Depending on the chemical structure, polyester can be a thermoplastic or thermoset. There are also polyester resins cured by hardeners; however, the most common polyesters are thermoplastics. Fabrics woven or knitted from polyester thread or yarn are used extensively in apparel and home furnishings, from shirts and pants to jackets and hats, bed sheets, blankets, upholstered furniture and computer mouse mats. Industrial polyester fibers, yarns and ropes are used in car tire reinforcements, fabrics for conveyor belts, safety belts, coated fabrics and plastic reinforcements with high-energy absorption. Polyester fiber is used as cushioning and insulating material in pillows, comforters and upholstery padding. Polyester fabrics are highly stain-resistant—in fact, the only class of dyes which *can* be used to alter the color of polyester fabric are what are known as disperse dyes.

Polyester fibers are sometimes spun together with natural fibers to produce a cloth with blended properties. Cotton-polyester blends (polycotton) can be strong, wrinkle and tear-resistant, and reduce shrinking. Synthetic fibers in polyester also create materials with water, wind and environmental resistance compared to plant-derived fibers. Disadvantages of cotton and polyester blends include being less breathable than cotton and trapping more moisture while sticking to the skin. They are also less fire resistant and can melt when ignited.

Polyester blends have been renamed so as to suggest their similarity or even superiority to natural fibers (for example, China silk, which is a term in the textiles industry for a 100% polyester fiber woven to resemble the sheen and durability of insect-derived silk).

Polyesters are also used to make bottles, films, tarpaulin, canoes, liquid crystal displays, holograms, filters, dielectric film for capacitors, film insulation for wire and insulating tapes. Polyesters are widely used as a finish on high-quality wood products such as guitars, pianos and vehicle/yacht interiors. Thixotropic properties of spray-applicable polyesters make them ideal for use on open-grain timbers, as they can quickly fill wood grain, with a high-build film thickness per coat. Cured polyesters can be sanded and polished to a highgloss, durable finish.

Liquid crystalline polyesters are among the first industrially used liquid crystal polymers. They are used for their mechanical properties and heat-resistance. These traits are also important in their application as an abradable seal in jet engines.

### Synthesis


Synthesis of polyesters is generally achieved by a polycondensation reaction. See "condensation reactions in polymer chemistry". The general equation for the reaction of a diol with a diacid is :



### Azeotrope esterification

In this classical method, an alcohol and a carboxylic acid react to form a carboxylic ester. To assemble a polymer, the water formed by the reaction must be continually removed by azeotrope distillation.

#### Alcoholic transesterification



**Transesterification:** An alcohol-terminated oligomer and an ester-terminated oligomer condense to form an ester linkage, with loss of an alcohol. R and R' are the two oligomer chains, R'' is a sacrificial unit such as a methyl group (methanol is the byproduct of the esterification reaction).



### Acylation (HCl method)

The acid begins as an acid chloride, and thus the polycondensation proceeds with emission of hydrochloric acid (HCl) instead of water. This method can be carried out in solution or as an enamel.

### Silyl method

In this variant of the HCl method, the carboxylic acid chloride is converted with the trimethyl silyl ether of the alcohol component and production of trimethyl silyl chloride is obtained

### Acetate method (esterification) Silyl acetate method Ring-opening polymerization


Aliphatic polyesters can be assembled from lactones under very mild conditions, catalyzed anionically, cationically or metallorganically. A number of catalytic methods for the copolymerization of epoxides with cyclic anhydrides have also recently been shown to provide a wide array of functionalized polyesters, both saturated and unsaturated.

### Cross-linking

Unsaturated polyesters are thermosetting resins. They are generally copolymers prepared by polymerizing one or more diol with saturated and unsaturated dicarboxylic acids (maleic acid, fumaric acid...) or their anhydrides. The double bond of unsaturated polyesters reacts with a vinyl monomer, usually styrene, resulting in a 3-D cross-linked structure. This structure acts as a thermoset. The exothermic cross-linking reaction is initiated through a catalyst, usually an organic peroxide such as methyl ethyl ketone peroxide or benzoyl peroxide.

### Example: Poly(ethylene terephthalate)

A polyester is a polymer (a chain of repeating units) where the individual units are held together by ester linkages.



The diagram shows a very small bit of the polymer chain and looks pretty complicated. But it isn't very difficult to work out - and that's the best thing to do: work it out, not try to remember it. You will see how to do that in a moment.

The usual name of this common polyester is poly(ethylene terephthalate). The everyday name depends on whether it is being used as a fibre or as a material for making things like bottles for soft drinks.

When it is being used as a fibre to make clothes, it is often just called *polyester*. It may sometimes be known by a brand name like *Terylene*.

When it is being used to make bottles, for example, it is usually called *PET*.


### Making polyesters as an example of condensation polymerisation

In condensation polymerisation, when the monomers join together a small molecule gets lost. That's different from addition polymerisation which produces polymers like poly(ethene) - in that case, nothing is lost when the monomers join together. A polyester is made by a reaction involving an acid with two -COOH groups, and an alcohol with two -OH groups.


In the common polyester drawn above:

The acid is benzene-1,4-dicarboxylic acid (old name: terephthalic acid). The alcohol is ethane-1,2-diol (old name: ethylene glycol).






Now imagine lining these up alternately and making esters with each acid group and each alcohol group, losing a molecule of water every time an ester linkage is made.



That would produce the chain shown above (although this time written without separating out the carbon-oxygen double bond - write it whichever way you like).



### Hydrolysis of polyesters


*Simple esters* are easily hydrolysed by reaction with dilute acids or alkalis.

*Polyesters* are attacked readily by alkalis, but much more slowly by dilute acids. Hydrolysis by water alone is so slow as to be completely unimportant. (You wouldn't expect your polyester fleece to fall to pieces if you went out in the rain!)


If you spill dilute alkali on a fabric made from polyester, the ester linkages are broken. Ethane-1,2-diol is formed together with the salt of the carboxylic acid.

Because you produce small molecules rather than the original polymer, the fibres are destroyed, and you end up with a hole!

For example, if you react the polyester with sodium hydroxide solution:



## 5. Phenol formaldehyde resin



**Phenol formaldehyde resins (PF)** or **phenolic resins** are synthetic polymers obtained by the reaction of phenol or substituted phenol with formaldehyde. Used as the basis for Bakelite, PFs were the first commercial synthetic resins (plastics). They have been widely used for the production of molded products including billiard balls, laboratory countertops, and as coatings and adhesives. They were at one time the primary material used for the production of circuit boards but have been largely replaced with epoxy resins and fiberglass cloth, as with fireresistant FR-4 circuit board materials.

There are two main production methods. One reacts phenol and formaldehyde directly to produce a thermosetting network polymer, while the other restricts the formaldehyde to produce a prepolymer known as **novolac** which can be moulded and then cured with the addition of more formaldehyde and heat. There are many variations in both production and input materials that are used to produce a wide variety of resins for special purposes.


### *Formation and structure*

Phenol-formaldehyde resins, as a group, are formed by a step-growth polymerization reaction that can be either acid- or base-catalysed. Since formaldehyde exists predominantly in solution as a dynamic equilibrium of methylene glycol oligomers, the concentration of the *reactive* form of formaldehyde depends on temperature and pH.


Phenol reacts with formaldehyde at the ortho and para sites (sites 2, 4 and 6) allowing up to 3 units of formaldehyde to attach to the ring. The initial reaction in all cases involves the formation of a hydroxymethyl phenol:



The hydroxymethyl group is capable of reacting with either another free ortho or para site, or with another hydroxymethyl group. The first reaction gives a methylene bridge, and the second forms an ether bridge:



The diphenol  $(\text{HOC}_6\text{H}_4)_2\text{CH}_2$  (sometimes called a "dimer") is called bisphenol F, which is an important monomer in the production of epoxy resins. Bisphenol-F can further link generating tri- and tetra- and higher phenol oligomers. **Novolacs**



Novolac

Novolacs are phenol-formaldehyde resins with a formaldehyde to phenol molar ratio of less than one. The polymerization is brought to completion using acid-catalysis such as oxalic acid, hydrochloric acid or sulfonate acids. The phenol units are mainly linked by methylene and/or ether groups. Novolacs are commonly used as photoresists. See also photolithography. The molecular weights are in the low thousands, corresponding to about 10–20 phenol units.

Hexamethylenetetramine or "hexamine" is a hardener added to crosslink novolac. At a temperature  $>90\text{ }^{\circ}\text{C}$ , it forms methylene and dimethylene amino bridges.

### ***Applications***

Phenolic resins are found in a myriad of industrial products. Phenolic laminates are made by impregnating one or more layers of a base material such as paper, fiberglass or cotton with phenolic resin and laminating the resin-saturated base material under heat and pressure. The resin fully polymerizes (cures) during this process forming the thermoset polymer matrix. The base material choice depends on the intended application of the finished product. Paper phenolics are used in manufacturing electrical components such as punch-through boards, in household laminates, and in paper composite panels. Glass phenolics are particularly well suited for use in the high speed bearing market. Phenolic micro-balloons are used for density control. Snooker balls as well as balls from many table-based ball games are also made from phenol formaldehyde resin. The binding agent in normal (organic) brake pads, brake shoes and clutch disks are phenolic resin. Synthetic resin bonded paper, made from phenolic resin and paper, is used to make countertops. Phenolic resins are also used for making exterior plywood commonly known as WBP (Weather & boil proof) Plywood because phenolic resins have no melting point but only a decomposing point in the temperature zone of  $220\text{ }^{\circ}\text{C}$  ( $428\text{ }^{\circ}\text{F}$ ) and above.

Phenolic resin is used as a binder in loudspeaker driver suspension components which are made of cloth.

Billiard balls are made from solid Phenolic resin.


Sometimes people select phenolic resin parts because their coefficient of thermal expansion closely matches that of the aluminium used for other parts of a system, as in early computer systems and Duramold.

### **6. Epoxy**

*This article is about the thermoset plastic materials. For the chemical group, see epoxide.*




A syringe of "5-minute" epoxy glue, containing separate compartments for the epoxy resin and the hardener.



Structure of the highly reactive epoxide group present in all epoxy resins.

**Epoxy** is either any of the basic components or the cured end products of **epoxy resins**, as well as a colloquial name for the epoxidefunctional group.<sup>[1]</sup> Epoxy resins, also known as **polyepoxides**, are a class of reactive prepolymers and polymers which contain epoxide groups. Epoxy resins may be reacted (cross-linked) either with themselves through catalytic homopolymerisation, or with a wide range of co-reactants including polyfunctional amines, acids (and acid anhydrides), phenols, alcohols and thiols. These co-reactants are often referred to as hardeners or curatives, and the cross-linking reaction is commonly referred to as curing. Reaction of polyepoxides with themselves or with polyfunctional hardeners forms a thermosetting polymer, often with high mechanical properties, temperature and chemical resistance. Epoxy has a wide range of applications, including metal coatings, use in electronics / electrical components/LED, high tension electrical insulators, paint brush manufacturing, fiberreinforced plastic materials and structural adhesives.

### *Epoxy resin*



Structure of a cured epoxy glue. The triamine hardener is shown in red, the resin in black. The resin's epoxide groups have reacted with the hardener and are not present anymore. The material

Epoxy resins are low molecular weight pre-polymers or higher molecular weight polymers which is highly crosslinked and contains many OH groups, which confer adhesive properties. normally contain at least two epoxide groups. The epoxide group is also sometimes referred to as a glycidyl or oxirane group.

A wide range of epoxy resins are produced industrially. The raw materials for epoxy resin production are today largely petroleum derived, although some plant derived sources are now becoming commercially available (e.g. plant derived glycerol used to make epichlorohydrin). Epoxy resins are polymeric or semi-polymeric materials, and as such rarely exist as pure substances, since variable chain length results from the polymerisation reaction used to produce them. High purity grades can be produced for certain applications, e.g. using a distillation purification process. One downside of high purity liquid grades is their tendency to form crystalline solids due to their highly regular structure, which require melting to enable processing.

An important criterion for epoxy resins is the epoxide content. This is commonly expressed as the **epoxy equivalent weight**, which is the number of epoxide equivalents in 1 kg of resin (Eq./kg), or as the **equivalent weight**, which is the weight in grammes of resin containing 1 mole equivalent of epoxide (g/mol). One measure may be simply converted to another:


Equivalent weight (g/mol) = 1000 / epoxide number (Eq./kg)

The equivalent weight or epoxide number is used to calculate the amount of co-reactant (hardener) to use when curing epoxy resins. Epoxies are typically cured with stoichiometric or near-stoichiometric quantities of curative to achieve maximum physical properties.

As with other classes of thermoset polymer materials, blending different grades of epoxy resin, as well as use of additives, plasticizers or fillers is common to achieve the desired processing or final properties, or to reduce cost. Use of blending, additives and fillers is often referred to as **formulating**.

### ***Examples: Bisphenol A epoxy resin***

Important epoxy resins are produced from combining epichlorohydrin and bisphenol A to give bisphenol A diglycidyl ethers.



Structure of bisphenol-A diglycidyl ether epoxy resin:  $n$  denotes the number of polymerized subunits and is typically in the range from 0 to 25

Increasing the ratio of bisphenol A to epichlorohydrin during manufacture produces higher molecular weight linear polyethers with glycidyl end groups, which are semi-solid to hard crystalline materials at room temperature depending on the molecular weight achieved. As the molecular weight of the resin increases, the epoxide content reduces and the material behaves more and more like a thermoplastic. Very high molecular weight polycondensates (ca. 30 000 – 70 000 g/mol) form a class known as phenoxy resins and contain virtually no epoxide groups (since the terminal epoxy groups are insignificant compared to the total size of the molecule). These resins do however contain hydroxyl groups throughout the backbone, which may also undergo other cross-linking reactions, e.g. with aminoplasts, phenoplasts and isocyanates.

### **Bisphenol F epoxy resin**

Bisphenol F may also undergo epoxidation in a similar fashion to bisphenol A. Compared to DGEBA, bisphenol F epoxy resins have lower viscosity and a higher mean epoxy content per gramme, which (once cured) gives them increased chemical resistance.

### ***Applications***

The applications for epoxy-based materials are extensive and include coatings, adhesives and composite materials such as those using carbon fiber and fiberglass reinforcements (although polyester, vinyl ester, and other thermosetting resins are also used for glass-reinforced plastic). The chemistry of epoxies and the range of commercially available variations allows cure polymers to be produced with a very broad range of properties. In general, epoxies are known for their excellent adhesion, chemical and heat resistance, good-to-excellent mechanical properties and very good electrical insulating properties. Many properties of epoxies can be modified (for

example silver-filled epoxies with good electrical conductivity are available, although epoxies are typically electrically insulating). Variations offering high thermal insulation, or thermal conductivity combined with high electrical resistance for electronics applications, are available.<sup>[6]</sup>

### Paints and coatings

Two part epoxy coatings were developed for heavy duty service on metal substrates and use less energy than heat-cured powder coatings. These systems provide a tough, protective coating with excellent hardness. Some epoxy coatings are formulated as an emulsion in water, and can be cleaned up without solvents. Epoxy coatings are often used in industrial and automotive applications since they are more heat resistant than latex-based and alkyd-based paints. Epoxy paints tend to deteriorate, known as "chalking out", due to UV exposure.<sup>[7]</sup>

Polyester epoxies are used as powder coatings for washers, driers and other "white goods". Fusion Bonded Epoxy Powder Coatings (FBE) are extensively used for corrosion protection of steel pipes and fittings used in the oil and gas industry, potable water transmission pipelines (steel), and concrete reinforcing rebar. Epoxy coatings are also widely used as primers to improve the adhesion of automotive and marine paints especially on metal surfaces where corrosion (rusting) resistance is important. Metal cans and containers are often coated with epoxy to prevent rusting, especially for foods like tomatoes that are acidic. Epoxy resins are also used for decorative flooring applications such as terrazzo flooring, chip flooring, and colored aggregate flooring. Epoxies were modified in a variety of ways, Reacted with fatty acids derived from oils to yield epoxy esters, which were cured the same way as alkyds .

### Adhesives



Special epoxy is strong enough to withstand the forces between a surfboard fin and the fin mount. This epoxy is waterproof and capable of curing underwater. The blue-coloured epoxy on the left is still undergoing curing.



Epoxy adhesives are a major part of the class of adhesives called "structural adhesives" or "engineering adhesives" (that includes polyurethane, acrylic, cyanoacrylate, and other chemistries.) These high-performance adhesives are used in the construction of aircraft, automobiles, bicycles, boats, golf clubs, skis, snowboards, and other applications where high strength bonds are required. Epoxy adhesives can be developed to suit almost any application. They can be used as adhesives for wood, metal, glass, stone, and some plastics. They can be made flexible or rigid, transparent or opaque/colored, fast setting or slow setting. Epoxy adhesives are better in heat and chemical resistance than other common adhesives. Some epoxies are cured by exposure to ultraviolet light. Such epoxies are commonly used in optics, fiber optics, and optoelectronics. **Industrial tooling and composites**

Epoxy systems are used in industrial tooling applications to produce molds, master models, laminates, castings, fixtures, and other industrial production aids. This "plastic tooling" replaces



metal, wood and other traditional materials, and generally improves the efficiency and either lowers the overall cost or shortens the lead-time for many industrial processes. Epoxies are also used in producing fiber-reinforced or composite parts. They are more expensive than polyester resins and vinyl ester resins, but usually produce stronger and more temperatureresistant thermoset polymer matrix composite parts.

### **Electrical systems and electronics**



An epoxy encapsulated hybrid circuit on a printed circuit board.

The interior of a pocket calculator. The dark lump of epoxy in the center covers the processor chip

Epoxy resin formulations are important in the electronics industry, and are employed in motors, generators, transformers, switchgear, bushings, and insulators. Epoxy resins are excellent electrical insulators and protect electrical components from short circuiting, dust and moisture. In the electronics industry epoxy resins are the primary resin used in overmolding integrated circuits, transistors and hybrid circuits, and making printed circuit boards. The largest volume type of circuit board—an "FR-4 board"—is a sandwich of layers of glass cloth bonded into a composite by an epoxy resin. Epoxy resins are used to bond copper foil to circuit board substrates, and are a component of the solder mask on many circuit boards.

### **Petroleum & petrochemical**

Epoxies can be used to plug selective layers in a reservoir which are producing excessive brine. The technique is named "water shut-off treatment".<sup>[2]</sup>

### **Consumer and marine applications**

Epoxies are sold in hardware stores, typically as a pack containing separate resin and hardener, which must be mixed immediately before use. They are also sold in boat shops as repair resins for marine applications. Epoxies typically are not used in the outer layer of a boat because they deteriorate by exposure to UV light. They are often used during boat repair and assembly, and then over-coated with conventional or two-part polyurethane paint or marine-varnishes that provide UV protection.

There are two main areas of marine use. Because of the better mechanical properties relative to the more common polyester resins, epoxies are used for commercial manufacture of components where a high strength/weight ratio is required. The second area is that their strength, gap filling properties and excellent adhesion to many materials including timber have created a boom in amateur building projects including aircraft and boats.

Epoxy materials tend to harden somewhat more gradually, while polyester materials tend to harden quickly, particularly if a lot of catalyst is used.<sup>[9]</sup> The chemical reactions in both cases are



exothermic. Large quantities of mix will generate their own heat and greatly speed the reaction, so it is usual to mix small amounts which can be used quickly.

As adhesives, epoxies bond in three ways: a) Mechanically, because the bonding surfaces are roughened; b) By proximity, because the cured resins are physically so close to the bonding surfaces that they are hard to separate; c) Ionically, because the epoxy resins form ionic bonds at an atomic level with the bonding surfaces. This last is substantially the strongest of the three. By contrast, polyester resins can only bond using the first two of these, which greatly reduces their utility as adhesives and in marine repair.

### **Aerospace applications**

In the aerospace industry, epoxy is used as a structural matrix material which is then reinforced by fiber. Typical fiber reinforcements include glass, carbon, Kevlar, and boron. Epoxies are also used as a structural glue. Materials like wood, and others that are 'low-tech' are glued with epoxy resin.

### **Biology**

Water-soluble epoxies such as Durcupan are commonly used for embedding electron microscope samples in plastic so they may be sectioned (sliced thin) with a microtome and then imaged.

**Art** Epoxy resin, mixed with pigment, may be used as a painting medium, by pouring layers on top of each other to form a complete picture.

### **Industry**

These commodity epoxy manufacturers mentioned above typically do not sell epoxy resins in a form usable to smaller end users, so there is another group of companies that purchase epoxy raw materials from the major producers and then compounds (blends, modifies, or otherwise customizes) epoxy systems from these raw materials. These companies are known as "formulators". The majority of the epoxy systems sold are produced by these formulators and they comprise over 60% of the dollar value of the epoxy market. There are hundreds of ways that these formulators can modify epoxies—by adding mineral fillers (talc, silica, alumina, etc.), by adding flexibilizers, viscosity reducers, colorants, thickeners, accelerators, adhesion promoters, etc. These modifications are made to reduce costs, to improve performance, and to improve processing convenience. As a result, a typical formulator sells dozens or even thousands of formulations—each tailored to the requirements of a particular application or market.

## **7. Silicone**



Silicone caulk can be used as a basic sealant against water and air penetration.

**Silicones**, also known as **polysiloxanes**, are polymers that include any inert, synthetic compound made up of repeating units of siloxane, which is a chain of alternating silicon atoms and oxygen atoms, frequently combined with carbon and/or hydrogen. They are typically heatresistant and rubber-like, and are used in sealants, adhesives, lubricants, medicine, cooking utensils, and thermal and electrical insulation. Some common forms include silicone oil, silicone grease, silicone rubber, silicone resin, and silicone caulk. Silicones are of three types: 1. straight chain silicones; 2. cyclic silicones; 3. crosslinked silicones.

### ***Synthesis***

Most common are materials based on polydimethylsiloxane, which is derived by hydrolysis of dimethyldichlorosilane. This dichloride reacts with water as follows:



The polymerization typically produces linear chains capped with Si-Cl or Si-OH (silanol) groups. Under different conditions the polymer is a cyclic, not a chain.

For consumer applications such as caulks silyl acetates are used instead of silyl chlorides. The hydrolysis of the acetates produce the less dangerous acetic acid (the acid found in vinegar) as the reaction product of a much slower curing process. This chemistry is used in many consumer applications, such as silicone caulk and adhesives.

Branches or cross-links in the polymer chain can be introduced by using organosilicone precursors with fewer alkyl groups, such as methyltrichlorosilane and methyltrimethoxysilane. Ideally, each molecule of such a compound becomes a branch point. This process can be used to produce hard silicone resins. Similarly, precursors with three methyl groups can be used to limit molecular weight, since each such molecule has only one reactive site and so forms the end of a siloxane chain.

### ***Combustion***

When silicone is burned in air or oxygen, it forms solid silica (silicon dioxide)(SiO<sub>2</sub>) as a white powder, char, and various gases. The readily dispersed powder is sometimes called silica fume.

### ***Properties***

Silicones exhibit many useful characteristics, including:<sup>[1]</sup>

- Low thermal conductivity
- Low chemical reactivity
- Low toxicity
- Thermal stability (constancy of properties over a wide temperature range of –100 to 250 °C).
- The ability to repel water and form watertight seals.
- Does not stick to many substrates, but adheres very well to others, e.g. glass.
- Does not support microbiological growth.
- Resistance to oxygen, ozone, and ultraviolet (UV) light. This property has led to widespread use of silicones in the construction industry (e.g. coatings, fire protection, glazing seals) and the automotive industry (external gaskets, external trim).
- Electrical insulation properties. Because silicone can be formulated to be electrically insulative or conductive, it is suitable for a wide range of electrical applications.

- High gas permeability: at room temperature (25 °C), the permeability of silicone rubber for such gases as oxygen is approximately 400 times<sup>[citation needed]</sup> that of butyl rubber, making silicone useful for medical applications in which increased aeration is desired. Conversely, silicone rubbers cannot be used where gas-tight seals are necessary.

### Uses

Silicones are used in many products. Ullmann's Encyclopedia of Industrial Chemistry lists the following major categories of application: Electrical (e.g., insulation), electronics (e.g., coatings), household (e.g., sealants for cooking apparatus), automobile (e.g., gaskets), aeroplane (e.g., seals), office machines (e.g., keyboard pads), medicine/dentistry (e.g., teeth impression molds), textiles/paper (e.g., coatings). For these applications, an estimated 400,000 tons of silicones were produced in 1991. Specific examples, both large and small are presented below.

### Automotive

In the automotive field, silicone grease is typically used as a lubricant for brake components since it is stable at high temperatures, is not water-soluble, and is far less likely than other lubricants to foul. It is also used as DOT 5 brake fluid.

Automotive spark plug wires are insulated by multiple layers of silicone to prevent sparks from jumping to adjacent wires, causing misfires. Silicone tubing is sometimes used in automotive intake systems (especially for engines with forced induction).

Sheet silicone is used to manufacture gaskets used in automotive engines, transmissions, and other applications.

Automotive body manufacturing plants and paint shops avoid silicones, as they may cause "fish eyes", small, circular craters in the finish.

### Coatings

Silicone films can be applied to such silica-based substrates as glass to form a covalently bonded hydrophobic coating.

Many fabrics can be coated or impregnated with silicone to form a strong, waterproof composite such as silnylon.

### Cookware



Soup ladle and pasta ladle made of silicone.

A silicone food steamer to be placed inside a pot of boiling water.

Ice cube trays made of silicone.

- ✚ As a low-taint, non-toxic material, silicone can be used where contact with food is required. Silicone is becoming an important product in the cookware industry, particularly bakeware and kitchen utensils.
- ✚ Silicone is used as an insulator in heat-resistant potholders and similar items; however, it is more conductive of heat than similar less dense fiber-based products. Silicone oven mitts are able to withstand temperatures up to 260 °C (500 °F), allowing reaching into boiling water.
- ✚ Molds for chocolate, ice, cookies, muffins and various other foods.

- ✚ Non-stick bakeware and reusable mats used on baking sheets.
- ✚ Other products such as steamers, egg boilers or poachers, cookware lids, pot holders, trivets, and kitchen mats.

### **Defoaming**

Silicones are used as active compound in defoamers due to their low water solubility and good spreading properties. **Dry cleaning**

Liquid silicone can be used as a dry cleaning solvent, providing an alternative to the traditional chlorine-containing perchloroethylene (perc)solvent. Use of silicones in dry cleaning reduces the environmental impact of a typically high-polluting industry.

### **Electronics**

Electronic components are sometimes encased in silicone to increase stability against mechanical and electrical shock, radiation and vibration, a process called "potting".

Silicones are used where durability and high performance are demanded of components under hard conditions, such as in space (satellite technology). They are selected over polyurethane or epoxy encapsulation when a wide operating temperature range is required (–65 to 315 °C). Silicones also have the advantage of little exothermic heat rise during cure, low toxicity, good electrical properties and high purity.

The use of silicones in electronics is not without problems, however. Silicones are relatively expensive and can be attacked by solvents. Silicone easily migrates as either a liquid or vapor onto other components.

Silicone contamination of electrical switch contacts can lead to failures by causing an increase in contact resistance, often late in the life of the contact, well after any testing is completed. Use of silicone-based spray products in electronic devices during maintenance or repairs can cause later failures.

### **Firestops**

Silicone foam has been used in North American buildings in an attempt to firestop openings within fire-resistance-rated wall and floor assemblies to prevent the spread of flames and smoke from one room to another. When properly installed, silicone-foam firestops can be fabricated for building code compliance. Advantages include flexibility and high dielectric strength. Disadvantages include combustibility (hard to extinguish) and significant smoke development. Silicone-foam firestops have been the subject of controversy and press attention due to smoke development from pyrolysis of combustible components within the foam, hydrogen gas escape, shrinkage, and cracking. These problems have led to reportable events among licensees (operators of nuclear power plants) of the Nuclear Regulatory Commission (NRC).

Silicone firestops are also used in aircraft.

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

	Questions	Opt-1	Opt-2	Opt-3	Opt-4	Answers
1	Which is more flexible than HDPE due to lower crystallinity?	Polyethylene	Low Density Polyethylene	Polyamide	Low density polyamide	Low Density Polyethylene
2	80-90% of all plasticizers used with?	DOP	DIOP	PVC	Colourants	PVC
3	It must not exude from the plastic material?	Primary plasticizers	Secondary plasticizers	Antioxidants	Colourants	Primary plasticizers
4	Limited compatibility with the polymers are?	Primary plasticizers	Secondary plasticizers	Antioxidants	Colourants	Secondary plasticizers
5	Inhibiting the oxidation of polymers is usually filled by a substance which itself is readily oxidized.	Antioxidants	Flame retardants	Colourants	Mgo	Antioxidants
6	In polymer industry 2-hydroxybenzophenones are used as	Light stabilizers	Antioxidants	Polymer initiators	Fillers	Light stabilizers
7	Any of a group of substances that are used in plastics or other materials to impart viscosity, flexibility, softness or other properties to the finished product	Plasticizers	Antioxidants	Polymer initiators	Fillers	Plasticizers

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

8	It often added to semicrystalline polymer to lower the value of Tg below room temperature.	Light stabilizers	Colouarants	Plasticizers	Flame retardents	Plasticizers
9	The basic requirement that must be met by a plasticizer are	Compatibility	Prevent oxidation	Retard flame	Impart a colour	Compatibility
10	Porosity increased as plasticizers content?	Increased	Decreased	Suddenly decreased	Never change	Increased
11	The substances which weaken the intermolecular forces between the polymer chains and decrease Tg.	Plasticizers	Antioxidants	Polymer initiators	Fillers	Plasticizers
12	Which content did not have a significant effect on the rate of erosion?	Light stabilizers	Colouarants	Plasticizers	Flame retardents	Plasticizers
13	Which type of compound is not used as a flame retardant in polymers	Aluminum Hydroxide	Halogen compounds	Phosphorous compounds	Ferrocene	Ferrocene
14	Chemical compounds capable of interfering with the physical and chemical processes of UV light-induced degradation .	Plasticizers	Antioxidants	Polymer initiators	Light stabilizer	Light stabilizer
15	which one of the following polymers is the product of a condensation polymerisation reaction?	Polypropylene	Polytetrafluoroethene	Polyacetic acid	PVC	Polyacetic acid



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

16	The phenol-formaldehyde resins are formed by polymerisation of phenol and formaldehyde by	Addition polymerisation	Cationic polymerisation	Condensation polymerisation	Anionic polymerisation	Condensation polymerisation
17	The addition of polyethylene glycol in dielectric property significantly improves?	Electrolytic conductivity	Dielectric conductivity	Electric conductivity	Ionic conductivity	Ionic conductivity
18	Melamine is	White crystalline solid	Gas	Colourless liquid	Yellow liquid	White crystalline solid
19	Plastics are ?	Hydrocarbons	Aldehyde	Ester	Amide	Hydrocarbons
20	Which one is an inorganic pigment?	Barium sulfate	Perylenes	Pyrroles	Arylamides	Barium sulfate
21	Poly vinyl chloride is?	An allotrope polymer of vinyl chloride	An addition product of vinyl chloride	An isomer of vinyl chloride	A polymer of hydrated vinyl chloride	An addition product of vinyl chloride
22	Which one is more active flame retardant?	Aluminum hydroxide	Antimony oxychloride	Phosphorous	Halogen compounds	Antimony oxychloride
23	The most useful material imparting flame retardance to plastics is?	Antimony trioxide	Aluminum hydroxide	Halogen compounds	Antimony oxychloride	Antimony trioxide
24	Which one of the following flame retardant forms a gas shield layer?	Calcium	Phosphorous	Ammonium	Aluminium oxide	Phosphorous



# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

25	Which one of the following flame retardant breaks down endothermic reaction?	Phosphorous	Ammonium	Aluminium oxide	Aluminum Hydroxide	Aluminum Hydroxide
26	Melting Point of Low Density Polyethylene (LDPE) is?	~115°C	~116 °C	~135°C	~148 °C	~135°C
27	Which one is a synthetic polymer?	Cellulose	Cotton	Polyamide	Fibers	Polyamide
28	Polymethyl methacrylate is a colourless and transparent ?	Plastic	Rubber	Cotton	Nylon	Plastic
29	Polymethyl methacrylate can be prepared by using acetone cyanohydrin and	Nitric acid	Acetic acid	Sulphuric acid	Hydrochloric acid	Sulphuric acid
30	Silicones was commercially introduced in ?	1943	1930	1936	1947	1943
31	Polyvinyl chloride was commercially introduced in ?	1943	1930	1936	1947	1936
32	Polyvinyl acetate monomer is prepared by the reaction of acetic anhydride with ?	Benzaldehyde	Acetaldehyde	Acetic acid	Sodium acetate	Acetaldehyde
33	Polyvinyl acetate is used for the manufacture of ?	Polyvinyl chloride	Polyvinyl alcohol	Poly methyl methacrylate	Polyvinyl acetate	Polyvinyl alcohol

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

34	Styrene(butadiene rubber) was commercially introduced during the year	1943	1930	1936	1947	1930
35	Polyvinyl acetate is insoluble in which solvent?	Alcohols	Aromatic solvents	Esters	Water	Water
36	Polythene was first synthesised in ?	1877	1853	1890	1898	1898
37	Polythene was first produced in ?	German	England	India	USA	England c
38	Polyethylene was first synthesized by ?	Pechmann	Fawcett	Karl ziegler	Walter	Pechmann
39	Which one of the compound is used in the manufacture of terylene ?	Vinyl chloride	Ethylene glycol	Vinyl alcohol	Ethylene	Ethylene glycol
40	Which one of the following is an example of condensation polymer?	Terylene	PVC	Vinyl alcohol	Ethylene	Terylene
41	The synthetic polymer which resembles natural rubber is ?	Cotton	Nylon	Chloroprene	Neoprene	Neoprene
42	Which one is prepared by the melt polycondensation between dicarboxylic acids and diamides.	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyamides

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

43	Aliphatic polyamides are generally known as ?	Cotton	Nylon	Polyamide	Polyester	Nylon
44	Which one of the following is obtained from dibasic acids and diamides.	Cotton	Nylon	Polyamide	Polyester	Nylon
45	The ring opening polymerization of lactometated is represented only by ?	Single number	Double number	Triple number	No number	Single number
46	It has good tensile strength and abrasion resistance	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyamides
47	It is used as a plastic as well as a fibre	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyamides
48	Which one is used in tires and ropes?	Cotton	Nylon	Polyamide	Polyester	Nylon
49	Which is used in clothes, belts and accessories?	Cotton	Nylon	Polyamide	Polyester	Nylon
50	It is prepared by polycondensation reaction between a dicarboxylic acid and a diol.	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyester
51	Which polymers contains ester groups in the main chain of the polymer itself.	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyester

# KARPAGAM ACADEMY OF HIGHER EDUCATION

CLASS: II M.Sc CHEMISTRY

COURSE NAME: POLYMER CHEMISTRY

COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019

52	The molecular weight of cellulose varies between	20000 to 500000	10000 to 20000	10000 to 12000	1000 to 2000	20000 to 500000
53	Condensation polymerization is not used to produce	Polyester	Nylon 6	Nylon 66	Polypropylene	Polypropylene
54	Polyethylene terephthalate (PETP) has a high melting point because of the presence of ?	Aliphatic chain	Aromatic ring	Nitrogen bond	CN bond	Aromatic ring
55	Which one of the following is resistant to heat and moisture.	Polyamides	Polyester	Acrylic fibre	Polyethylene	Polyester
56	PETP melts at ?	275°C	266°C	267°C	265°C	265°C
57	Which one of the following is used in the manufacturing of magnetic recording tapes, aluminised sheets for certain special applications?	Polyethylene terephthalate	Polyester	Acrylic fibre	Polyethylene	Polyethylene terephthalate
58	The polymer made from acrylonitrile ?	Polyacrylic fibres	Polyethylene	Polyester	Polyethylene terephthalate	Polyacrylic fibres
59	Polymer which contains between 35-65% of acrylonitrile are known as?	Orlon	Modacrylics	Acrlan	Verel	Modacrylics
60	Polymers which contain 85% or more acrylonitrile is?	Orlon	Modacrylics	Vinyl acetate	Verel	Orlon

# **KARPAGAM ACADEMY OF HIGHER EDUCATION**

**CLASS: II M.Sc CHEMISTRY**

**COURSE NAME: POLYMER CHEMISTRY**

**COURSE CODE: 17CHP305A UNIT: V (PROPERTIES OF COMMERCIAL POLYMERS) BATCH-2017-2019**

---

KARPE

Reg. No.....

**KARPAGAM ACADEMY OF HIGHER EDUCATION  
COIMBATORE-21**

**(For the candidates admitted from 2017 & onwards)**

**M.SC DEGREE EXAMINATION-2018**

**III SEMESTER**

**INTERNAL TEST – I**

**M.SC., CHEMISTRY**

**POLYMER CHEMISTRY**

**DATE:**  
**TIME: 2 HRS**

**SUBJECT CODE: 17CHP305A**  
**TOTAL: 50 MARKS**

**Section-A**  
**Answer All The Questions**

**(20x1=20 marks)**

1. The azo(bis-isobutyro)nitrile (AIBN) is commonly used at?  
a. 60-70 °C    b. 50-70 °C    c. 80-90 °C    d. 40-50 °C
2. Teflon is a polymer of the monomer or Teflon is obtained by the polymerization of?  
a. Monofluoroethene    b. Difluoroethene  
c. Trifluoroethene    d. Tetrafluoroethene
3. Which of the following is an example of condensation polymer?  
a. PVC    b. Polyamide    c. Terylene    d. Polyester
4. Two trimers react together to form  
a. Trimer    b. Hexamer    c. Monomer    d. Heptamer
5. Example for radical sources for the polymerization reactions?  
a) Peroxides    b. Epoxides    c. Nitrenes    d. Carbenes
6. Two or more monomers are combined to form  
a. Co-ordination polymer    b. Co-polymer    c. Crystalline polymer  
d. Homo polymer
7. The metal in the co-catalyst is come from  
a. I to III    b. III to IV    c. IV and V    d. IV-VIII
8. R-Ti-Cl<sub>4</sub> is an  
a. bi-metallic catalyst    b. mono metallic catalyst  
c. tri metallic catalyst    d. alkyl catalyst
9. Monometallic mechanism proposed by  
a. Natta    b. Cossee    c. Robert    d. Wilson

10. The catalyst used for the Ziegler–Natta polymerizations?
  - a.  $\text{TiCl}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$
  - b.  $\text{BCl}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$
  - c.  $\text{TiCl}_3$  with  $\text{Fe}(\text{C}_2\text{H}_5)_2\text{Cl}$
  - d.  $\text{TiF}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{F}$
11. Which one is not a polymer?
  - a. Carbohydrates
  - b. Proteins
  - c. Carboxylic acid
  - d. Nucleic acid
12. The Polyesterification of a diol and a diacid will illustrate the general kinetics of a type of polymerization.
  - a. Step polymerization
  - b. Ionic polymerization
  - c. Radical polymerization
  - d. Self catalyzed polymerization
13. In free radical vinyl polymerization
  - a. The electrons in the pi bond split up
  - b. The electrons in the sigma bond split up
  - c. Non bonding electrons are used
  - d. Electrons from the functional group splits.
14. The alkyl resins are condensation polymers obtained from dibasic acids and
  - a. phenol
  - b. formaldehyde
  - c. Acetaldehyde
  - d. Glycol
15. Which find extensive use as radical sources?
  - a. Peroxides
  - b. Epoxides
  - c. Nitrenes
  - d. Carbenes
16. Which polymer is not a copolymer?
  - a. CCDDCCDDCCD
  - b. AAAAAAAAAAA
  - c. BBBBBAAAAAAAAA
  - d. CCCDDCCDDCCC
17. The various initiators are used at different temperatures depending on their rates of
  - a. Reaction
  - b. Decomposition
  - c. Composition
  - d. Entropy
18. In the monometallic mechanism monomer attacks the
  - a. Ti-Cl bond
  - b. Al-R bond
  - c. Ti-R bond
  - d. Al-Cl bond
19. Which of the following is an example of condensation polymer?
  - a. PVC
  - b. Polyamide
  - c. Terylene
  - d. Polyester
20. Polymers are?
  - a. Large molecule
  - b. small molecule
  - c. Small chain molecule
  - d. large chain molecule

### Section-B

(3x 2 = 6 marks)

Answer All The Questions

21. What is degree of polymerization?
22. Write briefly about self-polycondensation.
23. How inhibitors play role in addition polymerization?



**Section-C**  
**Answer All The Questions**

**(3x 8 = 24 marks)**

24. a. Explain the mechanism of step-growth polymerization.

Or

b. Write a note on free radical addition polymerization.

25. a. What are the types of addition polymers? Explain each one of them.

Or

b. Write a note on i) Monomer ii) Repeat unit iii) Polymer.

26. a. What is Ziegler-Natta catalyst? Explain it briefly.

Or

b. Write notes on Co-ordination polymerization.

Reg. No.....

[17CHP305A]

**KARPAGAM ACADEMY OF HIGHER EDUCATION  
COIMBATORE-21**

**(For the candidates admitted from 2017 & onwards)**

**M.SC DEGREE EXAMINATION-2018**

**III SEMESTER**

**INTERNAL TEST – I**

**M.SC., CHEMISTRY**

**POLYMER CHEMISTRY**

**DATE:  
TIME: 2 HRS**

**SUBJECT CODE: 17CHP305A  
TOTAL: 50 MARKS**

**Section-A  
Answer All The Questions**

**(20x1=20)**

1. **b. 50–70°C**
2. **d. Tetrafluroethene**
3. **c. Terylene**
4. **b. Hexamer**
5. **a. Peroxides**
6. **b. Co-polymer**
7. **d. IV-VIII**
8. **b. mono metallic catalyst**
9. **b. Cossee**
10. **a.  $\text{TiCl}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$**
11. **c. Carboxylic acid**
12. **a. Step polymerization**
13. **a. The electrons in the pi bond split up**
14. **a. phenol**
15. **a. Peroxides**
16. **b. AAAAAAAAAA**
17. **b. Decomposition**
18. **c. Ti-R bond**
19. **c. Terylene**
20. **d. large chain molecule**

**Section-B**  
**Answer All The Questions**

**3x 2 = 6**

**21. What is degree of polymerization?**

The **degree of polymerization**, or **DP**, is the number of monomeric units in a macromolecule or polymer or oligomer molecule.

For a homopolymer, there is only one type of monomeric unit and the *number-average* degree of polymerization is given by  $DP_n = X_n = M_n / M_0$ , where  $M_n$  is the number-average molecular weight and  $M_0$  is the molecular weight of the monomer unit. For most industrial purposes, degrees of polymerization in the thousands or tens of thousands are desired. This number does not reflect the variation in molecule size of the polymer that typically occurs, it only represents the mean number of monomeric units.


**22. What is self polycondensation?**

**Self-Condensation polymerization**

The monomer that are involved in condensation polymerization having different functional group (like alcohol, amine, or carboxylic acid-groups). Or same functional groups in the end of the same monomer. Instead of double bonds, these monomers have functional groups.

**23. What is the role of inhibitors in addition polymerization?**

Inhibitors react with the radical site of a growing polymer chain to give a less reactive radical. Benzoquinone is a typical inhibitor used in free radical polymerization reactions.



**Section-C**  
**Answer All The Questions**

**3x 8 = 24**

**24. a. Explain the mechanism of step-growth polymerization?**

**Stepwise polymerization**

A number of different chemical reactions may be used to synthesize polymeric materials by step polymerization. These include esterification, amidation, the formation of urethanes, aromatic substitution, and others. Polymerization usually proceeds by the reactions between two different functional groups, for example, hydroxyl and carboxyl groups, or isocyanate and hydroxyl groups. All step polymerizations fall into two groups depending on the type of monomer(s) employed. The first involves two different bifunctional and/or polyfunctional



monomers in which each monomer possesses only one type of functional group. (A polyfunctional monomer is a monomer with more than one functional group per molecule. A bifunctional monomer is one with two functional groups per molecule.) The second involves a single monomer containing both types of functional groups. The synthesis of polyamides illustrates both groups of polymerization reactions. Thus polyamides can be obtained from the reaction of diamines with diacids.



or from the reaction of amino acids with themselves:




The two groups of reaction can be represented in a general manner by the equations




where A and B are the two different types of functional groups. The characteristics of these two polymerization reactions are very similar. The successful synthesis of high polymers (i.e., polymer of sufficiently high molecular weight to be useful from the practical viewpoint) using any step polymerization reaction generally is more difficult than the corresponding small molecule reaction, since high polymers can be achieved only at very high conversions (>98–99%). A conversion of 90%, which would be considered excellent for the synthesis of ethyl acetate or methyl benzamide, is a disaster for the synthesis of the corresponding polyester or polyamide. The need for very high conversions to synthesize high polymer places several stringent requirements on any reaction to be used for polymerization—a favorable equilibrium and the absence of cyclization and other side reactions. These stringent requirements are met by a relatively small fraction of the reactions familiar to and used by chemists to synthesize small molecules. An additional requirement for achieving high molecular weights is the need for the A and B functional groups to be present at very close to stoichiometric amounts.


### **Kinetics of Stepwise Polymerisation:**

Consider the polyesterification of a diacid and a diol to illustrate the general form of the kinetics of a typical step polymerization. Simple esterification is a well-known acidcatalyzed reaction and polyesterification follows the same course [Otton and Ratton, 1988; Vancso-Szmercsanyi and Makay-Bodi, 1969]. The reaction involves protonation of the carboxylic acid,



followed by reaction of the protonated specie with the alcohol to yield the ester





3

In the above equations and are used to indicate all acid or alcohol species in the reaction mixture (i.e., monomer, dimer, trimer, . . . , n-mer). Species I and II are shown in the form of their associated ion pairs since polymerization often takes place in organic media of low polarity. (A<sup>-</sup>) is the negative counter ion derived from the acid HA. Polyesterifications, like many other step polymerizations, are equilibrium reactions. However, from the practical viewpoint of obtaining high yields of high-molecular-weight product such polymerizations are run in a manner so as to continuously shift the equilibrium in the direction of the polymer. In the case of a polyesterification this is easily accomplished by removal of the water that is a by-product of the reaction species II (Eq. 3).

Under these conditions the kinetics of polymerization can be handled by considering the reactions in Eqs. 2 and 3 to be irreversible.

The rate of a step polymerization is conveniently expressed in terms of the concentrations of the reacting functional groups. Thus the polyesterification can be experimentally followed by titrating for the unreacted carboxyl groups with a base. The rate of polymerization  $R_p$  can then be expressed as the rate of disappearance of carboxyl groups  $-d[\text{COOH}]/dt$ . For the usual polyesterification, the polymerization rate is synonymous with the rate of formation of species II; that is,  $k_4$  is vanishingly small (since the reaction is run under conditions that drive Eqs. 2 and 3 to the right), and  $k_1$ ,  $k_2$ , and  $k_5$  are large compared to  $k_3$ . An expression for the reaction rate can be obtained following the general procedures for handling a reaction scheme with the characteristics described [Moore and Pearson, 1981]. The rate of polymerization is given by

$$R = -d[\text{COOH}]/dt = k_3[\text{C}^+(\text{OH})_2][\text{OH}] \quad 4$$

Where  $[\text{COOH}]$ ,  $[\text{OH}]$ , and  $[\text{C}^+(\text{OH})_2]$  represent the concentrations of carboxyl, hydroxyl, and protonated carboxyl (I) groups, respectively. The concentration terms are in units of moles of the particular functional group per liter of solution. Equation 4 is inconvenient in that the concentration of protonated carboxylic groups is not easily determined experimentally. One can obtain a more convenient expression for  $R_p$  by substituting for  $\text{C}^+(\text{OH})_2$  from the equilibrium expression

$$K = k_1/k_2 = [\text{C}^+(\text{OH})_2] / [\text{COOH}][\text{HA}] \quad 5$$

for the protonation reaction (Eq. 1). Combination of Eqs. 4 and 5 yields

$$-d[\text{COOH}]/dt = k_3K[\text{COOH}][\text{OH}][\text{HA}] \quad 6$$


Two quite different kinetic situations arise from Eq. 6 depending on the identity of HA, that is, on whether a strong acid such as sulfuric acid or p-toluenesulfonic acid is added as an external catalyst.

Or

**b. Write a note on free radical addition polymerization?**

### Free-Radical polymerization

Initiation The initiation reaction produces free radicals. There are several ways to do this: •  
Chemical initiation The decomposition of the initiator (e.g. AIBN) forms free radicals:



where  $f$  is the initiator efficiency, typically  $f = [0.5, 1]$ . Note that in order to ensure a continuous production of radicals all over the process,  $1/k_d$  should be larger than the characteristic time of the polymerization reaction. Examples of the decomposition characteristic time,  $\tau_d$  for some commercial initiators are:

Acetyl peroxide 2 h 80 °C

Cumyl peroxide 12 h 110 °C

*t*-Butyl hydroperoxide 45 h 150 °C

Since this is a first order process,  $\tau_d = 1/k_d$ .

• Thermal initiation: thermal decomposition of the monomer (e.g. styrene).

This represents a danger, for example during monomer transportation, since it may lead to undesired polymerization of the monomer. For this reason, inhibitors (scavengers of radicals) are usually added to the monomers before storage. This causes the occurrence of a non reproducible induction period when such monomers are polymerized.

• Initiation by radiation


The decomposition of the initiator is caused by light or another source of radiation. Since this method is quite expensive, it is only applied to polymerization systems operating at very low temperatures.

## Initiation

Initiation is the first step in cationic polymerization. During initiation, a carbenium ion is generated from which the polymer chain is made. The counterion should be non-nucleophilic, otherwise the reaction is terminated instantaneously. There are a variety of initiators available for cationic polymerization, and some of them require a coinitiator to generate the needed cationic species.<sup>[7]</sup>


### Classical protonic acids

Strong protic acids can be used to form a cationic initiating species. High concentrations of the acid are needed in order to produce sufficient quantities of the cationic species. The counterion ( $\text{A}^-$ ) produced must be weakly nucleophilic so as to prevent early termination due to combination with the protonated olefin. Common acids used are phosphoric, sulfuric, fluoro-, and triflic acids. Only low molecular weight polymers are formed with these initiators.




### *Lewis acids/Friedel-Crafts catalysts*

Lewis acids are the most common compounds used for initiation of cationic polymerization. The more popular Lewis acids are  $\text{SnCl}_4$ ,  $\text{AlCl}_3$ ,  $\text{BF}_3$ , and  $\text{TiCl}_4$ . Although these Lewis acids alone are able to induce polymerization, the reaction occurs much faster with a suitable cation source. The cation source can be water, alcohols, or even a carbocation donor such as an ester or an anhydride. In these systems the Lewis acid is referred to as a coinitiator while the cation source is the initiator. Upon reaction of the initiator with the coinitiator, an intermediate complex is formed which then goes on to react with the monomer unit. The counterion produced by the initiator-coinitiator complex is less nucleophilic than that of the Brønsted acid  $\text{A}^-$  counterion. Halogens, such as chlorine and bromine, can also initiate cationic polymerization upon addition of the more active Lewis acids.<sup>[1]</sup>




### *Carbenium ion salts*

Stable carbenium ions are used to initiate chain growth of only the most reactive olefins and are known to give well defined structures. These initiators are most often used in kinetic studies due to the ease of being able to measure the disappearance of the carbenium ion absorbance. Common carbenium ions are trityl and tropylium cations.



### *Ionizing radiation*


Ionizing radiation can form a radical-cation pair that can then react with a monomer to start cationic polymerization. Control of the radical-cation pairs are difficult and often depend on the monomer and reaction conditions. Formation of radical and anionic species are often observed.



### **Propagation**

Propagation proceeds via addition of monomer to the active species, i.e. the carbenium ion. The monomer is added to the growing chain in a head-to-tail fashion; in the process, the cationic end group is regenerated to allow for the next round of monomer addition.





### ***Effect of temperature***

The temperature of the reaction has an effect on the rate of propagation. The overall activation energy for the polymerization ( $E$ ) is based upon the activation energies for the initiation ( $E_i$ ), propagation ( $E_p$ ), and termination ( $E_t$ ) steps:

$$E = E_i + E_p - E_t$$

Generally,  $E$  is larger than the sum of  $E_i$  and  $E_p$ , meaning the overall activation energy is negative. When this is the case, a decrease in temperature leads to an increase in the rate of propagation. The converse is true when the overall activation energy is positive.

Chain length is also affected by temperature. Low reaction temperatures, in the range of 170–190 K, are preferred for producing longer chains. This comes as a result of the activation energy for termination and other side reactions being larger than the activation energy for propagation. As the temperature is raised, the energy barrier for the termination reaction is overcome, causing shorter chains to be produced during the polymerization process.

### ***Effect of solvent and counterion***

The solvent and the counterion (the gegen ion) have a significant effect on the rate of propagation. The counterion and the carbenium ion can have different associations according to intimate ion pair theory; ranging from a covalent bond, tight ion pair (unseparated), solvent-separated ion pair (partially separated), and free ions (completely dissociated).



The association is strongest as a covalent bond and weakest when the pair exists as free ions.<sup>[6]</sup> In cationic polymerization, the ions tend to be in equilibrium between an ion pair (either tight or solvent-separated) and free ions. The more polar the solvent used in the reaction, the better the solvation and separation of the ions. Since free ions are more reactive than ion pairs, the rate of propagation is faster in more polar solvents.

The size of the counterion is also a factor. A smaller counterion, with a higher charge density, will have stronger electrostatic interactions with the carbenium ion than will a larger counterion which has a lower charge density. Further, a smaller counterion is more easily solvated by a polar solvent than a counterion with low charge density. The result is increased propagation rate with increased solvating capability of the solvent.


## Termination

Termination generally occurs via unimolecular rearrangement with the counterion. In this process, an anionic fragment of the counterion combines with the propagating chain end. This not only inactivates the growing chain, but it also terminates the kinetic chain by reducing the concentration of the initiator-coinitiator complex.




## Chain transfer

Chain transfer can take place in two ways. One method of chain transfer is hydrogen abstraction from the active chain end to the counterion. In this process, the growing chain is terminated, but the initiator-coinitiator complex is regenerated to initiate more chains.



Chain transfer by hydrogen abstraction to the counterion

The second method involves hydrogen abstraction from the active chain end to the monomer. This terminates the growing chain and also forms a new active carbenium ion-counterion complex which can continue to propagate, thus keeping the kinetic chain intact.



Chain transfer by hydrogen abstraction to the monomer

## 25. a. What are the types of addition polymers?

**Polymers** are long chain giant organic molecules are assembled from many smaller molecules called **monomers**. **Polymers** consist of many repeating monomer units in long chains. A polymer is analogous to a necklace made from many small beads (monomers). Many monomers are alkenes or other molecules with double bonds which react by **addition** to their unsaturated double bonds.

## Introduction


The electrons in the double bond are used to bond two monomer molecules together. This is represented by the red arrows moving from one molecule to the space between two molecules where a new bond is to form. The formation of polyethylene from ethylene (ethene) may be illustrated in the graphic on the left as follows. In the complete polymer, all of the double bonds have been turned into single bonds. No atoms have been lost and you can see that the monomers have just been joined in the process of addition. A simple

representation is  $-\text{[A-A-A-A-A]}-$ . Polyethylene is used in plastic bags, bottles, toys, and electrical insulation.

- **LDPE - Low Density Polyethylene:** The first commercial polyethylene process used peroxide catalysts at a temperature of 500 C and 1000 atmospheres of pressure. This yields a transparent polymer with highly branched chains which do not pack together well and is low in density. LDPE makes a flexible plastic. Today most LDPE is used for blow-molding of films for packaging and trash bags and flexible snap-on lids. LDPE is recyclable plastic #4.
- **HDPE - High Density Polyethylene:** An alternate method is to use Ziegler-Natta aluminum titanium catalysts to make HDPE which has very little branching, allows the strands to pack closely, and thus is high density. It is three times stronger than LDPE and more opaque. About 45% of the HDPE is blow molded into milk and disposable consumer bottles. HDPE is also used for crinkly plastic bags to pack groceries at grocery stores. HDPE is recyclable plastic #2.

### Other Addition Polymers

- **PVC (polyvinyl chloride)**, which is found in plastic wrap, simulated leather, water pipes, and garden hoses, is formed from vinyl chloride ( $\text{H}_2\text{C}=\text{CHCl}$ ). The reaction is shown in the graphic on the left. Notice how every other carbon must have a chlorine attached.
- **Polypropylene:** The reaction to make polypropylene ( $\text{H}_2\text{C}=\text{CHCH}_3$ ) is illustrated in the middle reaction of the graphic. Notice that the polymer bonds are always through the carbons of the double bond. Carbon #3 already has saturated bonds and cannot participate in any new bonds. A methyl group is on every other carbon.
- **Polystyrene:** The reaction is the same for polystyrene where every other carbon has a benzene ring attached. Polystyrene (PS) is recyclable plastic #6. In the following illustrated example, many styrene monomers are polymerized into a long chain polystyrene molecule. The squiggly lines indicate that the polystyrene molecule extends further at both the left and right ends.



- Blowing fine gas bubbles into liquid polystyrene and letting it solidify produces *expanded polystyrene*, called *Styrofoam* by the Dow Chemical Company.
- **Polystyrene with DVB:** Cross-linking between polymer chains can be introduced into polystyrene by copolymerizing with **p-divinylbenzene (DVB)**. DVB has vinyl groups ( $-\text{CH}=\text{CH}_2$ ) at each end of its molecule, each of which can be polymerized into a polymer chain like any other vinyl group on a styrene monomer.

Or

b. Write a note on i) Monomer ii) Repeat unit iii) Polymer?

### Monomer

A **monomer** (*/ˈmɒnəməɹ/ MON-ə-məɹ*) (*mono-*, "one" + *-mer*, "part") is a molecule that, as a unit, binds chemically or supramolecularly to other molecules to form a supramolecular polymer. Large numbers of monomer units combine to form polymers in a process called polymerization. It is a small molecule of an organic substance. A double bond exist between the individual molecule which is weak. Molecules of a small number of monomer units (up to a few dozen) are called oligomers. The term "monomeric protein" may also be used to describe one of the proteins making up a multiprotein complex.

### **Biopolymer groupings, and the types of monomers that create them:**

- For *lipids* (Diglycerides, triglycerides)\*, the monomers are **glycerol and fatty acids**.
- For *proteins* (Polypeptides), the monomers are **amino acids**.

### **Repeat unit**

A **repeat unit** or **repeating unit** is a part of a polymer whose repetition would produce the complete polymer chain (except for the end-groups) by linking the repeat units together successively along the chain, like the beads of a necklace.

A repeat unit is sometimes called a *mer* or *mer unit*. "Mer" originates from the Greek word "meros," which means part. The word polymer derives its meaning from this, which means "many mers." A repeat unit (or mer), is not to be confused with the term monomer, which refers to the small molecule from which a polymer is synthesized.

One of the simplest repeat units is that of the addition polymer polyvinyl chloride,  $-\text{[CH}_2\text{-CHCl]}_n-$ , whose repeat unit is  $-\text{[CH}_2\text{-CHCl]}-$ . In this case the repeat unit has the same atoms as the monomer vinyl chloride  $\text{CH}_2=\text{CHCl}$ . When the polymer is formed, the  $\text{C}=\text{C}$  double bond in the monomer is replaced by a  $\text{C}-\text{C}$  single bond in the polymer repeat unit, which links by two new bonds to adjoining repeat units.

### **Polymer**

The term "polymer" derives from the ancient Greek word *πολύς* (*polus*, meaning "many, much") and *μέρος* (*meros*, meaning "parts"), and refers to a molecule whose structure is composed of multiple repeating units, from which originates a characteristic of high relative molecular mass and attendant properties.

## **22 a) What is Ziegler-Natta catalyst explain it briefly?**

### **Ziegler-Natta catalysis and polymerization**

#### **Historical Development of Ziegler-Natta Initiators**

Various mechanisms have been proposed to explain the stereoselectivity of Ziegler-Natta initiators [Boor, 1979; Carrick, 1973; Corradini et al., 1989; Cossee, 1967; Ketley, 1967a,b; Tait and Watkins, 1989; Zambelli and Tosi, 1974]. Most mechanisms contain considerable details that distinguish them from each other but usually cannot be verified. In this section the mechanistic features of Ziegler-Natta polymerizations are considered with emphasis on those features that hold for most initiator systems.

The major interest will be on the titanium-aluminum systems for isoselective polymerization, more specifically,  $\text{TiCl}_3$  with  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$  and  $\text{TiCl}_4$  with  $\text{Al}(\text{C}_2\text{H}_5)_3$ —probably the most widely studied systems, and certainly the most important systems for industrial polymerizations. Before proceeding with the mechanistic consideration it is useful

to review the evolution of the Ti-Al initiator system for industrial applications. The original initiator used by Ziegler for ethylene polymerization was obtained in situ as a precipitate on mixing the components  $\text{TiCl}_4$  and  $\text{Al}(\text{C}_2\text{H}_5)_3$  in a hydrocarbon solvent. The mixture was used directly for initiating polymerization. Natta, recognizing that the major product of the reaction was  $\text{b-TiCl}_3$  (brown in color), explored various methods of performing it outside the polymerization system, for example, by reduction of  $\text{TiCl}_4$  with hydrogen, aluminum, and various alkylaluminum compounds. The stereoselectivity of these early initiator systems was low with isotactic indices of only 20–40% for polypropene. The isotactic index, a measure of the isotactic content of a polymer, is the percentage of the sample insoluble in a hydrocarbon solvent such as boiling n-heptane. This is not as informative a technique as high-resolution NMR since insoluble molecules may contain some syndiotactic and atactic sequences and soluble molecules may contain some isotactic sequences. It does, however, give a simple measure of isotacticity that is usually within about 10% of the value obtained from NMR, especially for highly isotactic samples.






There was a dramatic increase in stereoselectivity when the  $\alpha$ -,  $\delta$ -, or  $\gamma$ -crystalline form of  $\text{TiCl}_3$  (all violet in color) was used directly. The early generations of industrial processes used  $\text{TiCl}_3$  together with  $\text{Al}(\text{C}_2\text{H}_5)_3$  and/or  $\text{Al}(\text{C}_2\text{H}_5)_2\text{Cl}$ . Over a two decade period starting in the late 1950s, the isotactic indices for polypropene increased to the low 90 percentile range. The initiator activity was enhanced by various ball milling and heat treatments of the initiator components before and after mixing. Ball milling involves mechanical grinding and not only increases surface area but also facilitates reactions between the initiator components.

However, the activities were too low to allow the polymer products to be used without purification (by treatment with base or acid) to remove the residual metals, a process referred to as deashing. Also, optimization of the physical properties of the product often required removal of the atactic fraction. The initiator systems were inefficient with less than 1% of the Ti being active in polymerization. The later generations of initiators, starting in the late 1970s, increased initiator efficiency and activity without sacrificing stereoselectivity [Bohm, 2001; Busico and Cipullo, 2001; Cecchin et al., 2001; Chadwick, 2001; Chadwick et al., 2001; Chien et al., 1982; Hu and Chien, 1988]. The effective surface area of the active component of the initiator system was increased by close to 2 orders of magnitude by using  $\text{MgCl}_2$  as a solid support in which  $\text{TiCl}_4$  is finely dispersed. Stereoselectivity was kept high and actually increased by the addition of electron-donor additives.

A typical recipe for a present-day superactive or high-mileage initiator system involve ball milling of  $\text{MgCl}_2$  (or the alkoxide) and  $\text{TiCl}_4$  followed by the addition of  $\text{Al}(\text{C}_2\text{H}_5)_3$  with an electron donor (such as dialkyl phthalate and alkoxy silane) usually added in each step of preparation. Activity is 50–200 kg polymer per gram of initiator system. Typically, the initiator system is no more than 2–4% Ti, which makes the activity about 1500–6000 kg polymer per gram of Ti. The high activity not only minimizes initiator and production costs but also avoids the costly task of initiator removal from the polymer product (except possibly for food- and medical-grade products). Isotactic indices for polypropene have been increased to 98% or higher with (mmmm) pentad fractions up to 98% and higher. This not only improves the product's physical properties but also avoids the need to remove the atactic fraction.

### **Chemical Nature of Propagating Species**

Some early polymerizations reported as Ziegler–Natta polymerizations were conventional free-radical, cationic, or anionic polymerizations proceeding with low stereoselectivity. Some Ziegler–Natta initiators contain components that are capable of initiating conventional ionic polymerizations of certain monomers, such as anionic polymerization of methacrylates by alkyllithium and cationic polymerization of vinyl ethers by  $\text{TiCl}_4$ . Most Ziegler–Natta components participate in a complex set of reactions involving alkylation and reduction of the transition-metal component by the group I–III component as shown below for  $\text{TiCl}_4 + \text{AlR}_3$ :



Radicals produced in Eq. 8-31 are capable of initiating radical polymerizations with some monomers, for example, vinyl chloride. The mechanism for the stereoselective polymerization of  $\alpha$ -olefins and other nonpolar alkenes is a  $\pi$ -complexation of monomer and transition metal (utilizing the latter's d-orbitals) followed by a four-center anionic coordination insertion process in which monomer is inserted into a metal–carbon bond as described in Fig. 8-10. Support for the initial  $\pi$ -complexation has come from ESR, NMR, and IR studies [Burfield, 1984]. The insertion reaction has both cationic and anionic features. There is a concerted nucleophilic attack by the incipient carbanion polymer chain end on the  $\alpha$ -carbon of the double bond together with an electrophilic attack by the cationic counterion on the alkene  $\pi$ -electrons. The anionic character of the polymerization is consistent with the polymerization rate decreasing in the order ethylene > propene > 1-butene [Bier, 1961; Boor, 1967].

The reverse order is expected for a polymerization involving the conversion of a monomer into the corresponding carbocation. For addition of a carbanion to the monomers, attack occurs at the  $\alpha$ -carbon to form the less substituted (and more stable) carbanion. Further,  $\alpha$ -substituents sterically hinder the approach of a carbanion and/or counterion with the result that reactivity decreases with increasing substituent size. Evidence for the anionic nature of propagation also comes from studies in which labeled methanol is used to terminate chain growth. The terminated polymer is radioactive when  $\text{CH}_3\text{O}^{14}\text{H}$  is used, while termination by  $^{14}\text{CH}_3\text{OH}$  yields a nonradioactive polymer.

Or

a) **Write notes on Co-ordination polymerization?**

### **Coordination polymerization**

**Coordination polymerisation** is a form of addition polymerization in which monomer adds to a growing macromolecule through an organometallic active center. The development of this polymerization technique started in the 1950s with heterogeneous Ziegler-Natta catalysts based on titanium tetrachloride and an aluminium co-catalyst such as methylaluminoxane. Coordination polymerization has a great impact on the physical properties of vinyl polymers such as polyethylene and polypropylene compared to the same polymers prepared by other techniques such as free-radical polymerization. The polymers tend to be linear and not branched and have much higher molar mass. Coordination type polymers are also stereoregular and can be isotactic or syndiotactic instead of just atactic. This tacticity introduces crystallinity in otherwise amorphous polymers. From these differences in polymerization type the distinction originates between low-density polyethylene (LDPE), high-density polyethylene (HDPE) or even ultra-high-molecular-weight polyethylene (UHMWPE).

Polymerizations catalysed by metallocenes occur via the Cossee-Arlman mechanism. The active site is usually anionic but cationic coordination polymerization also exists.

In many applications Ziegler-Natta polymerization is succeeded by metallocene catalysis polymerization. This method is based on homogeneous metallocene catalysts such as the Kaminsky catalyst discovered in the 1970s. The 1990s brought forward a new range of post-metallocene catalysts.

Typical monomers are nonpolar ethylene and propylene. The development of coordination polymerization that enables copolymerization with polar monomers is more recent. Examples of monomers that can be incorporated are methyl vinyl ketones methyl acrylate and acrylonitrile.

### Kinetics

A case of heterogeneous polymerization.


It is defined : H is the surface of the transition-metal compound,

AR is the metal alkyl,


M is the monomer,

M<sub>x</sub> is the polymer.


Adsorption of metal alkyl from solution to form the active site




Adsorption of M from solution



Initiation




Propagation



Termination


(transfer)



Termination

(monomer forms an inactive site)





It is assumed that the process occurs in Langmuir isotherm condition and it is defined that :

$\Theta_A$  and  $\Theta_M$  are the fractions of the available surface covered by AR and M respectively,

$[C^*]$  is the concentration of growing chains,

Then the overall rate can be determined.

$$\theta_A = \frac{K_1 [AR]}{1 + K_1 [AR] + K_2 [M]} \quad \theta_M = \frac{K_2 [M]}{1 + K_1 [AR] + K_2 [M]}$$

The overall rate :

$$R_o = - \frac{d[M]}{dt} = (k_p + k_{tr}) \theta_M [C^*]$$

Assume that  $[C^*]$  reaches steady state so that the initiation rate is similar to the termination rate.

$$k_i \theta_A \theta_M = k_t [C^*] \theta_M$$

The overall rate :

$$R_o = - \frac{d[M]}{dt} = \frac{(k_p + k_{tr}) k_i}{k_t} \frac{K_1 K_2 [AR] [M]}{(1 + K_1 [AR] + K_2 [M])^2}$$

Reg. No.....

**KARPAGAM ACADEMY OF HIGHER EDUCATION  
COIMBATORE-21**

**(For the candidates admitted from 2017 & onwards)**

**M.SC DEGREE EXAMINATION-2018**

**III SEMESTER**

**INTERNAL TEST – II**

**M.SC., CHEMISTRY**

**POLYMER CHEMISTRY**

**DATE:**  
**TIME: 2 HRS**

**SUBJECT CODE: 17CHP305A**  
**TOTAL: 50 MARKS**

**Section-A**  
**Answer All The Questions**

**(20x1=20 marks)**

1. The weight average molecular degree of polymerisation indicates as  
a.  $D_p$                       b.  $(D_p)_w$                       c.  $(D_p)_n$                       d. D
2. A simple chemical compounds which have same molecular weight to form  
a. monodispersion      b. bi dispersion      c. poly dispersion      d. polymer solution
3. A polymer contains different molecular weight compounds to form  
a. monodispersion      b. bi dispersion      c. poly dispersion      d. polymer solution
4. The symbol  $M_n$  represents the  
a. Number-average molecular weight      b. Weight average molecular weight  
c. Viscosity average molecular weight      d. Vapor pressure molecular weight
5. Wet spinning technique is commercially used to produce filament yarn of  
a. Polypropylene      b. Polyester      c. Nylon 66      d. Acrylic
6. Which properties of fibers are quite complex and have been subject of much experimental work?  
a. Physical                      b. Mechanical                      c. Chemical                      d. Thermal
7. Crease resist finishing of cotton fabric does not lead to  
a. Reduction in tensile strength                      b. Increase in dimensional stability  
c. Increase in moisture regains                      d. Increase in bending length
8. Inhibiting the oxidation of polymers is usually filled by a substance which itself is readily oxidized.  
a. Antioxidants      b. Flame retardants      c. Colourants      d. Mgo

9. Any of a group of substances that are used in plastics or other materials to impart viscosity, flexibility, softness or other properties to the finished product  
a. Plasticizers    b. Antioxidants    c. Polymer initiators    d. Fillers
10. The symbol  $M_v$  represents the  
a. Number-average molecular weight    b. Weight average molecular weight  
c. Viscosity average molecular weight    d. Vapour pressure molecular weight
11. In polymer industry 2-hydroxybenzophenones are used as  
a. Light stabilizers    b. Antioxidants    c. Polymer initiators    d. Fillers
12. In melt spinning the temperature used for melting is about?  
a. 29K    b. 30K    c. 31K    d. 32K
13. One of the following is the most important fibers produced commercially?  
a. Nylons    b. Wood    c. Cotton    d. Silk
14. Plastics are?  
a. Hydrocarbons    b. Aldehydes    c. Ester    d. Amide
15. The intrinsic viscosity is also known as  
a. specific viscosity    b. reduced viscosity  
c. inherent viscosity    d. Staudinger viscosity
16. The rpm maintained for minute in the sedimentation equilibrium method is  
a. 30,000    b. 50,000    c. 15,000    d. 65,000
17. The error occurred in the viscometer due to the measurement of  
a. level of solute    b. density    c. nature    d. flow time
18. The phenomenon of depressing the freezing point of a liquid by the addition of solute is known as  
a. Cryoscopy    b. Ebulliometry    c. Osmometry    d. Vapour phase Osmometry
19. Which one of the following spinning methods, the polymer is melted by heating and then passed through a spinneret  
a. Melt spinning    b. Dry spinning    c. Wet spinning    d. Spinning
20. Any of a group of substances that are used in plastics or other materials to impart viscosity, flexibility, softness or other properties to the finished product  
a. Plasticizers    b. Antioxidants    c. Polymer initiators    d. Fillers

## Section-B

(3x 2 = 6 marks)

### Answer All The Questions

21. What is Fibre-Reinforced Plastics (FRP)?

22. Write briefly about glass transition temperature.

23. What is 'compounding' of the resin?

**Section-C**

**(3x 8 = 24 marks)**

**Answer All The Questions**

23. a. How to calculate the molecular weight of the polymer based on the number average method? Explain anyone of its experimental method.

Or

b. Give an account of viscosity methods.

24. a. What is calendaring technique? Explain it briefly.

Or

b. Write a note on injection moulding techniques.

26. a. Describe the compression moulding and Thermoforming techniques.

Or

b. Explain the ultracentrifugation techniques.

Reg. No.....

**KARPAGAM ACADEMY OF HIGHER EDUCATION  
COIMBATORE-21**

**(For the candidates admitted from 2017 & onwards)**

**M.SC DEGREE EXAMINATION-2018**

**III SEMESTER**

**INTERNAL TEST – II**

**M.SC., CHEMISTRY**

**POLYMER CHEMISTRY**

**DATE:  
TIME: 2 HRS**

**SUBJECT CODE: 17CHP305A  
TOTAL: 50 MARKS**

**Section-A  
Answer All The Questions**

**(20x1=20 marks)**

1. **b.  $(D_p)_w$**
2. **a. monodispersion**
3. **c. poly dispersion**
4. **a. Number-average molecular weight**
5. **d. Acrylic**
6. **b. Mechanical**
7. **c. Increase in moisture regains**
8. **a. Antioxidants**
9. **a. Plasticizers**
10. **c. Viscosity average molecular weight**
11. **a. Light stabilizers**
12. **b. 30K**
13. **Nylons**
14. **a. Hydrocarbons**
15. **d. Staudinger viscosity**
16. **d. 65,000**
17. **d. flow time**
18. **a. Cryoscopy**
19. **a. Melt spinning**
20. **a. Plasticizers**

**Section-B**  
**Answer All The Questions**

**(3x 2 = 6 marks)**

**21. What is Fibre-Reinforced Plastics (FRP)?**

Fibre-reinforced plastic (FRP) (also called fiber-reinforced polymer, or fiber-reinforced plastic) is a composite material made of a polymer matrix reinforced with fibres. The fibres are usually glass (in fibreglass), carbon (in carbon-fiber-reinforced polymer), aramid, or basalt. Rarely, other fibres such as paper, wood, or asbestos have been used. The polymer is usually an epoxy, vinylester, or polyester thermosetting plastic, though phenol formaldehyde resins are still in use.

FRPs are commonly used in the aerospace, automotive, marine, and construction industries. They are commonly found in ballistic armor as well.

**22. Write briefly about glass transition temperature.**

The **glass-liquid transition** or **glass transition** for short is the reversible transition in [amorphous](#) materials (or in amorphous regions within [semicrystalline](#) materials) from a hard and relatively brittle "glassy" state into a viscous or rubbery state as the temperature is increased. An amorphous solid that exhibits a glass transition is called a [glass](#).

**23. What is 'compounding' of the resin?**

**Compounded Resins**

Compounded Resins are quite common in our industry. Sometimes the additive has processing characteristics so similar to the basic resin that you can dry and process in exactly the same manner as is indicated for the main ingredient.

**Section-C**  
**Answer All The Questions**

**(3x 8 = 24 marks)**

**23. a. How to calculate the molecular weight of the polymer based on the number average method. Explain anyone of its experimental method?**

**Concept of Average Molecular Weight**

A specified polymer material is generally a mixture of molecules of identical or near – identical chemical structure and composition, but differing in degree of polymerization (DP) or molecular weight. The molecules produced by polymerization reaction have chain lengths that are distributed according to a probability function that is governed by the polymerization mechanism and by the condition prevailing during the process. A concept of average molecular weight, therefore, assumes importance and very much

relevant. However, assignment of a numerical value to the molecular weight will be dependent on the definition of a particular average. An average molecular weight,  $M$  may in fact be generally expressed as

$$M = f_1 M_1 + f_2 M_2 + f_3 M_3 + \dots = \sum f_i M_i \quad (1)$$

Here,  $M_1, M_2, M_3$  etc. refer to molecular weights of different sizes of molecules and the coefficients  $f_1, f_2, f_3$  etc. are fractions such that their summation  $\sum f_i$  equals to unity. The average molecular weight  $M$  may otherwise be expressed as

$$M = \frac{\sum N_i M_i^a}{\sum N_i M_i (a - 1)} \quad (2)$$

where,  $N_i$  is the number of molecules, each of which is characterized by the molecular weight  $M_i$  and the index 'a' may have any real value. Two very important average molecular weight widely recognized and used are (i) number average molecular weight,  $M_n$  and (ii) weight average molecular weight,  $M_w$ . Setting  $a = 1$  in equation (2), one obtains the expression for the number average molecular weight,  $M_n$  :

$$M_n = \frac{\sum N_i M_i}{\sum N_i} \quad (3)$$

Equation (3) can, in fact, be expressed as a simple summation series resembling equation (1) where the fractional coefficients are actually the mole fractions of the respective molecular species existing in the polymer system such that total weight  $W = \sum N_i M_i$  and total number of molecules  $N = \sum N_i$ , Thus,

$$\begin{aligned} M_n &= \frac{W}{N} = \frac{\sum N_i M_i}{\sum N_i} = \frac{N_1 M_1 + N_2 M_2 + N_3 M_3 + \dots}{N} \\ &= f_1 M_1 + f_2 M_2 + f_3 M_3 + \dots \end{aligned} \quad (4)$$

On the other hand, however, setting  $a = 2$  in equation (2), one finds the expression for weight average molecular weight,  $M_w$ , i.e.,

$$\sum N_i M_i^2$$



$$M_w = \frac{\sum N_i M_i}{\sum N_i} \quad (5)$$

Equation (5) can also be rearranged and expressed as a summation series as given by equation (1), but in this case, the fractional coefficients actually correspond to weight fractions of different molecular species present. So, one may write :

$$\begin{aligned} M_w &= \frac{\sum N_i M_i}{\sum N_i} = \frac{\sum w_i M_i}{\sum w_i} = \frac{\sum w_i M_i}{W} \\ &= \frac{w_1}{W} M_1 + \frac{w_2}{W} M_2 + \frac{w_3}{W} M_3 + \dots \\ &= f_1 M_1 + f_2 M_2 + f_3 M_3 + \dots \quad (6) \end{aligned}$$

Here,  $w_1$  ,  $w_2$  ,  $w_3$  , etc. stand for weight of different molecular species having molecular weight  $M_1$  ,  $M_2$  ,  $M_3$  etc. respectively and  $\sum w_i = W$  gives the total weight of all the molecules present.

The obvious consequences of above definitions imply that  $M_w \geq M_n$  , i.e.,  $M_w / M_n \geq 1$ ; the equality, however, relates to a perfectly monodisperse polymer sample where all the polymer molecules are of equal molecular weight, i.e.  $M_1 = M_2 = M_3 = \dots = M$ . So, for monodisperse systems,  $(M_w / M_n) = 1$ . Deviation from unity of the ratio  $M_w / M_n$  , known as the distribution ratio is taken as a measure of polydispersity of the polymer sample. The said ratio is also referred to as polydispersity index; a higher value of the ratio means a greater polydispersity.

Evaluation of number average molecular weight is helpful for having a good understanding of polymerization mechanism and relevant kinetics.  $M_n$  is useful in the analysis of kinetic data and assessing or ascertaining effects of many side reactions such as chain transfer, inhibition and retardation and also autoacceleration effects during vinyl and related polymerizations. The number average molecular weight assumes prime importance in the context of studies of solution properties that go by the name of colligative properties viz., vapour pressure lowering, freezing point depression, boiling point evaluation and osmometry. Polymer molecules of lower molecular weight or even

low molecular weight soluble impurities contribute equally and enjoy equal status with polymer molecules of higher molecular weights in determining the colligative properties.

On the other hand, weight average molecular weight assumes importance in the context of various bulk properties of polymers, particularly the rheological and resistance properties. Softening/melting and hot deformation, melt – viscosity or melt – flow, tensile and compressive strength, elastic modulus and elongation at break, toughness and impact resistance and some other bulk properties of polymers are better appreciated on the basis of weight average molecular weight, keeping in mind, however, the influence of chemical nature of the repeat units, degree of branching and cross linking, thermal or thermomechanical history of the polymer sample, etc.

### **Number Average Molecular Weight**

Number average molecular weight can be evaluated using dilute solution of a polymer making use of ebulliometric (boiling point elevation), cryoscopic (freezing point depression) and osmometric (membrane osmometry) measurements. Direct measurements of vapour pressure lowering of dilute polymer solution lack precision and mostly produce uncertain results. Vapour – phase osmometry, however, allows indirect exploitation of vapour pressure lowering of polymer solution at equilibrium as can be related through the Clapeyron equation and in this method, one measures a temperature difference that can be related to vapour pressure lowering. This difference in temperature is comparable to or of the same order of magnitude as those observed in cryoscopy and ebulliometry. These methods require calibration with low molecular weight standards and they may produce reliable results for polymer molecular weights < 30,000. The working equations for ebulliometric, cryoscopic and osmometric measurements are as follows:

$$\lim_{c \rightarrow 0} \frac{\Delta T_b}{c} = \frac{RT^2}{\rho \Delta H_v} \cdot \frac{1}{M} \quad (7)$$

$$\lim_{c \rightarrow 0} \frac{\Delta T_f}{c} = \frac{RT^2}{\rho \Delta H_f} \cdot \frac{1}{M} \quad (8)$$

$$\lim_{c \rightarrow 0} \frac{\pi}{c} = \frac{RT}{M} \quad (9)$$

where,  $\Delta T_b$ ,  $\Delta T_f$ , and  $\pi$  are boiling point elevation, freezing point depression and osmotic pressure,  $\rho$  is the density of the solvent,  $\Delta H_v$  and  $\Delta H_f$  are respectively the latent heat of vaporization and of fusion of the solvent per gram,  $c$  is the polymer (solute) concentration in g/cm<sup>3</sup> and  $M$  is the solute molecular weight. Very low observed temperature differences (of the order of 10<sup>-3</sup> °C) for low finite concentrations of a polymer of the molecular weight range of  $\geq 20,000$  and lack of development of equipments for ebulliometric and cryoscopic measurements have turned them unattractive and less useful. Vapour pressure lowering for low finite concentrations is also very low (of the order of 10<sup>-3</sup> mm Hg) for such polymers. The osmotic method is in more wide use than other colligative techniques as because the osmotic response is of a magnitude that is easily observable and measurable, even though success of this method is contingent upon availability of perfect osmotic membranes.

Or

## **b. Give an account of viscosity methods?**

### **Introduction**

Viscosity of a polymer solution depends on concentration and size (i.e., molecular weight) of the dissolved polymer. By measuring the solution viscosity we should be able to get an idea about molecular weight. Viscosity techniques are very popular because they are experimentally simple. They are, however less accurate and the determined molecular weight, the viscosity average molecular weight, is less precise. For example,  $M_v$  depends on a parameter which depends on the solvent used to measure the viscosity. Therefore the measured molecular weight depends on the solvent used. Despite these drawbacks, viscosity techniques are very valuable. This chapter discusses the theory and methods for determining polymer molecular weight by measuring solution viscosity.

### 6.2 Viscosity and Viscosity Nomenclature

Figure 6.1 shows a piece of a liquid moving at a strain rate  $\dot{\gamma}$  under an applied shear stress of  $\tau$ . The viscosity of the liquid is the ratio of the applied shear stress to the resulting strain rate (or equivalently, the ratio of the shear stress required to move the solution at a fixed strain rate to that strain rate). The shear strain in Fig. 6.1 is  $\gamma = du/dy$  (6.1) where  $u$

is displacement in the x direction. The strain rate is therefore  $\dot{\gamma} = \frac{d}{dt} \frac{du}{dy} = \frac{d}{dy} \frac{du}{dt} = \frac{dv_x}{dy}$  (6.2) where  $v_x$  is velocity in the x direction. The relations between viscosity ( $\eta$ ), shear stress ( $\tau$ ), and shear rate ( $\dot{\gamma}$ ) are  $\tau = \eta \dot{\gamma}$  or  $\dot{\gamma} = \tau / \eta$  or  $\eta = \tau / \dot{\gamma}$  (6.3) 77 78

## VISCOSITY

$F \tau = F A \frac{d\gamma}{dt} \dot{\gamma} = \dot{\gamma}$  Figure 6.1: A piece of a liquid moving at shear rate  $\dot{\gamma}$  under an applied shear stress of  $\tau$ . A Newtonian fluid is one in which the viscosity is independent of the shear rate. In other words a plot of shear stress versus shear strain rate is linear with slope  $\eta$ . In Newtonian fluids all the energy goes into sliding molecules by each other. In non-Newtonian fluids, the shear stress/strain rate relation is not linear. Typically the viscosity drops at high shear rates — a phenomenon known as shear thinning. Although the following development will not discuss shear rate effects in detail, the possibility of experimental results being affected by the shear rate of the measurement should be kept in mind. Plots of shear force vs. shear rate for Newtonian and non-Newtonian fluids are given in Fig. 6.2. We let  $\eta_0$  be the viscosity of the pure solvent and  $\eta$  be the viscosity of a solution using that solvent. Several methods exist for characterizing the solution viscosity, or more specifically, the capacity of the solute to increase the viscosity of the solution. That capacity is quantified by using one of several different measures of solution viscosity. The most common solution viscosity terms are: 1. Relative viscosity  $\eta_r = \eta / \eta_0$  (6.4) 2. Specific viscosity  $\eta_{sp} = \eta - \eta_0$   $\eta_0 = \eta_r - 1$  (6.5) 3. Inherent Viscosity  $\eta_i = \ln \eta_r / c$  (6.6) 4. Intrinsic Viscosity  $[\eta] = \lim_{c \rightarrow 0} \eta_{sp} / c$

## VISCOSITY AND VISCOSITY NOMENCLATURE


Shear Force Non-Newtonian Newtonian Shear Rate Shear Force Figure 6.2: Schematic plots of shear force vs. shear rate for Newtonian and non-Newtonian fluids. In these equations,  $\eta$  is solution viscosity,  $\eta_0$  is viscosity of the pure solvent, and  $c$  is concentration. Relative viscosity is self-explanatory. Specific viscosity expresses the incremental viscosity due to the presence of the polymer in the solution. Normalizing  $\eta_{sp}$  to concentration gives  $\eta_{sp}/c$  which expresses the capacity of a polymer to cause the solution viscosity to increase; i.e., the incremental viscosity per unit concentration of polymer. As with other polymer solution properties, the solutions used for viscosity measurements will be nonideal and therefore  $\eta_{sp}/c$  will depend on  $c$ . As with osmotic pressure, it will probably be useful to extrapolate to zero concentration. The extrapolated value of  $\eta_{sp}/c$  at zero concentration is known as the intrinsic viscosity —  $[\eta]$ .  $[\eta]$  will be shown to be a unique function of molecular weight (for a given polymer-solvent pair) and measurements of  $[\eta]$  can be used to measure molecular weight. The remaining form for the viscosity is the inherent viscosity. Like  $\eta_{sp}$ ,  $\ln \eta_r$  is zero for pure solvent and increases with increasing concentration, thus  $\ln \eta_r$  also expresses the incremental

viscosity due to the presence of the polymer in the solution. Normalizing  $\ln \eta_r$  to concentration or  $\ln \eta_r/c$  gives the inherent viscosity. In the limit of zero concentration,  $\eta_i$  extrapolates the same as  $\eta_{sp}/c$  and becomes equal to the intrinsic viscosity. This can be proved by:  $\lim_{c \rightarrow 0} \ln \eta_r c = \lim_{c \rightarrow 0} \ln (1 + \eta_{sp}) c = \lim_{c \rightarrow 0} \eta_{sp} c = [\eta]$  (6.8) We can thus find  $[\eta]$  by extrapolating either  $\eta_{sp}/c$  or  $\eta_i$  to zero concentration. When  $c$  is not equal to zero the specific viscosity and inherent viscosities will be different, even for an ideal solution. In ideal solutions  $\eta_{sp}/c$  will be independent of concentration, but  $\eta_i$  will depend on concentration.

**24. a. What is calendaring technique? Explain it briefly.**

Plastics are mainly organic polymers of high molecular mass, but they sometimes contain other substances as well. Plastics are usually synthetic, most commonly derived from petrochemicals, but many are partially natural. Plastics are usually classified by their chemical structure of the polymer's backbone and side chains. Some important groups in these classifications are the acrylics, polyesters, silicones, polyurethanes, and halogenated plastics. There are a variety of methods used to process plastic. Each method has its advantages and disadvantages and are better suited for specific applications. There are various plastic processing techniques.

**Calendering**




Calendering is a continuous process which works in much the same way as an old-fashioned clothes mangle. For plastics, there are usually four heated rollers of different sizes rotating at slightly different speeds. The material is fed into these rollers, heated and melted, then shaped into a sheet or film. This is then cooled and rolled up. The sheets can be mono-oriented during this process. The most commonly calendered material is PVC.

Or

**b. Write a note on injection moulding techniques?**


**Injection molding**



Injection molding is a manufacturing process for producing parts by injecting material into a mold. The main method used for processing plastic is injection molding. With this process, the plastic is placed into a hopper. The hopper then feeds the plastic into a heated injection unit, where it is pushed through a long chamber with a reciprocating screw. Here, it is softened to a fluid state. A nozzle is located at the end of the chamber. The fluid plastic is forced through the nozzle into a cold, closed mold. The halves of the mold are held shut with a system of clamps. When the plastic is cooled and solidified, the halves open and the finished product is ejected from the press.


## 26. a. Explain the method of compression moulding and Thermoforming.

### Compression molding



Compression molding is the most common process used with thermosetting materials and is usually not used for thermoplastics. With this process, the material is squeezed into its desired shape with the help of pressure and heat. Plastic molding powder and other materials are added to the mix in order to create special qualities or to strengthen the final product. When the mold is closed and heated, the material goes through a chemical change that causes it to harden into its desired shape. The amount temperature, amount of pressure, and length of time utilized during the process depends on the desired outcome.

### Thermoforming



Thermoforming is a manufacturing process where a plastic sheet is heated to a pliable forming temperature, formed to a specific part shape in a mold, and trimmed to create a usable product. The sheet, or film when referring to thinner gauges and certain material types, is heated in an oven to a high-enough temperature that it can be stretched into or onto a mold and cooled to a finished shape. The second animation shows the twin sheet thermoforming process whereby two individual components are fused together through the application of tremendous pressure which forces two molds together, thereby fusing the materials together.


Or

**b. Write a note on ultracentrifugation techniques?**

Analytical ultracentrifugation (AUC) is a powerful method for the characterization of polymers, biopolymers, polyelectrolytes, nanoparticles, dispersions, and other colloidal systems. The method is able to determine the molar mass, the particle size, the particle density and interaction parameters like virial coefficients and association constants. Because AUC is also a fractionation method, the determination of the molar mass distribution, the particle size distribution, and the particle density distribution is possible.

In an analytical ultracentrifuge, a sample being spun can be monitored in real time through an optical detection system, using ultraviolet light absorption and/or interference optical refractive index sensitive system. This allows the operator to observe the evolution of the sample concentration versus the axis of rotation profile as a result of the applied centrifugal field. With modern instrumentation, these observations are electronically digitized and stored for further mathematical analysis. Two kinds of experiments are commonly performed on these instruments: sedimentation velocity experiments and sedimentation equilibrium experiments.





Sedimentation velocity experiments aim to interpret the entire time-course of sedimentation, and report on the shape and molar mass of the dissolved macromolecules, as well as their size-distribution. The size resolution of this method scales approximately with the square of the particle radii, and by adjusting the rotor speed of the experiment size-ranges from 100 Da to 10 GDa can be covered. Sedimentation velocity experiments can also be used to study reversible chemical equilibria between macromolecular species, by either monitoring the number and molar mass of macromolecular complexes, by gaining information about the complex composition from multi-signal analysis exploiting differences in each components spectroscopic signal, or by following the composition dependence of the sedimentation rates of the macromolecular system, as described in Gilbert-Jenkins theory.

Sedimentation equilibrium experiments are concerned only with the final steady-state of the experiment, where sedimentation is balanced by diffusion opposing the concentration gradients, resulting in a time-independent concentration profile. Sedimentation equilibrium distributions in the centrifugal field are characterized by Boltzmann distributions. This experiment is insensitive to the shape of the macromolecule, and directly reports on the molar mass of the macromolecules and, for chemically reacting mixtures, on chemical equilibrium constants.

The kinds of information that can be obtained from an analytical ultracentrifuge include the gross shape of macromolecules, the conformational changes in macromolecules, and size distributions of macromolecular samples. For macromolecules, such as proteins, that exist in chemical equilibrium with different non-covalent complexes, the number and

subunit stoichiometry of the complexes and equilibrium constant constants can be studied.

Analytical ultracentrifugation has recently seen a rise in use because of increased ease of analysis with modern computers and the development of software, including a National Institutes of Health supported software package, SedFit.